

REMOTE

SPEAKER & MIC



GUIDELINES FOR WEARING YOUR CONTROLLER



For optimal audio performance and microphone placement, please ensure the Remote Speaker is worn on the upper chest area. Avoid wearing the speaker directly on the top of your shoulders or your mic performance will be degraded.

Pacemaker and Other Implanted Devices:

This Relay accessory contains magnets and could interfere with pacemakers or other electronic medical devices. Before using this Relay Accessory, consult with your doctor or medical device manufacturer about the required safe distance between Relay accessory and your medical device.

FCC ID: 2AMBHR220310 IC: 25353-R220310

relaypro.com/safety-and-warranty