



Button Control FUNCTION OPERATION Power on/off Hold the Power Button for 2 seconds. Answer a call/ Tap the Power Button. Reject a call/ Double click the Power Button. Tap the Multi-function Play/Pause Tap the Previous Track Previous track Next track Tap the Next Track Button Volume up/ Tap the Volume+ / down Volume- button. Disconnect Hold the Next Track for 2 Bluetooth seconds. Voice dial (Siri on iPhone Button. EQ (Switch two (will hear long "du" prompt sound) EQ settings) Hold the Multi-Function

(will hear short "dudu"prompt sound)

Button for over 2 seconds to

switch to another EQ.

Charging Indicator On Charging Indicator Off How to Use Charging 1. Connect the charger to the USB port on the speaker. Connect the USB on the other end of the charger to any USB charging adapter or active computer USB port 3. Charging will start automatically with the charging indicator turning red. 4. The speaker is fully charged when the charging indicator turns off.

LED Indicator

. Please make sure the speaker is within Bluetooth indicator flashes white Pairing mode Bluetooth indicator becomes solid white 3 feet of your device, like a cell phone. 2. Press and hold the Power Button for 5 seconds until the white light flashes. You will also hear a prompt sound. 3. Turn on the Bluetooth function on your phone and search for nearby Bluetooth For iOS: Settings > General > Bluetooth

Pairing with Bluetooth Device

> Scan for devices

tap on it to connect.

2.Enable your device's NFC function. 3. Put your device near the NFC chip 4.Click "Yes" on your device's screen to confirm Bluetooth connection. 5.When the Bluetooth speaker and your device are successfully paired, the white indicator will be solid. For Android: Settings > Bluetooth > On 4. Find "MBOX" in the search results and Connect any device to the MBOX using a 3.5mm AUX cable. A prompt sound will be 5. The Bluetooth indicator will turn solid

will also hear a prompt sound.

1. Press and hold the Power Button for 5 To reset the speaker, please use a 1.0mm seconds until the white light flashes. You pin or probe to press the reset button for 5 seconds. 1. When not in use, please power off the speaker and store in a cool, dry place. 2. The operational range of the speaker may be influenced by obstructions, such as walls, pillars, etc. To ensure a stable connection, we recommend avoiding such obstructions whenever possible and/or shortening the distance during use. 3. To protect the long-term performance of the battery, please do not place the speaker in high temperatures above 140°F/60℃, such as in a hot vehicle or under direct sunlight.

Pairing with a NFC-Supportive Device Restore to Factory Settings

Bluetooth Profile	A2DP.AVRCP.HSP
Audio Output	2X8W
Operating Range	10 meters/33 feet
Working Time	About 12 hours
Charging Power	DC 5V/1A
Charging Time	About 3~4hours
Weight	350g/12.3oz
Dimensions	16.6x6x4.7cm 6.5x2.36x1.85in

FAQ and Solutions 1. My speaker will not switch on. a. Please recharge it and make sure it has enough power.

b. Plug the unit into a charger and see if the LED indicator becomes solid red. 2. Why can't the speaker connect to my device? a. Check to ensure the Bluetooth

function of your device is enabled. b. Make sure your device is within 3ft/1m of the speaker.

c. Try tapping on the previous paired device to see if they can be connected

d. Delete the pairing record(s) on the speaker or your device. And, re-pair them. 3. Can I use the speaker to play music

while charging?

attempting to connect. c. Disable the Bluetooth connection of

Warranty and contact info

To protect the long-term performance of Warranty the battery, it is better to charge when the speaker is turned off, especially when the the date of purchase, we offer a 30-day

through the speaker? Yes. The speaker has a built-in

microphone. 5. Why can't I connect by NFC?

a. Make sure that your device supports NFC functionality.

b. Keep your mobile device close to the email to the address below and we will NFC chip location of the speaker when

the speaker to other devices.

FCC STATEMENT:

We guarantee that every product has Rules. Operation is subject to the following been tested before shipping. Following two conditions: (1) This device may not cause

4. Can I make or answer phone calls money-back guarantee and a 12 months warranty. For detailed information, please contact our customer service.

For any inquiries, issues or comments concerning our products, please send an

respond as soon as possible. E-mail: support@hussar.com Website: www.hussar.com

HUSSAR

protection against harmful interference in a This device complies with Part 15 of the FCC residential installation. This equipment generates uses and can radiate radio frequency energy and,

if not installed and used in accordance with the harmful interference, and (2) This device must

instructions, may cause harmful interference to accept any interference received, including

approved by the party responsible for compliance

NOTE: This equipment has been tested and found

could void the user's authority to operate the

to comply with the limits for a Class B digital

device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable

radio communications. However, there is no The device has been evaluated to meet general RF interference that may cause undesired operation.

guarantee that interference will not occur in a particular exposure requirement. The device can be used in Warning: Changes or modifications not expressly

interference to radio or television reception, which

the user is encouraged to try to correct the

Reorient or relocate the receiving antenna.

can be determined by turning the equipment off and on,

interference by one or more of the following measures:

Increase the separation between the equipment and

installation. If this equipment does cause harmful

RF warning statement:

technician for help.

portable exposure condition without restriction.

Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV