

Photographs ----- 01 Instructions-----02 FAQS-----03 How to charge-----04 Specifications------05

01. Photograhs 1. Structure microphone part console part audio part audioutput charging/recording /audio input

2.Standard accessorise





audio/recoding line

USB charging line

- 1. When the battery voltage is too low, the product will automatically shutdown;
- 2. Using USB cable to connect with mobile phone standard jack. The red light will light;
- 3. Normal charging 2 hours, charging is completed, the red light is automatically extinguished;
- 4. Normal conditions continue 6-8 hours.

- Pickup device: capacitance
- Output power: 10mW (headphone output)
- 5W (speaker output)
- Frequency range: 100Hz-10KHz
- Maximum sound pressure level: >115dB 1KHz THD<1%
- Reverb mode: echo sound reverberation
- Power supply: external rechargeable lithium-ion battery
- Charging source: DC5V
- Battery capacity: 1500 mAh

03. FAQs

Status	Reasons	Solutions
LCD does not light	Electricity is too lo or charging cable is not plugged in	Charging, checking
N 0 sound	Switch is not turned on or The voice volum not adjusted	e Turn on the swith or turn VOL
Microphone without reverberation	ECH key needs to adjust	Adjust ECH to the suitable location
Presence of noise	Environmental noise, mobile phone signal interference	Adjust the distance between microphone and phone
Some types of mobile phone recording effect is poor	Phone does not match, phone chip processing ability that is weak	Restart the phone to try or replace the existing mobile phone
mich prajring the	Microphone is too far or there are obstructio between microphone and mobile phone	Close to mobile phone, keep away from obstructions
Accompanment sounds weak or without sound	The mobile phone sound is too low or music flies quality is bad	Open media volume, download high quality flies
Phone can't connect to the bluetooth	too far, already connected to another	Close to mobile phonekeep away from obstructions Cancel the connection
Playin g music is not real	Volume too high, electricity is too low	Turn down mobile phone volume, charge the battery
Bluetooth cannot	IOS system don't	Choose a music

How to sing 1. Power: turn on the power switch, the blue light will be

2. Bluetooth connection: open your mobile phone bluetooth, after searching KTV-K088, Pairing connections connecting handheld KTV issued can be heard after 'tick' sound (Note:Pairing process to enter a password, enter '0000');

3. Music: open cell phone music player such as 'cool music' to download that you like songs or to play the music to start playing. (Note:accompaniment volume can be adjusted via mobile phone);

4. Adjusting sound:adjust sound volume of microphone and intensity of reverb in place; 5. Start singing

Bluetooth with memory function. Once they had have one time connection with mobile phones, they will automatically connect nexttime.

If you need to disconnect, you can settings disconnect by If you just listen to the music, you can adjust microphone

volume to a minimum. $How\ to\ record$

1. Connecting audio line: take out audio line, plug the USB plug into a pocket KTV audio jack, bluetooth will automatically disconnect at this time.

 $2. \ \mbox{Connecting phone:}$ audio cord $3.5\mbox{mm}$ Jack on the other end into the headphone jack of phone.

As follow





If insert the tape line, bluetooth will automatically turn off

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following This device compliance with Part 13 of the PCC chains. Operation is subject to the indiowing two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.