

TableofContents

Index	1
Safety Instructions	2
Base Control Functions	4
Key features	6
Get Started	7
Bluetooth Mode	8
Telephone answering	9
How to get into AUX Mode	9
Summary	10
Warranty	12

1 Safety Instructions

The speaker contains controls and battery within its case – these can get warm.

- ◆ Do not place or install this speaker in a confined or built-in space such as a book case or similar unit, Keep the speaker well ventilated.
- ◆ Ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- ◆ WARNING: Only use attachments/accessories specified or provided by the manufacturer (such as the exclusive power adapter).
- ◆ WARNING: Please refer to the information the base of the speaker stand for electrical and safety information before installing or operating the apparatus.
- ◆ WARNING: This speaker is not water proof. Do not use in rain or where there is risk of contact with water such as bathrooms and showers.
- ◆ To reduce the risk of fire or electric shock, do not expose this speaker to rain or moisture. The speaker should not be exposed to dripping or splashing and objects filled with liquids, such as vases, should not be placed on the speaker.
- ◆ WARNING: Make sure that the right adapter relevant to your country is attached to the power connector. Only use from the selection provided.

- ◆ When not in use and during movement, please take care of the power supply unit, tie the cable carefully, avoid folding the cable tightly.

Before use, make sure the power cord set is not damaged. If any damage is found, please replace the power cord set with one that matches that specified by the manufacturer.

◆ Correct Disposal of this product. This marking indicates that this product should not be disposed with other household waste throughout the EU. To prevent possible harm to the environment or human health from excessive waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. Take this product for environmental safe recycling.

◆ No naked flame sources, such as lighted candles, should be placed on the speaker.

◆ This speaker is designed to function within moderate climates.

◆ When carrying the speaker – hold it from the bottom of the base –

be careful not to mark or scratch the face.

◆ Use a soft cleaning cloth (such as, glasses lens cleaner) when cleaning speaker – do not use any cleaning agents, this could cause damage to the plastic or electro plating.

◆ When transporting your speaker use the dust bag provided.

Outersurfacecanscratcheasily


Take care when handling your Speaker

2 Base Control Functions





1. Poweron/offswitch
2. PowerLED
3. Power 9vpowersocket
4. USB5vCharger
5. AUXin
6. BuiltinMicforHandsfree speaking
7. NFC-Nearfield communication
8. BassDown
9. BassUp



10. Shortpress–Volumedown
11. Press&hold–trackback
12. Shortpress–play/pause
13. Incomingcall–shortpress to answer/short ; presstocancel phonecall
14. Short press–Volumeup
15. Press&hold–trackforward
16. PairBluetoothMode
17. AUXmode

3 Key Features

- ◆ BLUETOOTH WIRELESS AUDIO - Play your music wirelessly with built in Bluetooth systems using the included Aux cable.
- ◆ ICONIC CHARACTERS - Upon pairing your character will utter the iconic phrase 'I have a job to do' .
- ◆ NFC - Easy pairing , Just hold your phone up to the speaker and it pairs with NFC.
- ◆ AUX - Hook up your speakers to your PC or external audio.
- ◆ TWS- Pair two ACW speakers with bluetooth device to make Truewireless stereo system.
- ◆ HANDS FREE - Automatic call muting when a call comes in your music automatically mutes.
- ◆ THE MASK - The Mask light will turn on whilst paired.
- ◆ USB - Charge your phone or Tablet whilst listening to your music.
- ◆ PORTED SUBWOOFER - creates awesome depth of sound.

4 GET STARTED

CONTROLS AND LIGHTING

MAINS POWER

Plug in mains adapter (3) – Only use the correct plug adapter clip for relevant country plug socket. Turn power switch at rear to “on” (1) Power light will glow green/orange/red(2).It will turn to a fixed green light when fully charged.

Speaker will give a soft beep to confirm power on. Mask will light up and pressing& holding the two button of B+ and B- at the same time can turn on/off the mask light.

BATTERY POWER

Turn power switch at rear to “on” (1) Power light indicator (2) will glow green when power is over 70%, orange light when power is between 20%-70% and flash red if power is less than 20%.

AUX

Aux cable (5) connect 3.5mm jack plug to your Smartphone, Tablet, PC, TV, Laptop or Games station.

TOUCH BUTTONS

All buttons on the front panel are soft touch – no need to press down. Each time a button is touched the side LED lights will flash white light. Pressing and holding the button the light will keep flashing.

USB

This USB connection (4) can be used to charge any smartphone or tablet.

BASS CONTROLS

To adjust the bass sound (8,9) touch +/- the bass will increase or decrease.

VOLUME CONTROLS

To adjust volume (10,14) a short tap on the button and volume will increase or decrease.

TRACK FORWARD/BACK

To move a track forward or back (11,15) , press and hold button $|>/<|$ will move the track forward or back .

5 BLUETOOTHMODE

NOTE: The term “mobile device” refers to mobile phones/tablets/ MP3 players, laptop or any other device that has Bluetooth function.

HOW TO PAIR TO SINGLE SPEAKER

Short press the PAIR button (16) to go into the single Bluetooth Speaker mode, the side lights will “Blink” on and off white. The speaker is now in pairing mode.

When pairing with a mobile device the speaker will play the pairing sound “I have a job to do” . The Mask lights will “blink” until the pairing sound ends.

Once a connection is made the flashing white side LED light will turn to a fixed white LED.

When the speaker is powered on it will connect automatically with the last mobile device it was paired to.

HOW TO UN-PAIR FROM THE SPEAKER

If the speaker is already paired with a mobile device, short press the PAIR button to disconnect.

The fixed white side LED light will turn to a flashing white LED.

HOWTOCONNECTTOWSPEAKERS(DUALMODE)

For two new speakers which have never paired before: power on both speakers, then press & hold the MODE button of each speaker, the speakers will “beep” and go into the Stereo

Bluetooth Speaker mode.

The side LED lights of each speaker ’“blink” yellow and white alternately. When both lights flash white it means two speakers paired. If they paired successfully with mobile device, the side LED lights of each speaker will turn to a fixed white LED.

Press & hold the PAIR button can disconnect the Dual Bluetooth Speakers mode.

When the speakers are powered on they will connect automatically with the last mobile device they were paired to. If the last paired mobile device is not in the effective range or not open the Bluetooth, the speakers will automatically enter into pairing mode.

THEBUTTONSFUNCTIONSUNDERTHE DUALBLUETOOTH SPEAKER MODE: Only the speaker which is under touch control will have the light effect.

Short press any button, the side lights will flash once.

Press & hold and the side lights will keep flashing .

Each speakers will have the function effect when touching the button of V+ / V- / PLAY.

Only the speaker which is under touch control can react the B+/B- function.

6 TELEPHONE ANSWERING

Single Bluetooth Speaker mode: Incoming call - the microphone LED will turn orange and mask will “blink” until the call is canceled or the conversation is ended.

Dual Bluetooth Speaker mode: only the Main speaker can answer/cancel or redial. Only the Main speaker can communicate. Only the Main speaker has microphone light effect and mask light effect.

AUX MODE: if the speaker is paired with a mobile phone - the side LED lights will turn yellow and mask will “blink” until the call is canceled or the conversation is ended.

7 HOW TO GET INTO AUX MODE

How to connect with AUX cable

(3.5mm jack plug) Single Bluetooth Speaker mode, when an AUX is plugged in, the speaker will “beep” and go into the AUX mode automatically, the side lights will turn to be fixed yellow LED.

Dual Bluetooth Speaker mode, when the audio cable is plugged into Main speaker, the Main speaker will “beep” and the 2 speakers will go into AUX mode. The side lights of Main speaker will turn to a fixed yellow LED, the side lights of the Auxiliary speaker will keep the white LED.

To toggle between AUX mode and single Bluetooth speaker mode, short press the MODE button.

THE BUTTONS FUNCTIONS UNDER THE AUX MODE

VOLUME + (Short Press for 1 second)

VOLUME - (Short Press for 1 second)

BASS + (short press)

BASS - (short press)

TRACK forward and Back function not available in AUX Mode

PLAY/PAUSE function not available in AUX mode

8 SUMMARY

BATTERYPOWER

When battery power is between 70% - 100% the power light at the rear (2) will glow green.

When battery power is between 20% - 70% the power light at the rear (2) will glow orange.

When battery power is between 0% - 20% the power light at the rear (2) will glow red.

BELOW 20% POWER

The Mask lights will “blink” every 30 secs and play the “Need Assistance” sound until mains power is connected.

The speaker will be powered off automatically to protect the battery if the power reaches a very low level.

MASKLIGHTING

1. When your Speaker is powered on the Mask will keep flashing.
2. Bluetooth mode - Mask will “blink” on and off until paired.
3. When your phone rings the Mask lights “blink” on and off until the call is canceled or the conversation is ended.
4. When battery power drops below 20% the Mask will blink on and off for 3 seconds every 30 seconds until mains adapter connected.
5. When pressing & holding the button of B+ and B- at the same time the mask lights turn on/off.

SIDE LED LIGHTS ACTIONS

1. Side LED lights “blink” white when a control panel button is pressed.
2. Side LED lights “blink” white under pairing mode of Single Speaker Mode.
3. Side LED lights turn to a fixed white light when paired.
4. Side LED lights will be fixed yellow light under AUX mode.
5. Side LED lights of each speakers “blink” yellow and white alternately under pairing mode of Dual Bluetooth Speaker mode.
6. Side LED lights of each speakers turn to flashing white light when speakers paired.
7. Side LED lights turn to fixed white light when two speakers paired with mobile device .

VISIT OUR WEBSITE

acworldwide.cool and contact us if you have any questions.

9 WARRANTY

The ACW speaker product is covered by a limited warranty in respect of manufacturing defects. Other claims are not covered. The original purchaser of this product is provided with a 12 month warranty from date of purchase for all defective parts in workmanship or materials.

The warranty is voided upon:

- ◆ The appliance being modified in any way.
- ◆ The appliance being used in a commercial environment.
- ◆ The appliance not being used as instructed in the manual.
- ◆ The appliance being connected to an improper voltage or electricity source.
- ◆ The appliance being repaired by an unauthorised person.

Should you experience any difficulties with your appliance, you should firstly contact us at warranty@acworldwide.cool

The manufacturer does not accept liability for any direct or consequential damage, loss or other expenses arising from misuse or incorrect installation and operation of the appliance.

Due to ongoing product development and continual product improvement, the actual product may differ slightly from that illustrated on the packaging or in the manual instruction booklet.

If you are not satisfied with or have an issue with your speaker you must first return it to the retail outlet you purchased it from.

If it is a warranty claim then please contact us at warranty@acworldwide.cool and we can send you a warranty claim form.

To claim under this warranty please send your defective product with your warranty form and your original purchase receipt.

Any item sent back to ACWorldwide Ltd must be sent via registered post and signed for by an authorised member of staff. ACWorldwide Ltd will not be responsible for a product that arrives without correct documentation.

Products sent back without correct documentation will not be dealt with. Customers are reminded that they must package the item in an appropriate box to avoid any damage en route, ACWorldwide Ltd will not be responsible for the condition the product arrives in.

No returns will be accepted for warranty without a Warranty Card and proof of purchase. Any item returned to beat the customers expense, ACWorldwide Ltd is not responsible for the cost of postage.

All contact information can be found on our website acworldwide.cool

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.