

User Manual

Quick Start Please note that the Right Earphone is the “master device” and the Left Earphone is the “slave device”. Bluetooth pairing is controlled via the master device.

1. Remove the plastic seal and fully charge the earphones before the first use.
2. Press and hold the Multifunction Button on both earphones until you hear the “connected” voice prompt indicating TWS connected, then the right earphone will automatically enter Bluetooth pairing mode with a voice prompt saying “pairing”.
3. Turn on the Bluetooth function on your phone and search for “EB2011”, tap to connect. You will hear a voice prompt that says “second device connected”.

Control Functions:

Power On : Press and hold the Multifunction Button until the LED indicator flashes blue

Power off : Press and hold the Multifunction Button until the LED indicator becomes red, then turns off

Play / Pause : Press the Multifunction Button once

Answer/ Hang Up Phone Calls: When a call is incoming / during a phone call, press the Multifunction Button once on the right earphone

Reject Phone Calls: When a call is incoming, press the Multifunction Button twice.

Activate Voice Control: Press the Multifunction Button of the right earphone for 1 second

Note: During a phone call, sound will only come out of the right earphone. When battery is low, a voice prompt will remind you of the low battery level. Put the earphones in their corresponding docks to charge. The LED Indicator turns red once the charging contacts are aligned and charging has started, and then shuts off when fully charged.

Note:

- Make sure the battery is fully charged before putting the earphones away for storage.
- Charge the earphones at least once every 3 months when not using them for a long time.

LED Indicators

LED Indicators	Status
LED indicator flashes blue and red alternately	Pairing
LED indicator flashes blue	Paired
LED indicator of the earphones becomes red when in the charging dock	Earphones are being charged
LED indicator of the earphones turns off when in the charging dock	Earphones fully charged
LED indicator of the charging dock flashes white	Dock is being charged
LED indicator of the charging dock turns solid	Dock fully charged

Charging the Earphones



Note:

- Please note the “L” and “R” markings on the earphones, which correspond to your left and right ears respectively.
- In addition to the attached earbud tips, two extra pairs of different-sized tips are also included. Try each to find the most comfortable fit.

TWS Connection

Should the TWS connection become unstable and music is only heard from one earphone, you may need to reconnect the TWS:

1. Press and hold the Multifunction Button on both earphones until the indicators turn blue and red alternately.
2. After the earphones are connected, the indicator on the left earphone will flash blue and a “connected” prompt will be heard while the right earphone enters pairing mode with the LED indicator flashing red and blue alternately.
3. Once the right earphone and your device are successfully paired, the LED indicator will flash blue with a voice prompt saying “second device connected”

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.