



Thank you for purchasing **WIRELESS GEAR®**. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.

Package Contents

Remote Control Ring
Charging Case
Charging cable
User manual

Charging Case




USB-C charging port

Power indicator

Remote Control Ring


Next/Volume +

Button **Play/Pause Button**




**Previous/Volume-
Button**

Status LED indicator



Charging contact


Charging The Charging Case



Charging	 Flashing red (Case power indicator)
Fully charged	 Steady red (Case power indicator)
Low battery	 Flashing blue (Case power indicator)

Charging Your Remote Control Ring

Open the charging case's lid, then place the Remote Control Ring into the charging case, and close the lid to start recharging.



Charging	<ul style="list-style-type: none"> ● Steady red (Ring status indicator) ● Steady blue (Case power indicator)
Fully charged	<p>OFF (Ring status indicator)</p> <p>OFF (Case power indicator)</p>
Lower battery	 Flashing red (Ring status indicator)


Powering On/Off

Powering on

Press and hold the **Play/Pause button** for 1.5 seconds to turn the Remote Control Ring on. The ring status LED indicator will flash blue quickly.

Powering off

Remote Control Ring will power off automatically when placed back into the charging case.




To power it off manually, press and hold the **Play/Pause button** for 2 seconds. The ring status LED indicator will glow red for 1.5 seconds, then go off.

Bluetooth Connection With Your Device

Follow these steps to connect the Remote Control Ring to your device via Bluetooth.

1. Turn the Remote Control Ring on, it will default to pairing mode.
2. Turn on Bluetooth in your device's settings and search for "WG-BT-EB", then tap "WG-BT-EB" to connect.



Notes for Apple devices

1. For iPhone and iPad, make sure the iOS version is 14.8 or higher.
2. Make sure the Assistive Touch feature is turned on in your Apple device's settings. If not, go to **Settings > Accessibility > Touch > Assistive Touch** to turn it on.
 1. The Remote Control Ring will automatically pair with your last successfully connected media device the next time they are turned on.
 2. The Remote Control Ring will automatically turn off if it is not connected to a device within 5 minutes or if there is no operation for more than 15 minutes.

Controls

1. Short Video mode

Play/Pause	Press the Play/Pause button once.
Next video	Press the Next/Volume + button once.
Previous video	Press the Previous/Volume - button once.
Volume up	Press and hold the Next/Volume + button .
Volume down	Press and hold the Previous/Volume - button .
Like the Video	Quickly Press the Play/Pause button twice.
Screen off	Press and hold the Play/Pause button for 1 second.

2. Camera/Video recording mode

Take photo /Record video	Open the Camera App, select Photo mode or video mode, then press and hold the Next/Volume + button or the Previous/Volume - button .
Stop recording video	Press and hold the Next/Volume + button or the Previous/Volume - button .

3. Music mode

Play/Pause	Quickly press the Play/Pause button three times.
Next track	Quickly press the Next/Volume + button three times.
Previous track	Quickly press the Previous/Volume - button three times.
Volume up	Press and hold the Next/Volume + button .
Volume down	Press and hold the Previous/Volume - button .
Screen off	Press and hold the Play/Pause button for 1 second.

4. E-Book mode

Scroll down	Press the Next/Volume + button once.
Next page	Quickly press the Previous/Volume - button twice.
Scroll up	Press the Previous/Volume - button once.
Previous page	Quickly press the Next/Volume + button twice.
Volume up	Press and hold the Next/Volume + button .
Volume down	Press and hold the Previous/Volume - button .
Screen off	Press and hold the Play/Pause button for 1 second.

Specifications

Remote Control Ring

Charging Time: 1.5 hours

Working time: up to 5 hour

Bluetooth version: V5.4

Frequency(Hz): 2.40GHz~ 2.48 GHz

Dimension: 27.8 x 25.5 x 7 mm/ 1.1 x1.0 x 0.28 inch

Net: 0.13 oz/3.6 g

Charging Case

Power Input: 5V/1A

Battery Capacity: 200mAh

Charging Time: 1.5 hours for USB-C Port

Dimension: 42.4 x 42.4 x 23.0 mm/ 1.67 x 1.67 x 0.9 inch

Net: 1.0 oz/28.6 g

Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. Never use any charger that is damaged. Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 15C and 25C (59°F and 77F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

Disclaimer

All information, design, and specifications contained in this manual were correct at the time of this publication. As the product undergoes continuous upgrades and changes, however, the final device may have slight differences. The contents of this manual are subject to change without prior notice, and WIRELESS GEAR® will not be liable for any errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual.

LIMITED WARRANTY

With receipt for proof of purchase, ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when purchased from an authorized retailer and sold in its original packaging, will be free from defective workmanship and materials for one year from the date of purchase (90-days for batteries) and agrees that it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts and/or labor for the time period described.

This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor at any product the exterior of which has been damaged or defaced which design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases & Accessories, Inc.

The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases & Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases & Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liabilities and responsibilities of ESI Cases & Accessories, Inc. be liable or in any way responsible, for any incidental or consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

This warranty does not cover cables that have become frayed, cracked, or broken from use. The user should immediately replace this, or any, charge cable that has become frayed, cracked, or broken, as it may constitute a serious safety risk, including electrocution, if it is continued to be used.

Send product with \$11.95 shipping & handling fee to:


ESI Cases & Accessories

One Gateway Center, Suite 2600 Newark, NJ 07102

TechSupport@ESICellular.com



BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle battery according to local, state and national regulations.



WIRELESS GEAR®



**REMOTE CONTROL
SOCIAL MEDIA RING**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tested to comply with FCC standard. FOR HOME OR OFFICE USE.

Warning:


This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter..

Thank you for purchasing **WIRELESS GEAR®**. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.


Package Contents

- Remote Control Ring
- Charging Case
- Charging cable
- User manual

Charging Case



Power indicator




USB-C charging port

Remote Control Ring


Next/Volume +

Button Play/Pause Button



Status LED indicator

Previous/Volume-
Button



Charging contact