

(Fold Inward) — — — — — 

(Back Cover)

(Front Cover)

Before You Begin...

Customer Support
For any questions or problems with your product, please visit our website at customersupport123.com

Caution
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- **Do not disassemble, modify, or repair the device**.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- **Do not submerge in water**.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- Charging Case
- x2 Wireless Earbuds
- Charging Cable
- User Manual

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-Ion Battery Inside
This product is fitted with a Li-Ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label
Definitions

-  Direct current symbol.
-  This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.
-  This symbol signifies and denotes that this equipment has battery charging which complies with California CEC and energy efficiency.
-  This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

Warranty Information

90-Day Limited Warranty
Territory: United States

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com and select "Support".
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service does not cover:

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY.

DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMERS RECOVER AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANY ONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China
v1.11-2024

Brookstone®

Instruction Manual

KR810

FCC ID : 2AML6KR810

Before You Begin...

Please Note:

- Do not abuse this product, and do not squeeze it between heavy objects.
- Keep this product away from high frequency transmitter equipment as it could affect the signal reception, resulting in breakup, distortion, or disconnection.
- If for any reason you move out of range of the device you are listening to audio from while using the earbuds, the earbuds will disconnect and go into standby mode, but will power down after 3 minutes of no wireless signal to save battery life. You may need to re-pair the earbuds when they are back within the wireless range of the audio source.

Technical Specifications

- Bluetooth Version: V5.4
- Charging Time: Up to 1.5 hours
- Charging Interface: Type-C
- Talk/Music Time: Up to 12 hours
- * Applicable at 50% of maximum volume. Results will be lower when volume is higher.
- Transmission Range: Up to 33 ft

Location of Controls

Operation:

1. Please place the earbuds into the charging case.
2. Connect the included charging cable to a USB power source, and the bottom of the charging case.
3. You will see a blinking red light indicating that the unit is charging.
4. The earbuds will indicate that they are charging by glowing red.
5. When the earbuds are finished charging, their indicator lights will shut off, and when the case is fully charged, its indicator light will stay lit, but stop blinking.
6. You should disconnect the case from the power source when charging is complete. When you disconnect the charged case, an indicator will glow blue, and then shut off.

Touch Control

- 1 Tap: Play/Pause, Answer/End Calls
- 2 Taps: Left - previous track, Right - next track
- 3 Taps: Left - Volume Down, Right - Volume Up
- 4 Taps: Redial the last calling
- Long Press the Control Surface 1-2 seconds: Reject incoming call, Enable AI Voice Assistant
- Long Press 3 seconds: Power ON/OFF

Pairing

1. Once the case indicator light shuts off to indicate that it is fully charged, open the cover of the charging case and remove the earbuds.
2. The indicator lights on both earbuds will initially flash as they search for each other. One earbud flashing blue for several seconds means paired to each other, and are ready to pair to your device.
3. Once they are ready to pair, go to the Bluetooth settings on your device and look for "BLTWSB" in the list of new Bluetooth connections, and tap to pair it.
4. You can now listen to music or make a call.
5. Once you have successfully paired your earbuds to your device as described above, the earbuds will pair automatically every time they are removed from the case in proximity of the paired device with Bluetooth activated. If you encounter any issues, you can always unpair them from your device's Bluetooth settings and redo the pairing process.

Getting Started

Phone Calls
When connected to a device capable of making and receiving phone calls, you can single tap either earbud to answer or end a call.

Listening to Music
When the earbuds are turned on and connected to your Bluetooth device, you can open a music player or other audio source and listen. For a full list of controls, see the Touch Control section.

Using AI Voice Assistants
On either earbud, long press the control surface 1-2 seconds to activate your device's AI Voice Assistant. The AI Assistant on your device must already be activated prior to using it with these earbuds.

Charging

1. Replace the earbuds in the charging case.
2. Reconnect the Type-C charging cable to the USB power source (If it was disconnected) and to the back of the charging case.
3. See the Getting Started section for more information on charging.

Powering OFF
The earbuds will automatically power off when placed in the charging case, but you can manually shut them off by long pressing one earbud's control surface for 3 seconds.