


# KC208

Product Operating Instructions Documentation




# Contents

1. INTERFACE .....	3
2. LED STATUS DESCRIPTION .....	3
3. REPLACEMENT OF BATTERIES.....	3

# Product Specification


## 1. Interface

No.	Name	Instructions
A	Button A	Button for locking pattern
B	Button B	Button for unlock pattern
C	Button C	Horn Pattern Button
D	Button D	Pushbutton for electric pattern
E	LED	Indicate the Device working status



## 2. LED status description


Event	LED status
Push button	Lights up when the button is pressed
Pairing	Always on when no button is pressed
Connection successful	Rapid blinking 3 times
In Setting Mode	Slow blink
Setting successful	Slow blinking 2 times




## 3. Replacement of batteries

When you need to replace the battery, follow these steps.


- Find a small notch on the back of the unit near the lifting ring and pry open the back case with a small one-piece screwdriver.



- Remove the old batteries and install new batteries. (Note: Only Lithium batteries of CR2032 size can be used)



- Put it back on the back cover, taking care that the battery faces down and the buttons face up. Then close back into the housing.



- If it doesn't fit well, check if the buttons are upside down.

