




802.11a/20MHz/6M/7115MHz/Ch233 (OBW)




802.11a/20MHz/6M/7115MHz/Ch233 (EBW)




802.11ax/20MHz/MCS0/5955MHz/Ch1 (OBW)




802.11ax/20MHz/MCS0/5955MHz/Ch1 (EBW)




802.11ax/20MHz/MCS0/6195MHz/Ch49 (OBW)




802.11ax/20MHz/MCS0/6195MHz/Ch49 (EBW)




802.11ax/20MHz/MCS0/6415MHz/Ch93 (OBW)




802.11ax/20MHz/MCS0/6415MHz/Ch93 (EBW)




802.11ax/20MHz/MCS0/6435MHz/Ch97 (OBW)




802.11ax/20MHz/MCS0/6435MHz/Ch97 (EBW)




802.11ax/20MHz/MCS0/6475MHz/Ch105 (OBW)




802.11ax/20MHz/MCS0/6475MHz/Ch105 (EBW)




802.11ax/20MHz/MCS0/6515MHz/Ch113 (OBW)




802.11ax/20MHz/MCS0/6515MHz/Ch113 (EBW)




802.11ax/20MHz/MCS0/6535MHz/Ch117 (OBW)




802.11ax/20MHz/MCS0/6535MHz/Ch117 (EBW)




802.11ax/20MHz/MCS0/6695MHz/Ch149 (OBW)




802.11ax/20MHz/MCS0/6695MHz/Ch149 (EBW)




802.11ax/20MHz/MCS0/6855MHz/Ch181 (OBW)




802.11ax/20MHz/MCS0/6855MHz/Ch181 (EBW)




802.11ax/20MHz/MCS0/6875MHz/Ch185 (OBW)




802.11ax/20MHz/MCS0/6875MHz/Ch185 (EBW)




802.11ax/20MHz/MCS0/6895MHz/Ch189 (OBW)




802.11ax/20MHz/MCS0/6895MHz/Ch189 (EBW)




802.11ax/20MHz/MCS0/7015MHz/Ch213 (OBW)




802.11ax/20MHz/MCS0/7015MHz/Ch213 (EBW)




802.11ax/20MHz/MCS0/7115MHz/Ch233 (OBW)




802.11ax/20MHz/MCS0/7115MHz/Ch233 (EBW)




802.11ax/40MHz/MCS0/5965MHz/Ch3 (OBW)




802.11ax/40MHz/MCS0/5965MHz/Ch3 (EBW)




802.11ax/40MHz/MCS0/6205MHz/Ch51 (OBW)




802.11ax/40MHz/MCS0/6205MHz/Ch51 (EBW)




802.11ax/40MHz/MCS0/6405MHz/Ch91 (OBW)




802.11ax/40MHz/MCS0/6405MHz/Ch91 (EBW)




802.11ax/40MHz/MCS0/6445MHz/Ch99 (OBW)




802.11ax/40MHz/MCS0/6445MHz/Ch99 (EBW)




802.11ax/40MHz/MCS0/6485MHz/Ch107 (OBW)




802.11ax/40MHz/MCS0/6485MHz/Ch107 (EBW)




802.11ax/40MHz/MCS0/6525MHz/Ch115 (OBW)



802.11ax/40MHz/MCS0/6525MHz/Ch115 (EBW)



802.11ax/40MHz/MCS0/6565MHz/Ch123 (OBW)



802.11ax/40MHz/MCS0/6565MHz/Ch123 (EBW)

