



Internal Photographs

EUT - Open View




EUT – PCB View


Antenna Location




EUT – PCB View




EUT – PCB View




EUT – PCB View




EUT – PCB View




EUT – PCB View



EUT – PCB View



EUT – PCB View



EUT – Speaker View

