

BTS0019




Bluetooth Speaker

Contents

- BTS0019
Bluetooth® Speaker
- Micro USB to USB cable
- Instruction Booklet
- Carry pouch

Overview

1. Speaker
2. Micro USB Port
3. Hole for strap
4. LED Indicator
5. Microphone
6. Power Button/
Call answering/
Image capture button



Interpretation of the LED Indicators

	Indicator	Status
	⚡ Red	Charging
	⚡ Green	Fully charged
AUX/BT	Flashing Blue	Pairing Mode
AUX/BT	Blue	Connected

How to Charge Your Juice® Marshmallow

1. Connect the micro USB connector from the cable to the BTS0019 .

2. Plug the USB connector to a USB compatible wall charger (ideally with 0.5A current output/DC 5V, 300mA).
3. When the BTS0019 is fully charged, disconnect the USB Cable.

Note: A full charge takes approximately 2-3 hours required. The charge will last up to 4 hours when connected wirelessly.

Play audio from a Bluetooth® device

1. Switch the Bluetooth® Speaker on by pressing and holding the power button for 3 seconds. The speaker is discoverable and ready for pairing. The LED indicator flashes blue.
2. On your Bluetooth® device, turn on Bluetooth® and scan for devices in its Bluetooth® menu.
3. When the 'BTS0019' appears on the device list of your Bluetooth® device, select 'BTS0019'. After pairing the LED will change to a constant blue light. The speaker is now ready to play music .
4. Press the power button to start playing music.
5. A short press of the power button will also increase the volume of the music playing

Example: iPad / iPhone / iPod Touch
Press Settings > Bluetooth® > Bluetooth® ON > BTS0019

Using the call function

When receiving a call simply press the power button once to accept the call or accept the call in the normal way using your mobile phone. The call will then come through your BTS0019 .

Using the camera shutter function

When taking photos using your Bluetooth® device you can use the BTS0019 to capture the image. Just press the power button once to capture the

photograph.

Note: On some Android devices you may not be able to take a photo as described above, if you encounter a problem open 'Settings' then go to 'Camera', then set the 'Volume key' to 'Settings'. If you have an IOS device if you encounter an issue just refresh the Bluetooth® connection.

Reconnecting the Bluetooth® device

Keep in mind that the BTS0019 has a 10 metre range in open field. If you move out of range or turn off the Bluetooth® feature on your Bluetooth® device, the BTS0019 will disconnect from your device. To reconnect, simply follow the instructions in the 'Play Audio from Bluetooth® Device' section.

Changing connected Bluetooth® device

1. Disable the Bluetooth® function of your Bluetooth® device.
2. The speaker can now be connected to a different Bluetooth® device.
3. Now follow the instructions in the 'Play audio from a Bluetooth® device' section.

Lets get techy

Input	3.7V
Output	3W
Charge Time	2-3 hours
Playback Time	Up to 4 hours on Bluetooth®
Operating Distance	Around 10 metres
Bluetooth Version	Bluetooth 4.2
Dimensions	76.6 x 76.1 x 60 mm
Net Weight	222.2g
Capacity	850 mAh

Troubleshooting

No connection between Bluetooth® speaker and your Bluetooth® device.

- Make sure the BTS0019 is fully charged.
- Make sure the BT mode is switched on.
- Make sure your Bluetooth® device is available and supports Bluetooth®.
- Make sure the BTS0019 is within range of your Bluetooth® device.

Audio is not coming out from the BTS0019 after Bluetooth® device successfully paired.

- Make sure the Bluetooth® device volume is set to a reasonable listening level.

Audio is coming out with abnormal noise and sound quality.

- Try to recharge up the battery of the BTS0019 .

Precautions

1. The radio waves emitted by the BTS0019 and Bluetooth® device can affect the operation of nearby electronics including medical devices.
2. Keep the unit in a cool, dry place.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.