

Antenna Kitting Information

- (1)Usage of unauthorized antennas, cables, and/or coupling devices may result in poor effect and, in severe cases, equipment damage.
- (2)a complete list of authorized antennas, cables, and/or coupling devices:
- (3)the default antenna, cable, and/or coupling device that are shipped with the booster
Log-periodic Antenna, Panel Antenna and Coaxial Cable.
- (4)The antenna is equipped with a U-shaped mounting bracket. The log-periodic antenna should be installed in a place with good outdoor signal. The panel antenna should be installed indoors and near the main device. If the amplification effect is not good after the installation is completed, the direction of the log-periodic antenna can be gradually adjusted to achieve better effect.

	Name	Model	Gain/Loss	Photo
Indoor Antenna	Panel Antenna (default)	TX.BG.2	9dbi @698-2700MHz	
	Ceiling Antenna	TX.XD.3	3dbi 698-2700MHz	
Outdoor Antenna	Log-periodic Antenna (default)	TX.DS.2	10dbi @698-2700MHz	
	Yagi Antenna	TX.BM.8.1	8dbi @698-2700MHz	
cable	Coaxial cable with N male connector (default)	X.13B1	3dbi @698-2700MHz	