

User Manual

VISION Bluetooth® HEADPHONE



Package Contents:

- 1 (One) Wireless Headphone
- 1 (One) Type-C USB Charging Cable
- 1 (One) Instruction Manual

Button Description:

- “”: ON/OFF/Pause/Play
- “+”: Short press to increase volume / long press for Next song
- “-”: Short press to decrease volume / long press for Previous song

How To Use:

- Power on:** Press the key “” 2 seconds when it is off. The blue LED light will turn on, and begin to alternate blue/red LED light. A voice will prompt “pairing”, indicating the headphones are in pairing mode.
- Pairing:** Activate the Bluetooth® function on your phone within range and select “VISION BT HEADPHONE” from the list shown. When the blue/red LED light stops flashing, it has paired successfully and you will hear “connected”. The blue LED will flash slowly when playing music.
- Play/Pause:** When it is playing, press the key “” to pause, then press the key “” again to play.
- Volume up:** Press “+” once to increase the volume.
- Volume down:** Press “-” once to decrease the volume.
- Previous song:** Hold down the “-” to play the previous song.
- Next song:** Hold down the “+” to play the next song.
- Phone Call:**
Press to answer/end a call.
Press and hold for about 1.5 seconds to reject an incoming call.
- Power off:** When the headphones are on standby or in operation, press the key “” 3 seconds to shut down the headphone (voice prompt “power off”).
- Switch LED light mode:** The RGB light will automatically turn off after 30 seconds. Triple click the button “” to switch on/off RGB LED light.

Tips:

- Low Battery:** LED light flashes red.
- To Charge:**
 1. Insert the USB connector end of the included cable (see packing list) into the USB jack on the charger or USB port on the computer. Connect another end (Type-C connector) to the headphones.
 2. The indicator light will be red while charging.
 3. When the headphones are fully charged, the indicator light will turn from red to blue. Please unplug your charger from the power source.
 4. Please use a qualified charger to recharge your headphone, If not, it may result in damage or even explosion.
 5. Repeated charging and discharging of the headphone will lead to decreased battery life over time, which is normal for rechargeable batteries.
 6. You must charge the Bluetooth® Headphone if it has not been used for more than 6 months.



Technical Specifications:

- Model Number: MU01040R
- Color Changing RGB Light
- Battery Capacity: 3.7 V / 200 mAh
- Buttons: 3 (On/Off/Play, Volume Up/Next, Volume Down/Back)
- Play Time: 3-4 hours
- Charge Time: 2-3 hours
- Frequency: 20Hz - 20kHz
- Impedance: 32 ohms
- Working Distance: 10 m
- 3.5mm auxiliary jack (cable not included)
- Operating temperature range: 0-45°C
- Type-C USB Cable Rating 1.0A Max

FAQ:

- 1) Why can't I start my Bluetooth® headphone?
Answer: Please ensure that the headphones are fully charged for your first use.
- 2) Why won't sound come out of the headphones?
Answer: Check whether the playback device and the Bluetooth® headphones are successfully established. If the audio device is not properly connected, please reconnect. Please also adjust your mobile phone or Bluetooth® headphone volume to a suitable volume level.
- 3) Why can't I find this headphone in my Bluetooth® options?
Answer: Make sure the Bluetooth® is in “visible mode”. If no pairing occurs, the Bluetooth® function will automatically shut off. Please reopen Bluetooth® to “visible mode”. If there is a program error, please reboot your phone, and if a program error is caused by your Bluetooth® headphone, please restart the headphone.

FCC statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

⚠️ WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the Headphone.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the Headphone charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the Headphone.
- Do not drop, place heavy weight or allow heavy impact to the Headphone.
- PCB of battery should not be crushed and twisted.
- Battery body should not be Bended.
- Do not disassemble and Do not dispose of in fire.
- Do not use the product while driving or crossing the road.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AMPLBH1045

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

Keep All Relevant Information For Future Reference



⚠️ WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

⚠️ WARNING:

This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

⚠️ CAUTION:

FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.