

Find thousands more
great ideas online

Brookstone®

321964
©Brookstone 2017



Brookstone®

Wireless Surround
Sound Earphones

WITH REVERSE SOUND TECHNOLOGY



321964_Wireless Surround Sound Earphones
Size: 101mm W x 114 mm H_Output:100%_Prints:1/1,Blk

TABLE OF CONTENTS

| | |
|---------------------------------------|----|
| FCC Information..... | 1 |
| Caution | 3 |
| Lithium-Polymer Battery Warning | 4 |
| Location of Parts and Controls | 5 |
| Charging the Battery..... | 6 |
| Pairing with Bluetooth®..... | 7 |
| Operation | 8 |
| LED Indicator..... | 10 |
| Care and Maintenance..... | 10 |
| Specifications | 11 |
| Warranty..... | 12 |

This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by services performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

ONE (1) YEAR LIMITED WARRANTY

warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by us, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes our property. When a store credit is given, the original product must be returned to our company.

Obtaining Service: To obtain warranty service, call Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products.

FCC INFORMATION

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: To comply with FCC's RF radiation exposure limits for general population/uncontrolled exposure, and must not be collocated or operating in conjunction with any other antenna or transmitter.

FCC ID: 2AMRE-CBTRS065

SPECIFICATIONS

| | |
|----------------------------|--|
| Bluetooth® Version Support | V4.1 |
| Bluetooth® Profile Support | HSP, HFP, A2DP, AVRCP |
| Battery | Lithium Polymer |
| Battery Capacity | 90 mAh |
| Battery Life | Up to 5 hours |
| Charging Time | Approx. 1.5 hours |
| IPX Rating | IPX4 |
| Dimensions | Approx. 24.80 x 2.44 x 0.71 in. (63 x 6 x 1.8 cm) |
| Weight | Approx. 0.6 oz (17 grams) |

LED INDICATOR

The color displayed by the LED Indicator reflects the current operation and status.

| | | |
|--------------|------------------------|----------------------|
| Blue | Flash once | Power on |
| | Flash every 10 seconds | Connected |
| | Solid | Fully charged |
| Red | Flash once | Power off |
| | Solid | Charging in progress |
| | Flash 3 times | Low battery |
| Red and Blue | Alternating | In pairing mode |

CARE AND MAINTENANCE

Clean the earphones with a soft cloth or damp chamois leather. Never use solvents.

⚠ CAUTION

- Use of earphones diminishes your ability to hear background noise. For your safety and the safety of others, do not use while driving, cycling, or in any situation where reduced ability to hear your surroundings may be hazardous.
- Reverse sound technology directs sound waves away from your ear, then bounces them back into the ear canal. This helps to protect your eardrums from excessive volume levels, but damage can still occur if the volume is sufficiently high.
- Do not drop, crush, bend or apply excessive force to the device.
- Do not expose the device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storage in damp, humid or wet locations.
- The unit can only be opened by qualified personnel.

LITHIUM-POLYMER BATTERY WARNING

This device contains a rechargeable Lithium-Polymer battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

Use only the supplied cable to recharge the battery. Improper charging may damage the battery and the device.

Do not attempt to open the rechargeable battery or battery pack. There are no serviceable parts inside.

Keep the battery out of reach of children. If swallowed, consult a physician immediately.

Do not dispose of battery in a fire as it may explode. The battery may also explode if damaged. (BC)

| Function | Operation |
|----------------------|---|
| Next Track | Long press Volume + |
| Previous Track | Long press Volume - |
| PHONE OPTIONS | |
| Answer a call | When there is an incoming call, short press MFB once |
| Enable mute | While on a call, double-click MFB |
| Disable mute | While muted, double-click MFB |
| End a call | While on a call, short press MFB once |
| Reject a call | When there is an incoming call, press and hold MFB for 1 second |
| Last Number Redial | Double-click MFB |

OPERATION


After pairing with your device, you can listen to music or answer phone calls using your Wireless Surround Sound Earphones whenever you are connected to your device through Bluetooth®.

To use, place one of the 3 provided eartip pairs onto the earphones. Place the earphone in your outer ear. Earphones are marked with R (right) and L (left). The curved stabilizer fin fits in the fold of your ear, holding the earphone in place.

Power on and enjoy your music and phone calls, as described in the following table. Operations are confirmed by the LED Indicator and by voice validation.

| Function | Operation |
|----------------------|---|
| Power on | Press and hold MFB for 3 seconds. The LED Indicator will flash blue once. |
| Power off | Press and hold MFB for 3 seconds. The LED Indicator will flash red once. |
| MUSIC OPTIONS | |
| Play/Pause | Press MFB |
| Volume Up | Short press Volume + |
| Volume Down | Short press Volume - |

LOCATION OF PARTS AND CONTROLS



CHARGING THE BATTERY

Charge the battery before first use. A full charge takes approximately 1.5 hours. After charging, the device can be used without the power connection. When the battery is low, the LED indicator flashes red three times periodically, and a low battery warning repeats every 5 seconds.

If the device is not used for an extended period of time, the battery may require recharging.

To charge the battery:

1. Plug the USB connector into a USB port on an active device.
2. Plug the Micro USB end of the USB connector into the Micro USB port on the earphones. The LED light turns red during charging. The light turns blue when the earphones are fully charged.

PAIRING WITH BLUETOOTH®

To pair for first-time use:

1. Prepare your device (e.g., smartphone) to pair using Bluetooth®, making sure that the device is within 33 feet of the earphones. Refer to your device's owner's manual for information on using the Bluetooth® function.
2. Press and hold the earphone's Multi-Function Button (MFB) for about 5 seconds, until the LED alternates between red and blue, indicating that the earphones are in pairing mode.
3. On your device, search the list of available devices and select Reverse Sound. Note that it may take a few seconds for the earphones to be listed as an available device. Depending on your device, you may have to tap SCAN to update the device list. Consult your device's owner's manual.
4. If prompted, type the password or PIN 0000.

A message will display on your device confirming that your device is now paired/connected and the earphone's LED will flash blue every 10 seconds, indicating that the device is paired.

The devices will remain paired, even after being turned off. When you next power on the earphones, they will search for previously paired devices. To cancel pairing, consult your device's owner's manual.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.