

## User manual

### TWS earphone with charging base



### Function introduction

1. The product is different with tradition wireless earphone, it make the left earbud and right earbud real connection, it is real wireless no need to worry the wire any more. It is integrated earphone, control button and microphone. User can use the multifunction button to play the music and answer the phone.
2. The two earbuds could be used independently. You could use the multifunctional button to play the music and answer the phone.
3. The TWS earbuds has voice prompt, the incoming voice call number function.

One button function: answer the phone, hang up the phone, reject the phone, pair with two devices, pause, previous song, next song.



#### 1. Double earbuds mode:

- 1.1 First time use: when the tws earbuds is power off, long press the left earbud and right earbud for 7 seconds into pairing mode (red light & blue light flash alternatively). Taking the two earbuds get close to each other, the earbuds will be paired successfully with prompt voice after several seconds (the main earbud blue light flash, the duputy earbud not flash). Searching the “KD-02” on the device and pairing with the device.
- 1.2 You can wear the two earbuds randomly, only one earbud produce voice when call communication (the first pairing earbud).
- 1.3 Either earbud is power off, the other earbud will be power off automatically.

#### 2. Single earbud mode:

- 2.1 The left earbud and right earbud could be used independently. You could just power on with either earbud when connection.
- 2.2 Long press one earbud with the multifunction button for 7 seconds (red light & blue light flash alternatively). Searching KD-02 on the device and pairing with the device.

Note: The earbuds is with one multifunction button operation, it can not control the volume by the earbuds, you need to control the volume on device.

### 3. Low battery warning:

Either earbud is with low battery, the earbuds will be voice prompt with low battery warning. It means the earbud is with low battery, the user need to charge the earbud on time.

#### Power on/ off function:

Power on/off	Status	Operation	Function
One multifunction button	Power off	Long press 4 seconds	Power on
	Power off	Long press 4 seconds than release	The earbud will be repaired with the other earbud, then will be repaired with mobile
	Power off	Long press 7 seconds	The left earbud and right earbud is on pairing mode
	Pairing	Long press 3 seconds	Power off

#### The multifunction button function:

1. Pairing: The earbud will be repaired automatically when click the multifunction button.
2. Connecting: Single click the multifunction button, Pause/Play. Double click the left channel of the multifunction button, previous song. Double click the right channel of the multifunction button, next song.
3. When the call coming: Single click the multifunction button, answer the phone. Long press the multifunction button for 1 second, reject the phone.
4. When call up: Single click the multifunction button, cancel the calling.
5. When on the phone: Single click the multifunction button, hang up the phone.

#### The earbuds operation process:



Push the cover with the direction of the arrow and up exertion at the same time, then you can open the cover.



You can put the earbuds into the charging base for charging. The red light is on when charging, the red light is off when the battery is full charge. You could leave the earbuds in the charging base i Push the cover with the direction of the arrow and up exertion at the same time, then you can open the cover.

#### TWS earbuds wearing:



Put the earbuds into your ear with the direction of the arrow gently, then adjust to suitable position.



Wearing successfully.

Battery replacement:



Push the cover with the direction of the arrow and push forward. Note with positive pole and negative pole.



Connect the OTG adapter to the charging port, then you could charge your mobile with charging cable.

The battery is full charged when the full indicators lights is on.

Product parameter:

Item number: EU-KD02

Bluetooth version: V4.2+EDR

Working Frequency: 2.402GHz-2.48GHz

Bluetooth range: Up to 10 meter (without obstacle)

Speaker driver size: 8mm

Sensitivity: 95dB SPL at 1kHz

Frequency response: 20Hz-20,000Hz

Earbuds battery capacity: Rechargeable 40mAh each

Charing base capacity: 1200mAh

Charging time: 1 hour

Phone time: 5 hours

Music time: 2.5 hours

#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which

can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.