Test Setup photographs (DTS)

EUT Position: X-axis



EUT Position: X-axis (Wireless Charging)




Test Setup photographs (DTS)


EUT Position: Y-axis




EUT Position: Z-axis



Test Setup Photo of Radiated Measurement (0.009 ~ 30MHz)



Test Setup Photo of Radiated Measurement (below 1000MHz)



Test Setup Photo of Radiated Measurement (Above 1GHz)

