


23362<sup>®</sup>


TRIP II

QUICK START GUIDE

## BUTTON / INTERFACE POSITION



## PACKAGING LIST




Type-C charging cable x1




User guide x1

## LIGHT INDICATORS



- Disconnected (White light flashing)
- Bluetooth pairing (Red & white light flashing)
- Device connected (White light flashing)
- Low battery (Red light flashing)
- Charging (Red light on)
- Charging complete (White light on)

## KEY FUNCTION



Tap: Play/Pause (Music) Answer(Call)  
Double tap: Ambient Normal/Noise Cancellation Off/Noise Cancelling On switch  
Triple tap: The Voice Assistant On  
Press and hold 2S: Reject/End the call

Short press increase volume  
Long press next track

Short press decrease volume  
Long press previous track

Press and Hold for 2 Seconds:  
Power On/Power Off  
Double Click: Enter Pairing Status

## TURN ON AND TURN OFF

Power on: Press and hold the power button for more than 2 seconds to power on in shutdown state, and the white indicator light flashes.

Shut down: Press and hold the power button for more than 2 seconds to shut down in power-on state, and the indicator light off.

## PAIRING

### Pair and connect for the first time

1. Press and hold the power button for 2 seconds in the shutdown state, and the voice prompt "Power on" is accompanied, the red and white lights flash alternately to enter the pairing state, and the prompts "Looking for device".
2. Open the bluetooth on the mobile phone and find "23362 TRIP II" to connect.

### Turn On To Reconnect

Press and hold the power button for 2 seconds in the power-off state, accompanied by a voice prompt of "Power on", white light flashing, the headphone will reconnect to the recently connected phone automatically.

### Re-pair

1. Press and hold the power button for more than 5 seconds to start up and enter the pairing state in the power-off state, and prompt tone, red and white light flashing alternately.
2. In the power-on state, double-click the power button to enter the pairing state, accompanied by a prompt tone, red and white lights flash alternately.

## NOISE CANCELLATION SETTING

In the power-on state, double tap the touch panel to switch Ambient Sound On/Noise Cancelling Off/Noise Cancelling On.

3. Open the Bluetooth on the mobile phone to connect.

### Disconnect and reconnect the Bluetooth

1. The headphone will not be powered off automatically when ambient on or noise cancellation on.
2. Automatically powered off (In noise cancellation off): After the headphone is disconnected and no reconnected within 10 minutes, the headphone will turn off automatically.

**Notice:** The headphone will be powered off automatically within 10 minutes, if there is no device connected to it. If there is no mobile phone connection within 5 minutes when the headphone is in the pairing state, the headphone will exit the pairing state, and enter the connectable state with the white light flashes. If there is still no mobile phone connection within 5 minutes, the headphone will be powered off automatically.

### Remote disconnection and reconnection

(In noise cancellation off)

- a. The headphone is disconnected, it will reconnect automatically by returning valid connection range within 10 minutes.
- b. After 10 minutes, the headphone will have to be manually reconnected.
- c. After 20 minutes of disconnection out the valid range, the headphone will be powered off automatically.

## TOUCH FUNCTION

Tap: Play/Pause (Music) Answer(Call)  
Double tap: Ambient Sound On/Noise Cancelling Off/Noise Cancelling On switch  
Triple tap: The Voice Assistant On  
Press and hold 2S: Reject/End the call

## CHARGING

1. When the battery power is less than 10%, the red indicator light will flash with voice prompt.
2. While charging, the red indicator light is on.
3. When fully charged, the white indicator light is on.

### Notice:

- A. Charge the earphone via computer or certified charger (output 5V/700mA and above), the earphone will be fully charged in 3 hours.

- B. If the earphone is automatically turned off due to insufficient power, charge the earphone on time. If the earphone is not charged for a long time, the battery life may be affected.

## VOICE PROMPTS

1. Power on: "Power on"
2. Pairing successful: "Audio connected"
3. Low battery: "Battery low"(<10%)
4. Bluetooth pairing: "Looking for device"
5. Connection disconnected: "Audio disconnected"
6. Power off: "Power off"

7. Maximum volume: "Beep Beep"

8. Incoming call: "Beep Beep Beep"

9. Hanging up: "Beep"

## CALL FUNCTION

1. Tap the touch panel to answer the call.
2. Press and hold the touch panel for 2 seconds to reject the call.

## WHEN THE CALLS ACTIVE

1. Press and hold the touch panel for 2 seconds to hang up the phone.
2. Press "Volume+/-" and "Volume-/-" to adjust the call volume.

## CALL SWITCH

1. Tap the panel to put the current call on hold and connect with the incoming call.

2. Long press the touch panel to continue the current call and reject the new call.

3. While holding the call, tap the touch panel to hang up the current call.

**Notice:** Some of the mobile phone brands and models may differ in operation. For queries contact seller for support.

## LISTEN TO MUSIC

### To play

Tap the panel to play music.

### To pause

1. Tap the panel to pause music.
2. Short press the "Volume+" button to turn up the volume.
3. Short press the "Volume -" button to turn down the volume.
4. Long press the "Volume + " button to play the next song.
5. Long press the "Volume -" button to play the previous song.

**Music playback will automatically pause if there is an incoming call.**

Press the touch panel to answer the call, and long press the touch panel to hang up the call and continue playing music. **Notice:** Keep the headphone and the phone within the valid range, preferably without obstacles. Otherwise the call and music playback quality may be affected or may disconnect.

## REGULATORY INFORMATION

Before using and operating the device, read and follow the precautions below to ensure that the equipment performs optimally and avoids dangerous or illegal conditions.

1. Do not use this device in dusty, humid, dirty environment or places near magnetic field to avoid malfunction of the internal circuit of the device.
2. When you listen to music or calls with earbuds, it is recommended to use the minimum volume to avoid hearing damage. Prolonged exposure to high volume

might result in permanent hearing damage.

3. Exposure to high volume while driving may distract attention and cause an accident.
4. Do not pack, seal or cover the equipment with towels and other articles, do not use the equipment in closed environment such as boxes and cases.
5. Keep the device away from heat sources or bare fire like heaters, microwave ovens, stoves, water heaters, candles or any place with high temperature conditions.
6. Do not use an external heating appliance such as a hair dryer or microwave to dry the device.
7. Do not subject the equipment and its accessories to strong impact or vibration to avoid damaging the equipment and its accessories, resulting in battery explosion or equipment failure.
8. Wipe the device with a clean, dry, soft cloth. Do Not use the device before cleaning and maintenance.
9. Please use the device in 5°C~35°C, and deposit the device and its accessories in 5°C~35°C. When the environmental temperature is too high or too low, it may cause device to stop working. When the temperature is lower than 5°C, the performance of the battery will be limited.
10. Keep the device and its accessories in a ventilated and cool environment without exposing it to direct sunlight.
11. This device is not a toy and children should use this device under adult supervision. This device and its accessories may contain small parts that should keep away from children. Children may inadvertently damage the device and its accessories, or swallow small parts resulting in suffocation or other hazards.
12. The device is equipped with non-removable built-in rechargeable battery. Do Not replace the battery by

yourself. The battery can only be replaced by authorized service center.

13. Do not disassemble or modify the device and accessories without permission, otherwise the device and accessories will not be covered under warranty, please contact the authorized service center when the device malfunction is detected.
14. Do not dispose this device and its accessories as ordinary household waste. Comply with the local laws and regulations dealing with this device and its accessories and support recycling.
15. In medical and health care facilities where the use of wireless devices is prohibited, comply with the regulations of such facilities and turn off the device.
16. Radio waves generated by devices may affect the normal operation of implantable medical devices or personal medical devices, such as pacemakers, cochlear implants, hearing aids, etc. If you use any of these medical devices, consult their manufacturer about the use restrictions of the device.
17. Keep the device at least 15cm away from the implanted medical device such as pacemaker, cochlear implants etc.
18. Use of unauthorized or incompatible power supplies, chargers or batteries may cause fire, explosion or other hazards.

## INFORMATIONAL NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- English:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil n'effectue pas de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**IC Radiation Exposure Statement:**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. The device can be used in portable exposure condition without restriction.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



## TRADEMARKS

1. The Bluetooth® wordmark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Grandsun Electronics Co., Ltd. is under license.

2. "23621" wordmark and logos are registered trademark of Shenzhen Grandsun Electronics Co., Ltd. Reproduction in whole or in part without written permission is prohibited. Other companies and products mentioned are trademarks of their respective owners.

Made in China.

## 23621 WARRANTY

1. The device is guaranteed for 2 months from the date of purchase. Repair and maintenance service are free during period.

2. The warranty initiation:

a. Manufacturer.

b. Beyond the Warranty period.

c. Accessories damaged due to proper use and maintenance.

d. Disassemble the device without manufacturer authority.

3. Service Information

23621 Website: www.thememberband.com