Find my Locator Find my 全球定位器 Find my 全球定位器















ABS外殼/ABS外壳

Metal snap Ring

金屬夾環/金属夹环----

when the device and the product are out of the

打开 Momax Smart 应用程序,选取设备分页,点击 您要使用的产品,手机界面会显示【播放声音】的 按钮,点击【播放声音】按钮,随即听见一段警报 声,表示产品可以正常使用。

riterrace and click on the "Anti-Lost Alarm" button.

"nable the "Alarm Notification" and choose the ration for the alarm. When the mobile device and the rict are out of range from

u alert messages and sound an alarm.

前2000年 前产品,手机界面会显示【播放声音】的 击【播放声音】按钮,随即听见一段警报



按鍵/按键

ABS蓋/ABS盖

- [Privacy & Security] - Turn on

確認裝有iOS14 5或iPadOS 14 5或以上版本,并已 Lost Mode, tap Enable.

> Find My app first 開啟【潰失模式】

宣教并研ルビー明 《清确认集有iOS14.5或iPadOS 14.5或以上版本・并已 「自用双重认证的iPhone、iPad或iPod touch。 在苹果设备上打开【蓝牙】、并且前往【设置】 6丁野片也是 前 后按下【**啟用**】

击【添加其他物品

Follow the on-screen instructions and enter a phone

Note: Please make sure to allow notifications from the

开启【丢失模式】 (孟失物品名称。在**【丢失模式】**下方,

number where you can be contacted, or if you want to enter an email address instead, tap Use email address. Then press Enable.

注:請先確定允許【查找】App的通知。

2.依照屏幕上的指示操作,输入可以与你联络的电话号码, 若要改为输入电子邮件地址,请点一下【使用电子邮件地址】。然后按下【启用】。

注:请先确定允许【查找】App的通知。

在地圖查看定位器位置

在地图查看定位器位置 打开【查找】应用程序,然后点按【物品】分享 在【物品】清单中选择您要定位的定位器。如

detected, you can see it on the map. Below its name you'll see the location and time of the update. . Open the [FindMy] app, select the [Item] tab.

2. If the base station is not within range of your device or any device on the Find My network, you can see its last known location and time. If you want to receive notifications when the tracker comes within he [Play Sound] button, and then you will hear a piece of music, indicating that the product can be *When the device and the product are out of the distance, the [Find My] app cannot connect to the product and the product cannot play sound normally. My] network, please turn on [Notify when found] under [Notifications].

> 使用的產品,手機界面會顯示【播放聲音】的按鈕·點擊【播放聲音】按鈕,隨即聽見一段音樂,表示產 《党詩備組產品超出使用距離后,【查找】應用程序 無法連接到產品并且產品無法正常播放聲音。

will display the [Play Sound] button, click

APP連接/ APP連接

ly connected with Find My App

業用MOMAX APP連接/僅用MOMAX APP連接 | 設備連接正常 / 设备连接正常

Momax app和Pinpop Dulmin 正在使用的Apple設備 MoMAX Smart App 载放PP和MOMAX APP同时连接/查找APP 和MOMAX APP同时连接 Momax app和Pinpop Dulmin 正在使用的Apple設備 素性及PP和MOMAX APP同时连接

d of time, you can send a notification to yo Apple through the Find My app device, and be able to observe the walking path as you move and in time. These features are designed to prevent people from

to track property that does not belong to you. In many countries and regions around the world, it is an offence to use these products to track someone without their consent. 防止擅自追蹤

查找】應用程序通知到您的Apple設備,并能夠觀察到隨您移動的行走路徑及時間。 2 這些功能為特章制作,旨在防止他人在你不知情的

**本產品加入了防止他人擅自追蹤的功能,不應用來追蹤他 和地區,未經他人同意使用這些產品追蹤別人屬犯罪

1.如果任何定位器或其他【查找】网络配件产品离开

Device Connection status / 設備連接/设备连接

1如果任何定位器或其他【查找】網絡配件產品離開

rotating groove of the product, and rotate the

1. Pinpop Duo Find My Locator

5. Instruction manual and warranty card

Adhesive sticker x 10pcs

Metal snap ring

Opener

**Except for the disassembly tool, any knife and

our safety is at risk, contact your local law enforcement

avoid damaging the product shell or appearance.

2 这些功能为特章制作,旨在防止他人在你不知情的 [试图追踪您,如果您感到安全受到威胁,请

和地区,未经他人同意使用这些产品追踪别人属犯罪。 REPLACE THE BATTERY

1 Take out the white triangle "white disassembling piece" that comes with the package. ate the slots on the back of the product. Take the white disassembling piece and place it the lot on the back of the product, rotate counter clockwise

旋轉槽處,用拆機片順時針旋轉后蓋,便

。 。 送附赠的三角形"**白色拆机片**" 白色拆机片放置在产品背面开槽处,逆时针旋转 滴"声,代表电池更换成功。然后将下盖放置在产 包转槽处,用拆机片顺时针旋转后盖,使其保持关

※若在未解绑前操作物理方式重置该产产品,苹果设

ound to your Apple device, in the [Find My] app, in the (Item) tab, find the product that needs to longer available in the [Item] tab.

 Long press the button for 10 seconds and hear the The device will be reset to pairing.

If you physically reset the product before unbinding, i will take longer for the Apple device to remove the

1.需要更換/解綁設備綁定產品時,在【查找】應用程 序中中、【物品】分頁,找到需要解納0產品,清 頁面至長底鄉·點擊【移除物品】、點擊【移除】 一百次點擊【移除】一確認【物品】分頁中已經沒有

2.長按按鈕10秒鐘,聽到「**嘀**」的聲音,然後在2秒 內點擊兩次按鈕並釋放,然將聽到兩個「**嘀**」的聲

econds and release, you will hear two "Di" sounds. . If you are unable to use the base station, make sure the product is ready to be set up, remove and replace the battery, place the base station close to the portable

device you want to connect to, or reset the product

NFC Scan to Read information

get basic contact information so they can return it. Here are the stens to read: Ensure that NFC is enabled on the mobile device.

接的手提設備維行產品重置,然后嘗試連接定位是 若在未解綁前操作物理方式重置該產产品,苹果设

最底部,点击【移除物品】,点击【移除】, 击【移除】,确认【物品】分页中已经没有

设备将被重置为配对状态。

After setting the device as "Lost Mode" by using Find Serial Number Lookup To locate the serial number of your Pinpop, you can tap it with a smartphone that has NFC capabilities, of

Tap on the pop-up to read the contact information. NFC 提描讀取訊 自

確保在行動設備上啟用了 NFC。

1. 确保在移动设备上启用了 NFC。

4 点击弹出视窗即可阅读联络资讯。

2. 将装置放在移动设备背面靠近 NFC 天线的位置。

3. 移动设备将自动侦测 NFC 并显示弹出视窗。

(a) 非本公司人員恣意拆解或 維修產品之任何部分:

日錯誤使用本公司產品而導致手提電話或其他電

答性,請在購買時向經銷商確認。此產品規格隨時

產品有任何損壞,本公司不會承擔任何責任

有關 MOMAX 原裝產品和您的手機或電子產品的相

1. 请勿将水或其它液体流入本产品介面内部,导致本

使用或充电期间避免长时间运行高耗能的程式

8. 請瀏覽 www.momax.net 瞭解最新產品資訊。

東用**【尋找】App,將裝置設定為"遭失模式"後**。 如果有人找到該設備,請使用 NFC 掃描它以獲取基 本聯絡資訊,以便他們可以歸還該設備。 以下是限

2. 將裝置放在行動設備背面靠近 NFC 天線的位置。 行動設備將自動偵測 NFC 並顯示彈出視窗。 點擊彈出視窗即可閱讀聯絡資訊。 原用【寻找】App,将装置设定为"**遗失模式**"后。 日果有人找到该设备,请使用 NFC 扫描它以获取基 联络资讯,以便他们可以归还该设备。 以下是阅

杏找序列号

3 保用期内,出现以下条款产品保用证自动失效

)不可抗拒章外事件或天然灾害导致产品损坏

本公司有权增删任何维修及保用条款而不作通知

6. 如因错误使用本公司产品而导致手提电话或其他电

·产品有任何损坏,本公司不会承担任何责任

7. 有关 MOMAX 原装产品和您的手机或电子产品的相

8. 请浏览 www.momax.net 了解最新产品资讯。

容性,请在购买时向经销商确认。此产品规格随时

有毒有害物质或元素

O: 表示该有害有毒物质在该部件所有均质材料中的含量均在GB/T 26572 标准

注:本产品标有"X"的原因是:现阶段没有可供选择的替代技术或部件

: 表示该有富物质至少在该部件的某一均质材料中的含量超过GB/T 26572 标准规定的则量更可

1. 此保用证如经注改,保用证自动失效

可能变更, 如不另行诵告;

) 错误的操作如:非法接驳电源,以及水、污秽物

要找到您的Pinpop的序列号,您可以用具有NFC功能的智能手机点击它,或者检查电池盖上的印刷。

Disable the Apple Find My network Open the battery cover on the back of the <Pinno

2. Remove the battery. 停用 Apple 尋找我的網絡

停用 Apple 寻找我的网络

2 取出由池。

1.下載 "MOMAX智能" APP

在 iOS 或 Android 或任何平台 HACIAGO F 上搜索 "MOMAX Smart" 應用程序。 1.下載 "MOMAX智能" APP 在 iOS 或 Android 或任何平台

上搜索 "MOMAX Smart" 應用程序。

number or email address. 主冊帳戶並使用您的手機號碼或電子郵件地址登錄。

 注册 注册帐户并使用您的手机号码或电子邮件地址登录。 Once the device is turned on the pairing broadca

of MOMAX Smart will be turned on, and it will be turned of, and it will be turned off after 10 seconds. Then the pairing broadcast of the FindMy will be turned on, and it will be turned off after 10 minutes. After the Momax pairing broadcast ends, press and hold the button for 3 seconds to hear a ringtone, and the device will reset the network pairing broadcast.

www.momax.net

-段鈴聲,設備配網廣播會進行重置.

BR11_Manual_NewSize_aw

5. Successfully connected Once the connection is completed. Please allow the permission for Momax Smart to access the location 5. 連接成功 一旦連接完成。 請允許 Momax Smart 存取位置和通 知的權限。

5. 连接成功 一旦连接完成。 请允许 Momax Smart 存取位置和通

pen the Momax Smart app, select the Device page,

connection, the app will record the location of the last connection. Click on "Navigate Now" and select the pre-set map from your mobile device. This will provide a

注置。点击"**立即导航**"并从您的移动设备中设备的地图。这将提供一条从您当前位置到丢失

From the app, navigate to the product interface and click on the "Find Your Phone" button. Enable the "Find Your Phone" feature. When you double-click the product's button within an effective connection

range, the app will sound an alarm to help you locate your phone.

hen the mobile device and the product lose

用程序配对的设备可以重置为配对状态

an 2 seconds 按10S後・2秒內雙擊 长按10S后・2秒内双击 対信息 工厂复位查找app配 対信息 ring press for 10 reactory reset to Long press for 10s, a sound, then Five-click momax Smart App

From the App, go to "Setting" to remove the Pinipop Duo.
This action will reset the corresponding product. s action will reset the corresponding product.

ou need to force a reset, long-press the button for 10 sounds. Devices paired with the Momax app can be

,听到"嘀"的声音,然后在2秒内点击按 《,您将听到两声"嘀"的声音。与 Momax 应

States/ 狀態/ 状态 | Action / 操作/ 操作 | Implementation

Button Logic Definition 按鍵邏輯定義/按键逻辑定义

当移动设备和产品彼此超出范围时,应用程式将向您 内双击产品按钮时,应用程序会发出警报, 助您找发送警报讯息并发出警报声。

ax Smart app ng broadcast

*seconds 後 2秒內五擊 工廠復位Momax app 2秒內五點 工戶當的Momax app 五擊后。 五擊后。 五擊后。 五擊后。 五擊后。 五擊后。 五擊后。 五擊后。 五擊后。

按10S后·2秒内五击 配對信息 工厂复位Momax app 长按10S, "滴"—声提示,已经配对过Momax app的设备

The login status of Apple ID only counts devices such as iPhone, iMac, iPad, MacBook, etc., that support the Find My App; Apple ID登録情况僅統計iPhone、iMac、iPad、MacBook等支持查找APP的設備:

onds, double-click My App pairing 工廠復位查找app配

Product Connection scenarios 設備連接場景/设备连接场景

MOMAX APP 默認僅支持一臺設備連接; MOMAX APP 默认仅支持一台设备连接

Response Remarks/ 备注/ 备注 響應/ 响 向

with the Momax app can be

und mode, there will also be I one press for 10S. a " Di Devices that have been paired

only connected with MOMAX Smart App
ple ID僅登錄1臺設備 僅用MOMAX APP連接僅用MOMAX APP連接 设備連接正常 / 设备连接正常
connected with both Find My App and
The device is connected pro MODEL: BR11 Battery : CR2032 和MOMAX APP同時連接/查找APP 設備連接正常 / 设备连接正常 Bluetooth version : BLF 5.2 WUMAX APPIN 性接

Iv connected with Find My App

The device is connected prop Waterproof Unity connected with normal papers by Big 世界 (1995) 1995 (1995) 1 MOMAX Smart App 宣找APP和MOMAX APP同時連接/宣找APP 和MOMAX APP同时连接/ 東接下第 和MOMAX APP同时连接/ を表する。 MOMAX app和Pinpop Duo断连:Find My和Pinpop Du MAX app和Pinpop Duo断连:Find My和Pinpop D Compatibility : Compatible with Apple device only; 兼容性 :僅兼容Apple設備; iOS 14.5 或以上 iPhone and iPod touch models with iOS 14.5 or later: 版本的 iPhone 及 iPod touch系列: iPadOS 14.5 或以上 connected. At most, only two devices will remain con 使用的Apple設備將與Pinpop Duo建立連接,其f le設備將隨機斷開連接。 最多只有兩臺設備保持i with macOS 12.5 or later o Android devices- Android 13 or later"

SPECIFICATION 產品規格 / 产品规格

> 電池 : CR2032 防水等級

iPad models with iPadOS 14.5 or later; iMac and MacBook 版本的 iPad系列; MacOS 12.5或以上版本的 iMac及 Momax Smart APP "Apple Devices - iOS 16 or later; Momax Smart APP "蘋果設備 - 需要iOS 16或更高版 本: Android設備-需要Android 13或更高版本"

1. Pinpop Duo Find my全球定位器

產品標簽貼紙 x 10pcs

5. 使用説明書及保用證

包裝內容:

3. 拆機片

4. 彈簧鉤

型號: BR11

· 45x36x9 5mr

Momax Smart APP "蘋果設備 - 需要iOS 16或更高版 本: Android設備-需要Android 13或更高版本"

型号: BR11 电池 : CR2032 蓝牙版本 : BLE 5.3

警报声

本的 iPhone 及 iPod touch系列; iPadOS 14.5 或以上版 本的 iPad系列; MacOS 12.5或以上版本的 iMac及

包装内容:

1. Pinpop Duo Find my全球定位器 产品标签贴纸 x 10pcs 3 拆机片

5. 使用说明书及保用证

4. 登山扣

兼容性 : 仅兼容Apple设备; iOS 14.5 或以上版

2. Please dispose of discarded electronic products properly according to local regulations.

while charging:

(a) it has explicitly modified or repaired in any way by

1. Do not dismantle or modify the product; Do not store the product in wet conditions: . Do not keep or use the product near heat sources 4 Do not let water or any other liquid flows into the inside

part of the product's interface. This would cause

7. Ensure good ventilation while using; In case of overheating, stop using the product. DISPOSAL OF ELECTRONIC PRODUCTS

> epairing free of charges 12 months commencing from the date of purchase at the discretion of our 2. A valid warranty card and original purchase invoice must be presented upon request of warranty service; This warranty card shall not apply to the product if:

> > acts, negligence, inflow of any liquid, or:

(b) it has been damaged through misuse, malicious

(c) losses or damages are caused by force majeure or

No alteration to this warranty card will be allowed;

. Avoid direct sunlight. Keep away from heat source; change without prior notice; Avoid high processor load in long running loops or 8. Please visit www.momax.net for latest product

recycling program. WARRANTY CONDITIONS 1. For any defect, in the judgment of our technician, 8 如出現禍熱·請停止使用 aused under normal use, we are responsible for 如何處理廢棄電子產品

persons other than technicians of this company, or;

5. The warranty terms and conditions are subject to 6. Please retain your proof of purchase for warranty Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to

change without prior notice:

. MOMAX encourages you to participate in electronics 5 避免陽光直接照射 使用或充電期間避免長時間運行高耗能的程式;

> 3. MOMAX鼓勵您積極參與電子產品回收計劃。 1. 由購買日期起12個月內,如產品有損壞或故障,經 本公司技術人員證實為在正常使用之情況下發生, 本公司將提供免費維修服務 2. 維修時必須出示本保用證及購買商號之發票正本

如果用戶不能提供,本公司有權不提供維修服務。

保用期內,出現以下條款產品保用證自動失效;

請勿將雷子產品當成家庭廢棄物丟棄

用戶可能需要支付相關維修費用

) 錯誤的操作如:非法接駁電源,以及水、污穢物 滲入產品內導致產品捐壞; 可抗拒意外事件或天然災害導致產品損壞; R用證如經塗改,保用證自動失效;

可能變更, 恕不另行诵告

請勿自行拆開或改裝本產品 請勿將本產品存放在潮濕環境中 请勿自行拆开或改装本产品 請勿將產品靠近熱源或於熱源附近充電: . 请勿将本产品存放在潮湿环境中 請勿將水或其它液體流入本產品介面內部・導致本 请勿将产品靠近热源或干热源附近充电

> 如何处理废弃电子产品 1. 请勿将电子产品当成家庭废弃物丢弃; 2. 请依当地的法例规定处理废弃的电子产品; 3. MOMAX鼓励您积极参与电子产品回收计划。

5、避免阳头古垤昭射

8. 如出现过热·请停止使用。

由购买日期起12个月内,如产品有损坏或故障,约 本公司技术人员证实为在正常使用之情况下发生。 本公司将提供免费维修服务:

) 维修时必須出示本保用证及购买商号ラ发車正木 如果用户不能提供,本公司有权不提供维修服务 1. 逆时针旋转背盖并将其滑出,打开<Pinpop Duo>背

Dun > by rotating counter clockwise of back cover.

2 取出雷池。

1. 逆時針旋轉背蓋並將其滑出,打開<Pinpop Duo>背

3.設備開啟後,會開啟Momax Smart的配對廣播,10s 後關閉,然後開啟尋找App配對廣播,10分鐘超時 關閉:Momax配對廣播結束後,長按3s按鈕,會聽到

WARRANTY/保用證/保用证

Date of Purchase/購買日期/购买日期:

iit A, 4/F., Cheung Lung Ind. Budg.,

Model/型號/型号:

Remarks/備註/备注:

香港及澳門:

ong Kong and Macau:

申邮: info@momax.net.cn

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not ause harmful interference, and (2) this device must accept any interference received, including interference that may cause

Note: This equipment has been tested and found to comply wit

he limits for a Class B digital device, pursuant to part 15 of the

Chi Kok, Kowloon, Hong Kongto Cheung Yer FCC Rules. These limits are designed to provide reasonable lotline: 852-2402 3186 E-Mail: info@moma rotection against harmful interference in a residential installation. his equipment generates uses and can radiate radio frequency nergy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

egister an account and log in using your mobile

undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to Customer Service/客戶服務中心/客户服务中心

摩米士科技(深圳)有限公司 ■東省深圳市龙崗區坂田街道崗頭社區雪崗路2016号 宇隆布吉廠房A四層 邮编: 518000 全国服务热线: 86-400-886-00

香港九龍荔枝角長義街10號昌隆大廈4樓A室 服務熱線: 852-2402 3186 電郵: info@momax.net

other trademarks are the property of their respecti

ommunications. However, there is no guarantee that interference

MAX是 MOMAX Technology Ltd 的註冊商標。 其他商標均為其各自擁有者的財產。 校所有 ©2024 MOMAX Technology Ltd。保留所有权

disassemble, heat above (manufacturer's specified temperature rating) or

not to be recharged.

incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."

INGESTION HAZARD: This product contains

DEATH or serious injury can occur if ingested

A swallowed button cell or coin battery can

KEEP new and used batteries OUT OF

Seek immediate medical attention if a battery

is suspected to be swallowed or inserted

a)The statement "Remove and immediately recycle

regulations and keep away from children. Do NoT

b) The statement "Even used batteries may cause

d) A statement indicating the compatible battery

e) A statement indicating the nominal battery voltage

) The statement "Non-rechargeable batteries are

g) The statement "Do not force discharge, recharge,

dispose of batteries in household trash or incinerate."

c) The statement "Call a local poison control center

or dispose of used batteries according to local

cause Internal Chemical Bums in as little as

a button cell or coin battery.

REACH of CHILDREN

severe injury or death."

for treatment information.

type(e.g., LR44, CR2032).

inside any part of the body.

ill not occur in a particular installation. If this equipment does ause harmful interference to radio or television reception, which encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver. -

ondition without restriction.

experienced radio/TV technician for help.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an

requirement. The device can be used in portable exposure

The device has been evaluated to meet general RF exposure