






Photo

Sample	
Front view	Rear view
	

Test position	
Limb Front Surface(0mm)	Limb Back Surface(0mm)
	
Limb Left Edge(0mm)	Limb Right Edge(0mm)
	
Limb Bottom Edge (0mm)	Limb Top Edge (0mm)



Note: The EUT requires Type-c power supply in both fixed frequency and actual use. Top Edge testing cannot be performed under the Falt, and the transmitting antenna is located on the upper left of the prototype. Therefore, it is placed under the model's left head to ensure the most conservative approach to SAR testing.