


Photographs of EUT



Antenna Location



The separation distance for antenna to edge:

Antenna	To Left Side (mm)	To Right Side (mm)	To Top Side (mm)	To Bottom Side (mm)
SDR / WLAN / BT ANT-0	44	5	22	5
SDR / WLAN / BT ANT-1	5	44	15	8


Photographs of SAR Setup



Front Face of EUT with 0.5 cm Gap



Rear Face of EUT with 0.5 cm Gap



Left Side of EUT with 0.5 cm Gap



Right Side of EUT with 0.5 cm Gap



Top Side of EUT with 0.5 cm Gap



Bottom Side of EUT with 0.5 cm Gap



Left Side of EUT with 0 cm Gap



Right Side of EUT with 0 cm Gap