







Test setup Frequency Range 9kHz-30MHz Active Loop Antenna (ECG Simulation mode)




Test setup Frequency Range 9kHz-30MHz Active Loop Antenna (ECG Simulation mode)



Test setup Frequency Range 30MHz-200MHz Biconical Antenna(ECG Simulation mode)




Test setup Frequency Range 30MHz-200MHz Biconical Antenna (ECG Simulation mode)




Test setup Frequency Range 200MHz-1GHz Log periodic Antenna(ECG Simulation mode)



Test setup Frequency Range 200MHz-1GHz Log periodic Antenna(ECG Simulation mode)



Test setup Frequency Range 1-18GHz Broadband Horn Antenna



Test setup Frequency Range 1GHz-18GHz Broadband Horn Antenna



Test setup Frequency Range 18GHz-26.5GHz Double ridged wave guide Horn Antenna




Test setup Frequency Range 18GHz-26.5GHz Double ridged wave guide Horn Antenna



Test setup Conducted Emission Test on A.C. Power Line



Test setup Conducted Emission Test on A.C. Power Line



EUT Setup charging mode (transmission mode function is not possible)



EUT Setup without charging mode (transmission mode function is possible)