






<div data-bbox="256 438 623 535">CRE-NORDIC DANISH DESIGN</div> <div data-bbox="241 711 640 800">Bluetooth Speaker with LED Light and Champagne Cooler Model: LUX 1 Operating manual Version 1.1 2019</div>	<div data-bbox="818 265 920 283">Introduction</div> <div data-bbox="818 302 1412 384">Dear Customer, Thank you for purchasing our Cre-Nordic LUX 1. This product complies with the statutory national and European requirements. To maintain this status and to ensure safe operation, you as the user must observe these operating instructions!</div> <div data-bbox="818 402 1412 449">These operating instructions are part of this product. They contain important notes on commissioning and handling. Also consider this if you pass on the product to any third party. Therefore, retain these operating instructions for reference!</div> <div data-bbox="818 465 1342 496">All company names and product names are trademarks of their respective owners. All rights reserved.</div> <div data-bbox="818 516 937 535">1.Intended use</div> <div data-bbox="818 553 1412 682">This LUX 1 is intended to be used as a lifestyle product. The product serves as a multifunctional speaker and light. Its top chamber can be used for chilling champagne or used as a planter. Any use, other than described above, can damage the product. Additionally, this is connected to dangers, such as short circuit, fire, electric shock, etc. No part of this product must be modified or converted! Read these operating instructions completely and attentively; they contain a lot of important information on setup, function and operation. Always observe the safety information!</div> <div data-bbox="818 706 940 724">2.Box contents</div> <div data-bbox="818 744 1030 826">- Bluetooth speaker and LED light - Operating Manual - USB cable - Wooden Support Stands - Silicone stands with Screws</div>	<div data-bbox="1511 265 1677 283">3.Safety information</div> <div data-bbox="1511 302 2105 384">The warranty/guarantee will expire if damage is incurred resulting from non-compliance with these operating instructions. We do not assume any liability for consequential damage! Nor do we assume any liability for damage to property or personal injury caused by improper use or failure to observe the safety information. In such cases the guarantee/warranty will expire!</div> <div data-bbox="1511 407 2105 475">The following safety information is intended not only for the protection of your health but also for the protection of the device. Please read the following items carefully: The unauthorized conversion and/or modification of the product is inadmissible for safety and approval reasons.</div> <div data-bbox="1511 498 2105 595">The product is only suitable for dry areas. Do not expose it to for long periods of time to direct sunlight, heat, cold, dampness or wetness; otherwise, it may cause damage to the product. There is danger of fire or potentially fatal electric shock. If this is the case, first power down the respective socket (e.g. switch off circuit breaker) and then pull the power adaptor from the socket. Disconnect all cables from the device. Do not operate the product anymore afterwards.</div> <div data-bbox="1511 618 2006 637">Do not place any open sources of fire, such as burning candles, on the device.</div> <div data-bbox="1511 658 2105 691">Handle the product with care. It can be damaged by impact, blows or when dropped even from a low height.</div> <div data-bbox="1511 707 2105 740">Note: The handle and wood parts are not water proofed and need to be kept dry at all times.</div> <div data-bbox="1511 762 2105 844">This product is not a toy and not suitable for children . Children cannot judge the dangers involved when handling electrical devices. Do not leave packing material unattended. It may become a dangerous toy for children. Also observe the safety and operating instructions of any other devices that you connect to the speaker.</div>	<div data-bbox="2172 265 2329 283">4.Product overview</div> <div data-bbox="2367 287 2751 837"></div> <div data-bbox="2172 598 2329 647">Keys function & Bottom A1 On/Off switch A2 USB charging port</div> <div data-bbox="2172 671 2256 704">Charging B1 USB cable</div> <div data-bbox="2172 720 2347 786">Assembly Parts C1 Wooden Support Stands C2 Silicone Support Feet C3 Screws</div> <div data-bbox="2172 802 2283 851">LED indicator D1 Charging LED D2 Mode LED</div>
<div data-bbox="157 948 541 966">5.Setup mono speaker (single-unit) connection</div> <div data-bbox="157 984 736 1104">Step 1: Before first use, turn off the Bluetooth function of any other Bluetooth devices near the speaker. Step 2: Press the On/Off key for about 3 seconds on the unit. You will hear a start-up sound and the blue LED indicator light will flash. Step 3: Short press the On/OFF key ONCE. Step 4: Now turn on your "Bluetooth" on your mobile phone and search for LUX 1 on discoverable devices in your Bluetooth menu and pair with the unit. The blue indicator light on the unit will then turn off. You can now play your favorite music.</div> <div data-bbox="157 1266 442 1284">6.Setup stereo speaker connection</div> <div data-bbox="157 1303 736 1439">Step 1: Before first use, turn off the Bluetooth function of any other Bluetooth devices near the speakers. Step 2: If you have purchased two (2) LUX 1 products and wish to pair them, press the On/Off switch for about 3 seconds on the first unit and repeat for the second unit. There will be a start-up tone and the blue LED indicator light will flash on both units.</div>	<div data-bbox="818 948 1412 1095">Step 3: Double press the On/Off button on one of the units. (This unit is now set as the LEFT channel speaker) Let the second unit automatically connect to the LEFT channel speaker. You will hear a "beep" tone once the connection between the second unit and the LEFT channel speaker is successfully made, the second unit's blue light indicator at the bottom will then turn off. (This unit is now set as the RIGHT channel speaker) The LEFT channel speaker unit's blue LED indicator will still be flashing.</div> <div data-bbox="818 1119 1412 1199">Step 4: Now turn on the "Bluetooth" on your mobile phone and search for LUX 1 in discoverable devices in your bluetooth menu and pair with the unit. The Blue light indicator on the LEFT channel speaker will then turn off. You can now play your favorite music.</div> <div data-bbox="818 1223 1004 1241">7.Pairing to new phone</div> <div data-bbox="818 1259 1412 1406">Step 1: While the product is on and connected to a device, press the On/Off key once on any of your LUX 1 products. Once the connection hassuccessfully been disconnected from the phone, a tone can be heard, and the unit's blue LED indicator will start flashing. Step 2: You can now turn on the "Bluetooth" on your mobile phone and search for LUX 1 in discoverable devices in your Bluetooth menu and pair with the unit. The blue LED indicator light on the LEFT channel speaker unit will then turn off.</div> <div data-bbox="818 1425 1237 1443">8.Changing from Stereo speaker to a Mono speaker</div> <div data-bbox="818 1461 1412 1506">Press the On/Off key TWICE on any of your LUX 1 products that are already connected. The connection between the units will now be disconnected and once successful, a tone can be heard, and the blue LED indicator can be seen flashing on both your LUX 1 products.</div>	<div data-bbox="1511 948 1601 966">9.Charging</div> <div data-bbox="1511 984 2105 1037">Remove the silicone part on the side of your LUX 1 product and insert the USB-C jack into the USB port. If you are using the product for the first time, it is recommended to leave the USB jack plugged-in for a minimum of 12 hours, in order to charge the internal battery fully.</div> <div data-bbox="1511 1061 2105 1141">General Notes: For an optimal experience, keep your mobile device within 10m to the LEFT channel speaker unit. Position your 2 units in the same room or outdoor area within 3-5m of each other, free from obstructions.</div> <div data-bbox="1511 1164 2105 1195">The performance of your LUX 1 products may vary based on device, distance and other environmental factors.</div> <div data-bbox="1511 1217 1750 1235">10.Maintenance and cleaning</div> <div data-bbox="1511 1253 2105 1319">Servicing or repair must only be carried out by a specialist or specialist workshop. The product contains no parts that require servicing by you. Therefore, never open the product (except for the procedures described in these operating instructions). A dry, soft and clean cloth is sufficient for cleaning the outside.</div> <div data-bbox="1511 1326 2105 1366">Never use any aggressive cleaning agents, alcohol or other chemical solutions that would damage the casing (discoloration).</div> <div data-bbox="1511 1388 1604 1406">11.Disposal</div> <div data-bbox="1511 1425 2105 1519">a) Product Electronic devices are recyclable waste and must not be disposed of in the household waste! At the end of its service life, dispose of the product according to the relevant statutory regulations. Remove any inserted batteries/rechargeable batteries and dispose of them separately from the product.</div>	<div data-bbox="2172 948 2795 1079">b) Batteries and Rechargeable Batteries You as the end user are required by law (Battery Ordinance) to return all used batteries/rechargeable batteries. Disposing of them in household waste is prohibited! Batteries/rechargeable batteries that contain any hazardous substances are labeled with the adjacent icon to indicate that disposal in domestic waste is forbidden. The descriptions for the respective heavy metals are: Cd=cadmium, Hg=mercury, Pb=lead (the names are indicated on the battery/rechargeable battery e.g. below the rubbish bin symbol shown on the left).</div> <div data-bbox="2172 1097 2795 1142">You may return used batteries/rechargeable batteries free of charge at the official collection points in your community, in our stores, or wherever batteries/rechargeable batteries are sold. You thus fulfill your statutory obligations and contribute to the protection of the environment.</div> <div data-bbox="2172 1179 2795 1268">FCC Warning This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.</div> <div data-bbox="2172 1286 2795 1321">Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div data-bbox="2172 1357 2795 1536">NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div>

成品尺寸：90X90MM 封面157G双铜版纸过哑胶 内页105G铜版纸 2颗骑马钉装订