



USER MANUAL

SMART WATCH

SHENZHEN YUNJI INTELLIGENT TECHNOLOGY CO.,LTD

202, Building A2, Silicon Valley Power Intelligent Terminal Industrial Park, No. 20, Dafu Industrial Zone, Kukeng Community, Guanlan Street, Longhua District, Shenzhen

Watch Introduction

For screen touch: slide down to enter the status setting bar, slide up to view the notice, slide left to enter the main function interface, and slide right to enter the split screen menu.
POWER key: wake up the screen/enter the function menu/return to the dial.
SPORT key: wake up the screen/take off the screen/press and hold to enter the sports menu/sport customization.




Charging guide

Before using the watch for the first time, it can be activated by charging. Use the equipped magnetic charging cable to connect the charging port on the back of the watch. Connect the other end of the charging line to the 5V/1A USB charging head or the computer USB interface.




App-Download

1. Download and install through Google Play Store.
2. Download and install through AppStore.
3. Download and install by scanning QR code.




Binding device

1. Binding devices with Android phones
Open the FitCloudPro application, enter the device page, click "Bind Device".
2. Click the device with Bluetooth name C26 on the search device page to bind.
3. You need to agree to the following permissions to make the watch function work normally and Bluetooth call function.



2. Binding devices with iOS mobile phones

Use iOS mobile phone to bind device
Open FitCloudPro application, enter the device page, click "Bind device".



Click the device with Bluetooth name C26 on the search device page to bind.

Open the watch Bluetooth call function and play mobile media audio function.



Audio setup


Open the watch Bluetooth call function and play mobile media audio function.



Dial setting

Dial switch: press and hold for 2s in the dial interface to switch the left and right to switch the dial.


Dial push: you can select your favorite dial in the app dial push and download it to the watch.



Sleep


Support daily light sleep and deep sleep records.

Support to view sleep history of nearly seven days.




Sport mode

The watch supports 8 built-in sports modes+100+ sports modes pushed by App.



Weather

After the watch is connected to the APP, this weather interface will display the real-time weather temperature and weather type.



FAQ

1. Why is there a reminder on QQ, WeChat and other information, but not on the bracelet?
1.1 Confirm whether the messages can be displayed normally in the mobile notification bar. The device pushes messages by reading the messages in the mobile notification bar. If there is no message in the mobile notification bar, the device can receive the push. You can find the notification message bar in the mobile phone settings, and click "Notification" -> "SMS and MMS".
- 1.2 Open the APP and enter the APP device bar - click the message reminder - open the corresponding application switch button to receive message push.
- 1.3 The Bluetooth connection between the device and the mobile phone is always maintained.

2. How can the device be unbound from the phone?

On the "Device" page of the APP, click the "Unbind" button and select OK to unbind.

iPhone:

- 2.1 Go to the "M" - "Device Information" page of APP, click the "Unbind" button.
- 2.2 Under "Settings" - "Bluetooth" - "M" device of the iPhone, select the device to be unbound, click the blue "i" sign at the back, and then click "Ignore this device". Note that when the device is unbound, it will receive a reminder notice when it is bound again, and it will still receive a reminder notice when there are reminders such as information and phone calls.

Android phone:

3. Why are Android phones easy to disconnect?
The APP must be running in the background so that Bluetooth will not automatically disconnect, but the Android mobile phone system memory management will force the APP to be killed. We need to go to the system of the power saving mode of the mobile phone system and add APP to the green background of system management so that the APP will not be forced to close.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.