

Ripple Speaker


USER MANUAL

Patent No: ZL 201430140871.4
Thank you for buying Mini Smart Speaker,
We think you'll have fun enjoying it.

What the Ripple Shower Speaker can do for you?

- You can chat with your friends on mobile or tablet PC. Can make call or answer telephone through its hands free function
- It will connect with all audio device Via Bluetooth
- Built-in 3.7V 500mAh lithium battery, can play up to 3-4 hours
- Will be your perfect partner with excellent sound anywhere you go!
- Can be used in the shower, swimming pool, on the beach, outdoor-sport
- USB sound card function, plug and play, you can enjoy PC video when charging
- Battery protection, automatic shutdown function. It will automatically shut down while not using after 15 minutes. Please charge it when the battery is low. It will automatically shut down if you continue use.

Operation instruction



How to turn on the Ripple Shower Speaker?

How to Charge the Ripple Shower Speaker?

Plug the cable into available USB port on any power

charging device or your computer. The red indicator light steady on while charging. It will be turn off after full charge.

Wireless Bluetooth connection

- (1)When you turn on the speaker, it will automatically be in Bluetooth status.
- (2)It will begin searching another Bluetooth device automatically, the speaker will say “waiting for connection”, The blue indicator light will fast flashing alternately.
- (3)Turn on the Bluetooth^{ON} your mobile phone, then search and find the device named “ Ripple ”, please click it and wait for connection. The blue indicator light will steady on after pairing success.
- (4)May be asked to enter a password for some lower Versions of Bluetooth device, please key in “0000” and confirm it

USB Sound Card

The Ripple speaker connect to computer through the USB cable, then turn it on. It can be used as audio output speaker of computer. (The computer will automatically search for drivers and then install it.)

The Ripple speaker connect to the computer through USB cable after power on. Short press (1) button can switch USB sound card and bluetooth play mode.

Note: It can not support this function if your computer version is low. Antivirus software may prevent this function.

How to Play music & Answer phone with Ripple Shower Speaker?

1. Wireless Bluetooth Connection for playing music:

When you're connected with the speaker via Bluetooth to play music, the music playing on your media device will be automatically transferred to the Ripple speaker. If you cannot hear sound, check it again and ensure the Bluetooth connection has no problem or turn up the volume.

2. To control music (play, pause, skip tracks, fast forward, rewind and adjust the volume etc.)

①. Control the repertoire of songs: Long press (4) or (5) button can pick a song

②. Short press (3) button can pause the music when playing, press again can continue play music.

③. Adjust the volume: Short press + or - button can adjust volume

④. Answer/Hang up/callback the phone call:

Short press (2) button can answer the phone call when you have a call, long press (2) button can decline a call. Continuous press (2) button twice can call back the last call.

⑤. Long press (3) button disconnect bluetooth connection, short press again reconnect.

3. Answer telephone

When Ripple is connected to your mobile phone via Bluetooth, all your calls will be transferred to it, which means you can answer the phone hands free.

When you have a call, the voice instruction will broadcast the call number and you can press the phone button to answer the call.

Notice: The music will be automatically paused during a call, then will resume when the call is ended.



System reset:

Press the Power button for 10s to reset

Support

Questions	Answer
I cannot hear anything on the speaker	1. Turn up the volume 2. Ensure the speaker is paired or connected with the audio device that's playing music
I cannot answer and end call	It depends on your mobile phone whether it supports hands free, because some older devices won't support this.
I cannot connect with speaker via wireless	Make sure your mobile phone has Bluetooth enabled and that the devices are connected. Refer to the guidance of "wireless Bluetooth connection"

If crash in the process of using	Please try to insert USB charging port with USB cable to reset, turn it on. Charging reset function.
I hear crackling	Bluetooth is a wireless radio technology, which means it is sensitive to objects between the Music bomb speaker and the connected device. The Music bomb speaker is designed to be used within 33feet (10 meters) of a connected device, with no major objects in between (walls, etc.).

How to care of your Ripple Speaker.

- Please store and use this product in a normal temperature environment.
- The product built-in lithium battery. Please don't expose this product in the rain or damp conditions.
- Please don't arbitrarily discarded or put is in fire, to avoid danger.
- Please store your Ripple Speaker with the power off.
- To avoid storage at extreme temperatures, otherwise it will shorten the battery life and affect its performance, high temperature also may lead to performance degradation.
- Please don't disassemble, repair and modify this product.

- Please quickly unplug the Charging Cable power cord if the abnormal phenomenon, to avoid accident, and please contact with our after-sales department for maintenance in time.

Specifications:

Bluetooth Range: 10 meters
Transmition Frequency: 2.4GHz
Rated Power:3W
IPX Grade: IPX5
Battery : 3.7 V 500mAh
Playing Time: about 3-4 hours
Unit Weight:200g



www.bopmen.com



4000 476 990



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.