

说明书尺寸：70 x 90mm

MINISO

USER MANUAL

使用說明書

人鱼姬系列蓝牙音箱

MODEL: A10

使用產品前請仔細閱讀本使用說明書,並請妥善保管。

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

尊敬的客戶

非常感謝您使用MINISO藍牙音箱產品,使用前請詳細閱讀本說明書,正確操作使用,更好發揮產品優越性能。MINISO藍牙音箱外觀設計時尚美麗、音質純美,多功能一體化設計,全系列擁有外觀設計專利,系統上採用行業領先電聲技術,使您在居家使用、戶外旅行、商務工作中隨時隨地享受卓越效果。為您的筆記型電腦、數碼音樂播放機等提供超值完美的音質體驗,帶給您歡樂妙音,感受健康快樂生活!

注意事項

1.請在溫度5℃~35℃範圍內使用及存放設備及配件,當環境溫度過高或過低時,可能會引起故障。

2.請將設備及其配件放置在通風、陰涼、無陽光直射的地方。

3.請勿將設備拆解、擰壓、擠壓或投入火中,以免發生爆炸。若電池出現鼓脹、漏液,請勿繼續使用。

4.在使用本設備時,請與插入的醫療設備(如起搏器等)保持至少15釐米的距離。

5.由於藍牙技術的特性,信號的強弱與具體使用環境有關,如果附近有較多無線信號干擾,或者有較強電磁波干擾,藍牙音箱接收到的信號變弱,甚至斷連。

6.如果長期不使用,請每三個月給產品充電一次,避免電池過放損壞。

7.清潔、維護設備前停止使用設備,請使用清潔、乾燥的軟布擦拭設備。

8.推薦使用品牌廠商、通過認證、輸出電壓為5V的充電器給本產品充電。請避免使用輸出電壓超過5V的快充充電器,以免過高電壓充電損壞產品!

產品參數

藍牙版本: 5.2

藍牙配對名: MINISO-A10

充電輸入: 5V 500mA

電池: 500mAh

充電接口: USB-C

音樂時間: 約4小時

充電時間: 約2小時


產品指示圖

1.開/關機鍵

2.音量+/上一曲

3.音量+/下一曲

4.暫停/播放鍵



所有配件

藍牙音箱\*1, USB-C充電線\*1, 說明書\*1

功能操作介紹

功能	
開機	按開機鍵2秒
關機	按開機鍵2秒
充電指示燈	充電時紅燈亮,充滿燈滅
藍牙連接	開啟用戶手機藍牙功能(或其他藍牙設備),並進行搜索或掃描,此時手機會搜索到附近所有的藍牙設備,點選搜索到的機器名稱:MINISO-A10成功配對連接後,機器指示燈常亮,表示配對連接成功!
音量加	短按音量加鍵,聲音增加
音量減	短按音量減鍵,聲音減小
上一曲	長按音量減鍵,上一曲
下一曲	長按音量加鍵,下一曲
暫停	短按開關鍵/暫停
TF卡接口	可插入TF卡播放卡里面的音頻文件。

TWS 模式  
1.打開兩台藍牙音箱,藍牙音箱進入自動配對狀態,此時藍色指示燈閃。  
2.双击任意一台音箱的開關機鍵,兩台音箱進入對聯狀態,听到“噠”提示音即互聯成功。(若30s內未成功,請重復1、2步驟)  
3、手機打開藍牙功能,搜索并連接音箱,連接成功後,兩台音箱可以同步播放。  
注意:藍牙音箱模式有記憶功能,再次開機會自動對聯,如果需要斷開TWS模式,再次双击開關機鍵,TWS連接即可斷開。

故障排除

1.藍牙音箱不能與手機配對  
答:請檢查音箱是否處於配對模式,以及檢查手機藍牙搜索功能是否已打開;並檢查設備上的藍牙功能表是否關閉/取消音響,按說明書將音響重新連接。

2.藍牙音箱啟動不了  
答:請檢查音箱的電量,並嘗試重新充電。

3.藍牙音箱能否更換電池  
答:不可以,音響使用不可拆卸式聚合物儲電池。

4.是否可以長時間大音量使用  
答:為提升藍牙音響使用壽命,不建議長時間大音量使用。

5.藍牙音箱與手機在10米斷開連接  
答:由於藍牙是一種無線技術,因此對耳機與已連接設備間的物體很敏感,請檢查在連接範圍內是否有金屬或其他影響連接的物件。

6.音響連接電腦或手機後,聽不到聲音  
答:請檢查電腦輸出聲道是否已設為藍牙音訊裝置以及電腦的藍牙是否支援A2DP協定,並檢查電腦/手機的音量。

7.藍牙音箱與手機連接後,可以用音響控制手機上的應用程式嗎  
答:設備應用程式的軟體設定或有所不同,各個別應用程式的功能不支援由音響操控。

產品參數

藍牙版本: 5.2

藍牙配對名: MINISO-A10

充電輸入: 5V 500mA

電池: 500mAh

充電接口: USB-C

音樂時間: 約4小時

充電時間: 約2小時


產品指示圖

1.開/關機鍵

2.音量+/上一曲

3.音量+/下一曲

4.暫停/播放鍵



所有配件

藍牙音箱\*1, USB-C充電線\*1, 說明書\*1

功能操作介紹

Function<->	->
Turn On<->	Press the Power button for 2 seconds<->
Turn Off<->	Press the Power button for 2 seconds<->
Charge indicator<->	When charging, the red light is on, and the full light is off<->
BT connector<->	Turn on the Bluetooth function of the user's mobile phone (or other Bluetooth devices), and search or scan, at this time the mobile phone will search for all nearby Bluetooth devices, click the name of the searched machine. MINISO-A10 successfully paired and connected, the machine indicator is steady on, indicating that the pairing and connection are successful!<->
volume +<->	Press the Volume plus button to increase the sound<->
volume -<->	Press the volume down button to reduce the sound<->
Previous song<->	Long press the volume down button<->
Next song<->	Press and hold the volume button and move on<->
pause<->	Short press on/pause<->
TF card<->	TF card can be inserted to play audio files on the card<->

TWS mode  
1. Turn on two Bluetooth speakers. When the Bluetooth speaker enters the automatic pairing state, the blue indicator blinks.  
2. Double-click the on/off button of any speaker. The two speakers are connected to each other. If you hear a beep, (if not, repeat steps 1 and 2.)  
3. turn on the Bluetooth function of the mobile phone, search and connect the speaker, after the connection is successful, the two speakers can play simultaneously.  
Note: The Bluetooth speaker mode has a memory function, and it will be automatically couched when it is turned on again. If you need to disconnect the TWS mode, double-click the switch button again to disconnect the TWS connection.

trouble removal

1. The Bluetooth speaker cannot be paired with the hand lattice  
A: Please check whether the speaker is in pairing mode, and check whether the mobile phone Bluetooth search function is turned on; and Check the Bluetooth menu on your device and delete/cancel the speaker, reconnecting the speaker according to the instructions.

2. The Bluetooth speaker won't start  
A: Please check the battery level of the speaker and try to recharge it.

3. Bluetooth speaker can replace the battery  
A: No, the speaker uses a non-removable polymer carp battery.

4. Whether it can be used at a high volume for a long time  
A: In order to improve the service life of Bluetooth speakers, it is not recommended to use high volume for a long time.

5. The Bluetooth speaker is disconnected from the phone at 10 meters  
A: Since Bluetooth is a wireless technology, it is very sensitive to the object asked by the headset and the connected device, please check Check for metal or other objects that affect the connection within the connection range.

6. No sound is heard after the speaker is connected to a computer or mobile phone  
A: Please check whether the computer output channel is set as a Bluetooth audio device and whether the computer's Bluetooth support A2DP protocol and check the volume of the computer/mobile phone.

7. After the Bluetooth speaker is connected to the mobile phone, can I use the speaker to control the app on the handset  
A: The software Settings of device applications may be different, so that the functions of individual applications are not supported by the speaker Control.

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.  
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.  
This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.