





EWAA MUG SPEAKER A163  User Manual	Packaging Please make sure all the following parts are inside when unboxing. -- EWA A163 Mug Speaker*1 -- Charging Cable*1 -- User Manual*1   	Button / Interface  ① Charging Port ② Control Button On/ Off: Press 3s to turn On/Off Play / Pause: Press once Next Song: Press twice Previous Song: Press three times	Connect  Step : Connect the speaker to the device 1. Turn on the speaker. 2. Enable the Wireless Connection on the your device. 3. Search and find "EWA Audio A163"	LED Indicator Guide 1. Pairing Mode: Fast flashing blue 2. Connect to a device: Steady blue 3. Playing Mode: Slow flashing blue 4.Charging:Red on 5. Fully Charged: Red off Warm reminder: Low battery: The speaker will make a “beep” sound every a few seconds. Please charge it.
--	---	---	--	--

Specifications Product Model: A163 Wireless Name: EWA Audio A163 Wireless version: 5.4 Wireless Distance: Around 10m Audio output: 5W Weight: 324g Dimensions: L73*W55*H48.5mm Charging Port: USB-C Charging Input: 5V --- 500mA Charging Time: Around 2h Battery Capacity:700mAh Playback Time: Around 4h (70% volume) Frequency: 100Hz-18kHz Protocols: HS/HF,A2DP,AVRCP,OPP

尺寸：单页： 60*65mm
材质：105g铜版纸
颜色：绿色专色号Pantone375C
扇形折