


**INCLUDES:**  
EDGE Wireless In-Ear Earphones  
Padded Protective Soft Pouch  
Micro USB Charging Cable  
Extra Ear Cushions & Ear Hooks  
Cable Clip  
User Manual & Warranty

# EDGE

Wireless In-Ear Earphones

User Manual and Warranty

## FEATURES



Functions vary depending on your phone, tablet or application.

## PRODUCT SPECIFICATIONS

Bluetooth	4.2
Bluetooth profiles	HFP, HSP, A2DP, AVRCP
Connectivity class	Bluetooth Class 2 (10 meter)
High performance driver	2 x Ø6 mm
Frequency response	20 Hz - 20 kHz
Sensitivity	99 +/- 3 dB at 1kHz
Impedance	16 Ω
Signal to noise ratio	≥ 57 dB
Charging method	Micro USB charging
Battery type	Lithium-ion polymer battery
Battery capacity	110 mAh
Play time	up to 7 hours (varies by volume level and audio content)
Recharge time	2 hours
Water proof standard	IPX-4
Dimensions	25 x 580 x 32 mm

## OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Power on the earphone	Press and hold the Power button for 3 seconds	Power On	Blue light goes on for 1 second
Standby (not connected with smartphone)	N/A	N/A	Blue light flashing twice every 1 second
Standby (connected with smartphone)	N/A	N/A	Blue light flashing once every 5 seconds
Pairing	Press and hold the Power button for 6 seconds (when earphones is off)	Pairing	Blue and red light flashing alternatively

## OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Pairing success	N/A	Your device is connected	Blue light flashing once every 5 seconds
Phone call in progress	N/A	N/A	Blue light flashing once every 3 seconds
Voice Dialing	Press the Power button for 1 second and then release	with tone	N/A
Redialling	Press the Power button twice	with tone	N/A
Incoming call	Press the Power button once	with tone	Blue light flashing quickly

## OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Refuse incoming call	Press and hold the Power button for 2 seconds	with tone	N/A
End a call	Press the Power button once	with tone	N/A
Mute the microphone during a phone call	Press "+" and "-" key simultaneously once	with tone for every 10 seconds	N/A
Play / pause	Press the Play/Pause button once	N/A	N/A
Listening music	N/A	N/A	Blue light flashing once every 5 seconds

## OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Increase volume	Press "+" button repeatedly	with maximum volume alert	N/A
Decrease volume	Press "-" button repeatedly	N/A	N/A
Previous song	Press and hold the "-" button for 1 second	N/A	N/A
Next song	Press and hold the "+" button for 1 second	N/A	N/A
Disconnect Bluetooth connection	N/A	Your device is disconnected	N/A
Battery level is low	N/A	Battery Low	Red light flashing once every 5 seconds

## OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Battery charging mode	N/A	N/A	Red light goes on constantly
Battery has been fully charged	N/A	N/A	Blue light goes on constantly
Power off the earphone	Press and hold the Power button for 3 seconds	Power Off	Red light goes on for 1 second
Reset	Press "+" and "-" button for 5 seconds when earphones is in standby mode or not connected with smartphone	with tone	N/A

## CUSTOMER SERVICE

**12** For any service or technical queries, please contact our service team on the below email.  
Email: [consumersupport@zeeva.com](mailto:consumersupport@zeeva.com)

Keep all relevant information for future reference

Imported and distributed by  
Zeeva Electronics Private Limited.  
All rights reserved

901-902, Trade World C wing  
Kamla Mill Compound,  
Senapati Bapat Marg,  
Lower Parel West,  
Mumbai-400013

1832023

## JOIN THE COMMUNITY

SIGN UP to receive  
• Special Offers!  
• Access to Events!  
• Contests!  
• News on new products launched



[www.muveacoustics.com/community](http://www.muveacoustics.com/community)



Thank you for trusting MuveAcoustics  
with delivering you excellence in sound.  
We encourage you to connect with us  
and become a part of our community!

**SCAN THE QR CODE YOU WILL FIND INSIDE.  
SHARE WITH US YOUR PRODUCT EXPERIENCE.**



**MUVEACOUSTICS®**  
SOUND THAT INSPIRES



#### Bluetooth Connection

Devices with Bluetooth 4.2 wireless technology or above, such as Bluetooth wireless technology equipped computers, smartphones, tablets and MP3 players. To use Bluetooth for your audio connection pair EDGE with your audio source (music player, smartphone, laptop, or other Bluetooth equipped device that can act as a source of music). First turn on your Bluetooth connection on your device, then press and hold the Power button for 4 seconds until you hear 'Pairing'. The EDGE is in pairing mode. The blue and red Sync LED will blink. Make sure Bluetooth is enabled on your audio source and in a few moments "MUVEACOUSTICS:EDGE" will appear on your list of possible Bluetooth connections. Press "pair" or "connect" on your device and when the connection is made you will hear "Your device is connected". You are paired. From now on, when you turn on EDGE, it will automatically search for the last Bluetooth device it was paired with.

#### Battery Level and Charging

EDGE comes with lithium-ion polymer battery. For best results, fully charge EDGE before use. It will take 2 hours to fully charged. When the battery voltage is low, red light replaces blue light with voice notification "Battery Low" every 2 minutes. EDGE will automatically shut off, after disconnected or no pairing with Bluetooth enabled device for 10 minutes or when the battery power level is very low. Please use the cable provided to recharge the earphones. Red LED light up during charging and it will turn blue once fully charged.

#### SAFETY INSTRUCTIONS

##### Warnings

- Contains small parts which may be a choking hazard. Not suitable for children under age three.
- Set a low volume setting before using the earphones.
- Long-term exposure to loud music or sounds may cause hearing damage. It is best to avoid high volume levels when using these earphones, especially for extended periods.
- Do not use these earphones when operating a motor vehicle, a bicycle, machinery or where your

inability to hear outside sounds may present a danger to you or others.

#### Cautions

- Using these earphones limits your ability to hear noises around you, regardless of listening volume. Please use caution when using these earphones.
- Do not drop, sit on, or allow the earphones to be immersed in water.



This product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.



Unsuitable for children under three years because it might, for instance, contain small parts.



To prevent possible hearing damage, do not listen at high volume levels for long periods.



The input voltage to the product is 5V 1A. In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger / adapter for charging the product. Only charge the product at ambient temperatures between 10 deg °C / 50 deg °F and 40 deg °C / 104 deg °F.

Do not heat above 70 deg °C / 158 deg °F, eg. Do not expose to sunlight or throw into fire. Switch off the product after use.

Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

#### FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.



FCC ID: 2ANVW-MA-1020

## MUVEACOUSTICS ONE-YEAR LIMITED WARRANTY

MUVEACOUSTICS EDGE earphones have been subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, MUVEACOUSTICS warrants to the original purchaser that this product will be free from defects in material and workmanship for a period of 12 months from the date of your original purchase from an authorized dealer. If a defect covered by this occurs, MUVEACOUSTICS, at its option, will repair

or replace the product purchase at no repair charge (postage charges will apply). If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to product used for any industrial, professional or commercial purposes.



MuveAcoustics



muveacoustics\_



MuveAcoustics