

EN

INSTRUCTIONS:

To play:

- Move switch on the rear of the speaker to the 'On' position.
- Enable Bluetooth® on your device.
- Select LUKSPE3 from list of available devices.
- Once connected, use your device to play music and control the volume.
- Once finished, disconnect by moving switch to 'Off'.

To charge:

- Ensure speaker is turned off;
- Connect the micro-USB cable provided;
- When charging LED indicator will glow red.
- The LED indicator will glow green once fully charged.
- Once fully charged, disconnect the speaker from power source.

WARNINGS:

- Disposal of a **battery** into fire or a hot oven, or mechanically crushing or cutting of a **battery**, that can result in an **explosion**;
- Leaving a **battery** in an extremely high temperature surrounding environment that can result in an **explosion** or the leakage of flammable liquid or gas;
- A **battery** subjected to extremely low air pressure that may result in an **explosion** or the leakage of flammable liquid or gas.
- Rating plate information is located on bottom enclosure of the apparatus.
- **Battery** shall not be exposed to excessive heat such as sunshine, fire or the like.
- No naked flame sources such as lighted candles should be placed on the apparatus.
- Attention should be drawn to the environmental aspects of **battery** disposal.
- The use of apparatus in moderate climates.
- CAUTION: Danger of **explosion** if **battery** is incorrectly replaced. Replace only with the same or equivalent type.

This is not a toy. Not suitable for children under 14. Keep item and cables out of reach of children at all times. Never charge longer than required. When charge light glows green, product is fully charged. Unplug immediately. Do not leave permanently on charge. For volume control, use phone controls. Use only the USB charging cable provided. Not for outdoor use. Dispose of with care! Correct disposal will ensure environmental protection and prevent any potentially harmful impact on people and the environment. Adhere to relevant legal requirements when disposing of this item. Do not attempt to de-construct speaker - electrical contents can be dangerous. Retain these instructions for reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.