


Quick Start

This user manual applies to all panoramic camera models


① Diagram



This is an interface example of 180 degree type, other 180 degree models similar.

USB interface: 5V external power supply


Micro SD card slot: For local storage, up to 128G



This is an interface example of 360 degree type, other 360 degree models similar.

USB interface: 5V external power supply

Micro SD card slot: For local storage, up to 128G



The power interface: **AC100~240V, 50~60Hz**

TF card slot: for storage, up to support 128G TF (SD card)

Note: the light bulb's voltage is 100V~240V, must be power-off when it is connected

② Scan to download APP

- Visit Apple APP Store or Google Play to download and install application “HDIPC360”. Launch the APP and create a new account. Alternatively you may scan the following QR Code with your smart phone which will bring you to the site:



(IOS)



(Android)

③ Camera connection

- Get the camera connected with power and wait until red light blinks.
- Connected your Android or IOS device to your Wi-Fi and enter Wi-Fi password in APP as guided (5G Wi-Fi is not available for now), turn on the phone volume and get it close to the camera. When heard beeping sound from camera, please click “next” and wait until green light blink accompany with the voice “camera ready” which means connection is done.
- Name the camera and enjoy the video.

Q&A

① Why is the camera not connected online?

- Please check you have entered the right Wi-Fi password. Change password if there is any special symbol.
- Make sure DHCP of router is enabled.

② How can I playback recorded video on Micro SD card?

Tab “clock” icon on APP and move the cursor to the exact date and time, then tab again to play the recorded video. The camera need to insert TF card to support the storage and playback of video. Insert TF card into the memory card slot when camera is powered off, then connect to power, click on the playback button, select the point of time on the blue strip to playback video files.

③ I want to share the camera with other people. How to do that?

Go to the Camera settings, find the “sharing device”, click the top right icon “+”, and enter the user's account. Then click “OK”.

Note: the shared account must be a registered account in APP. The users re-log in their own account will be able to see the shared camera.

④ What if the camera be bound by other accounts?

Use the reset pin to press reset button, after hearing the beep sound, to add the camera again.

⑤ How to make a call from camera to cellphone ?

- One key call function is only available to corresponding model with the button on front of the cameras. (Other models do not support it.)
- Press the calling button on front of cameras, you will hear a “ding dong”sound, at the same time, cellphone will indicate the same sound(voice on) and push a notification. Click in the APP you will see “You have a call request, whether to view it” Click on “Yes” you will enter the real-time video. Now, enjoy your conversation.

⑥ Why there is no response after pressing the call button?

The camera will not respond if people are watching the real-time video, in this situation, you can just talk, cellphone user can hear you. When people are not watching the real-time video, press the call button, the camera and cellphone will sound “ding dong”.

Instruction

①Indicating light

- Stable red Power is on
- Blink red Waiting for Wi-Fi password
- Stable green Waiting for connection to Internet
- Blink green Camera is working

②Working Temperature

The camera is fit for the environment between -5~40°C.
It's normal if you feel the camera a bit hot when in working condition.

③Camera reset


User will need to reset the camera when there is a requirement to:

- Change of Wi-Fi name or password.
- Change of Wi-Fi router
- Change of user to pair with the camera


④Package list

- Camera
- Power adaptor & cable
- User's manual

APP Illustration



180 degree Panoramic Video Camera Function Map



360 degree Panoramic Video Camera Function Map

Warranty terms

- We are entitled to discontinue the warranty period if product has been serviced or tampered with by unauthorized personnel.
- We reserve the right to modify the contents of the product at any time without prior notice.
- Unless otherwise specified, this warranty only covers the defect in material, design and workmanship of the hardware components of the product as originally supplied. The warranty does not cover any software, consumable items, or accessories even if packaged or sold together with the product.

Note

- Please be sure the power is off when remove/insert micro SD card.
- Keep the product out of children's reach.
- Keep it away from direct sunlight, strong light or dust
- The camera is suitable for indoor environment; please keep it away from humidity such as around the humidifier.
- To make the connection well among router, camera and phone, please ensure the devices are all in the effective range of Wi-Fi.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant

to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.