



<p>① Living a Beautiful Life</p> <p>Package Contents:</p> <table border="1"> <tr> <td>② 8" Subwoofer</td> <td>1 pcs</td> <td>③ Remote Control</td> <td>1 pcs</td> </tr> <tr> <td>② 2" L Speaker</td> <td>1 pcs</td> <td>④ RCA Cable</td> <td>1 pcs</td> </tr> <tr> <td>② 2" R Speaker</td> <td>1 pcs</td> <td>⑤ 3.5mm-to-RCA Cable</td> <td>1 pcs</td> </tr> <tr> <td>④ Speaker Floorstand</td> <td>2 pcs</td> <td>⑥ Hook for TV soundbar system installation bag</td> <td></td> </tr> </table>	② 8" Subwoofer	1 pcs	③ Remote Control	1 pcs	② 2" L Speaker	1 pcs	④ RCA Cable	1 pcs	② 2" R Speaker	1 pcs	⑤ 3.5mm-to-RCA Cable	1 pcs	④ Speaker Floorstand	2 pcs	⑥ Hook for TV soundbar system installation bag		<p>LUGULAKE®</p> <p>Living a Beautiful Life</p> <p>Specifications:</p> <ul style="list-style-type: none"> Input Protocol: A2DP/BT 4.0 Enabled Output protocol: 32bit/17.177.2watt*2 Frequency Response: subwoofer 30Hz-104Hz, LR speaker 139Hz-20kHz SN Ratio: >80dB, separation: >40dB Size: 240*W350*D345mm (9.45*13.81*13.94 inches) Weight: 4.9kg/10.82lb (subwoofer: 1.85*1.97*2.00 inches) LR speaker Net Weight: 4.9kg (1.084 lb) 											
② 8" Subwoofer	1 pcs	③ Remote Control	1 pcs																									
② 2" L Speaker	1 pcs	④ RCA Cable	1 pcs																									
② 2" R Speaker	1 pcs	⑤ 3.5mm-to-RCA Cable	1 pcs																									
④ Speaker Floorstand	2 pcs	⑥ Hook for TV soundbar system installation bag																										
<p>② Living a Beautiful Life</p> <p>Keys on remote and panels of subwoofer</p> <p>Front panel keys:</p> <p>Back Panel keys:</p>	<p>LUGULAKE®</p> <p>Living a Beautiful Life</p>																											
<p>③ Living a Beautiful Life</p> <p>Remote control:</p> <p>Tips:</p> <ul style="list-style-type: none"> * 0-9 number keys: 1: Under BT connection mode: press "1" to select "CH01" which has been stored after "SCAN" press "1" to select "CH01" in "FM" radio channel 2: Under USB connection mode: press "1" to select the song number in "1" in current folder. <p>* For FM connection mode use only: Tuner CH+, MEM, SCAN</p> <p>* For USB connection mode: Folder A V: switch up and down</p> <p>MEM: store the hand channel after "Mem".</p> <p>Default Settings</p>	<p>LUGULAKE®</p> <p>Living a Beautiful Life</p> <p>Installation:</p> <p>1.TV Soundbar System install</p> <p>Step 1: </p> <p>Step 2: </p> <p>Step 3: </p>																											
<p>④ Living a Beautiful Life</p> <p>2.Floorstand computer speaker system install</p> <p>Step1: Press power-on on the back panel of subwoofer.</p> <p>Step2: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step3: Press AUX on the front panel of subwoofer to "AUX" mode or Press AUX on the remote to activate AUX mode, volume up or down, tremble up or down, LED light changing for your actual use.</p> <p>Step4: Play Audio/video files on your devices to enjoy.</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, LED light changing for your actual use.</p>	<p>LUGULAKE®</p> <p>Living a Beautiful Life</p> <p>Connection mode:</p> <p>a.AUX (RCA) connection</p> <p>1.TV&DVDCD Connection</p> <p>Step1: Finish cable connection as in the following pic:</p> <p>Step2: Press power-on on the back panel of subwoofer.</p> <p>Step3: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step4: Press AUX on the front panel of subwoofer to "AUX" mode or Press AUX on the remote to activate AUX mode, BT will be shown on the LED display in the front panel of subwoofer</p> <p>Step5: Press BT on the front panel of subwoofer or on the remote to activate BT mode, BT will be shown on the LED display in the front panel of subwoofer</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, LED light changing for your actual use.</p>																											
<p>⑤ Living a Beautiful Life</p> <p>2.Computer, DVDCD, IPodMP3,Note book Connection</p> <p>Step1: Finish cable connection as in the following pic:</p> <p>Step2: Press power-on on the back panel of subwoofer.</p> <p>Step3: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step4: Press AUX on the front panel of subwoofer to USB mode or Press USB on the remote to activate USB mode, volume up or down, tremble up or down, LED light changing for your actual use.</p> <p>Step5: Play Audio/video files on your devices to enjoy.</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, fold up or down (on remote), LED light changing for your actual use.</p>	<p>LUGULAKE®</p> <p>Living a Beautiful Life</p> <p>b.BT connection</p> <p>Step1: Finish cable connection as in the following pic:</p> <p>Step2: Press power-on on the back panel of subwoofer.</p> <p>Step3: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step4: Press BT on the front panel of subwoofer or Press BT on the remote to activate BT mode, BT will be shown on the LED display in the front panel of subwoofer</p> <p>Step5: Press BT on the front panel of subwoofer or on the remote to automatically search FM radio channels and memorize them in "CH 01" mode</p> <p>Step6: Press BT on the front panel of subwoofer or on the remote to automatically search radio frequency "TV BAR", pair (default pair code 0000, if needed).</p> <p>For example: press 1, it will switch into "CH 01".</p> <p>Step7: Press BT on the front panel of subwoofer to select 102.8 MHz channel.</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, LED light changing for your actual use.</p> <p>Lugulake T-200X supports Digital FM with 100 channels capacity from FM 87.5MHz to 108MHz.</p>																											
<p>⑥ Living a Beautiful Life</p> <p>C:USB connection</p> <p>Step1: Finish cable connection as in the following pic:</p> <p>Step2: Press power-on on the back panel of subwoofer.</p> <p>Step3: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step4: Press AUX on the front panel of subwoofer to USB mode or Press USB on the remote to activate USB mode, volume up or down, tremble up or down, LED light changing for your actual use.</p> <p>Step5: Play Audio/video files on your devices to enjoy.</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, fold up or down (on remote), LED light changing for your actual use.</p>	<p>LUGULAKE®</p> <p>Living a Beautiful Life</p> <p>d:FM connection</p> <p>Step1: Finish cable connection as in the following pic:</p> <p>Step2: Press power-on on the back panel of subwoofer.</p> <p>Step3: Press BT on the front panel of subwoofer or on the remote.</p> <p>Step4: Press BT on the front panel of subwoofer to FM mode or Press FM on the remote to activate FM mode.</p> <p>Step5: Press BT on the front panel of subwoofer or on the remote to automatically search FM radio channels and memorize them in "CH 01" mode</p> <p>Step6: Press BT on the front panel of subwoofer or on the remote to automatically search radio frequency "TV BAR", pair (default pair code 0000, if needed).</p> <p>For example: press 1, it will switch into "CH 01".</p> <p>Step7: Press BT on the front panel of subwoofer to select 102.8 MHz channel.</p> <p>Other steps: volume up or down, tremble up or down, bass up or down, LED light changing for your actual use.</p> <p>Lugulake T-200X supports Digital FM with 100 channels capacity from FM 87.5MHz to 108MHz.</p>																											
<p>More Information:</p> <p>a.Warning:</p> <ul style="list-style-type: none"> Do not expose T-200X to the high-temper, humid environment, preventing it from raining. In order to avoid electric shock or other accidents, do not disassemble T-200X without any professional guidance. In case any liquids sparked into the subwoofer, switch off the power and unplug the power cable immediately. Do not keep T-200X close to fire. <p>b.Problem shooting</p> <table border="1"> <thead> <tr> <th>Problem</th> <th>Possible Cause</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td>T-200X does not turn on</td> <td>Power cable not connected</td> <td>Check connection</td> </tr> <tr> <td>T-200X does not respond to remote</td> <td>Battery is empty</td> <td>Replace battery</td> </tr> <tr> <td>Sound reproduction too soft</td> <td>Volume of T-200X too low</td> <td>Increase volume of T-200X and your source device and install your source device</td> </tr> <tr> <td>BT can not connect</td> <td>Error BT driver/software installed in your source device and install from your device retailer and install</td> <td>Get the right BT driver/software from your device retailer and install</td> </tr> <tr> <td>No sound reproduction</td> <td>Source device produces no signal</td> <td>Check connection of the source device and turn on the source device</td> </tr> <tr> <td>Cable connected in error/defective cable</td> <td>Cable connected in error/defective cable</td> <td>Check connection of the cable and replace the cable if necessary</td> </tr> <tr> <td>Under BT mode, distance is too far</td> <td>Under BT mode, distance is too far</td> <td>Put your BT source device close to the subwoofer</td> </tr> <tr> <td>BT source device not connected successfully</td> <td>BT source device not connected successfully</td> <td>Restart T-200X</td> </tr> </tbody> </table> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. It is recommended that the user try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>Warranty:</p> <p>Lugulake One-Year Limited Warranty Summary</p> <p>Lugulake warrants the included speaker products and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Lugulake does not warranty shipping charges may apply depending on location.</p> <p>Lugulake offers technical support service for lifetime free.</p> <p>Easy contact us:</p> <ul style="list-style-type: none"> Phone: 866-244-8595 Email: support@lugulake.us <p>We are always here to solve your problems.</p>		Problem	Possible Cause	Solution	T-200X does not turn on	Power cable not connected	Check connection	T-200X does not respond to remote	Battery is empty	Replace battery	Sound reproduction too soft	Volume of T-200X too low	Increase volume of T-200X and your source device and install your source device	BT can not connect	Error BT driver/software installed in your source device and install from your device retailer and install	Get the right BT driver/software from your device retailer and install	No sound reproduction	Source device produces no signal	Check connection of the source device and turn on the source device	Cable connected in error/defective cable	Cable connected in error/defective cable	Check connection of the cable and replace the cable if necessary	Under BT mode, distance is too far	Under BT mode, distance is too far	Put your BT source device close to the subwoofer	BT source device not connected successfully	BT source device not connected successfully	Restart T-200X
Problem	Possible Cause	Solution																										
T-200X does not turn on	Power cable not connected	Check connection																										
T-200X does not respond to remote	Battery is empty	Replace battery																										
Sound reproduction too soft	Volume of T-200X too low	Increase volume of T-200X and your source device and install your source device																										
BT can not connect	Error BT driver/software installed in your source device and install from your device retailer and install	Get the right BT driver/software from your device retailer and install																										
No sound reproduction	Source device produces no signal	Check connection of the source device and turn on the source device																										
Cable connected in error/defective cable	Cable connected in error/defective cable	Check connection of the cable and replace the cable if necessary																										
Under BT mode, distance is too far	Under BT mode, distance is too far	Put your BT source device close to the subwoofer																										
BT source device not connected successfully	BT source device not connected successfully	Restart T-200X																										