


INSIDE THE BOX

- 1. Fantom Fanband
- 2. Charging Dock
- 3. USB Charging Cable
- 4. Extended Wristband
- **5.** User Manual
- 6. Warranty Card



2. FOLLOW INSTRUCTIONS



3. DOWNLOAD APP





Fantom app available on App Store and Google play

CLEANING FANTOM

To clean, use a lint free cloth. Avoid the use of aerosol sprays, solvents or abrasives.

MORE INFORMATION

For more help and tutorials, visit www.getfantom.com/help

REGULATORY COMPLIANCE INFORMATION

EU Compliance Statement

TRNPK Group hereby declares that this wireless product is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive. A copy of the EU declaration of conformity can be found at www.getfantom.com/compliance

Fantom contains no user serviceable parts. Do not attempt to open or dismantle the device. Do not expose it to high tempera-

tures or liquids as it may may damage the battery causing harm or injury to you.

Disposal and recycling information

This symbol indicates that this product and/or battery should not be disposed of in household waste. When you decide to dispose of this product and/or battery, do so in accordance with local environmental laws and guidelines.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.