


CONTENT LIST




To prevent damage, the contents of the package listed are properly packed and may be out of plain sight. Please remove all contents in packaging.

CAUTION:
DO NOT MODIFY TOY IN ANY WAY. ADULT SUPERVISION IS ADVISED!

GETTING TO KNOW YOUR VEHICLE



CONTROLLER BATTERY INSTALLATION




DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE BATTERIES

DO NOT MIX OLD AND NEW BATTERIES

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

PLEASE NOTE:
A) Make sure batteries are inserted correctly (+ or -) into the controller.
B) If the vehicle does not respond properly, please replace the alkaline batteries in controller or recharge vehicle battery. Remember to take out all batteries from the controller if vehicle will not be used for a long period.

CHARGING YOUR VEHICLE



NOTE: CHARGING USUALLY TAKES ABOUT 15 MINUTES FOR A 15 MINUTE RUN TIME. DO NOT CHARGE MORE THAN THIS. NEW BATTERIES ARE REQUIRED ON THE CONTROLLER. ONCE RUN TIME STARTS TO INCREASE, WHEN THE BATTERIES ARE LOW, THE LED POWER INDICATOR WILL BEGIN FLASHING.

NOTE: AFTER 15 MINUTES OF INACTIVITY, THE CONTROLLER AND VEHICLE WILL GO INTO SLEEP MODE. ONCE IN SLEEP MODE, YOU MUST TURN THE VEHICLE OFF AND ON AGAIN, AND GO THROUGH LINKING PROCEDURE (SEE BELOW SECTION).


REMEMBER:
Before recharging the battery, wait 10-15 minutes to let the battery cool down.
Never leave unattended while charging.

DANGER!
NEVER INSERT ANY SHARP OBJECTS, PINS OR SCREWS INTO THE VEHICLE AS THIS MAY PUNCTURE THE INTERNAL BATTERY.


Caution:
1. Make sure to always use new or fully charged batteries in controller.
2. Do not operate the vehicle if it becomes damaged in any way.
3. Try not to crash vehicle as it may cause damage.
5. Check the area is clear of any obstacles before operating.
6. Adult supervision is always recommended.
7. Never operate near animals. Keep vehicle away from fingers, hair, eyes, and other body parts. Stay away from obstacles and electrical hazards.

Warning:
1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are only to be charged under adult supervision.
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Batteries are to be inserted with correct polarity.
6. Exhausted batteries are to be removed from the toy.
7. The supply terminals are not to be short-circuited.

HOW TO LINK YOUR VEHICLE



OPERATING YOUR VEHICLE



DANGER!
NEVER TOUCH THE WHEELS WHEN THEY ARE TURNING. NEVER INSERT ANY SHARP OBJECTS, PINS OR SCREWS INTO THE VEHICLE AS THIS MAY PUNCTURE THE MOTOR OR BATTERY!

NOTE:
Operating multiple vehicles with the same frequency in close proximity will cause interference and poor performance. Works best away from electrical hazards and large obstacles. Do not put objects or fingers near the front or rear of the wheels while it is turning. Vehicle may not run properly on rough terrain. Make sure objects do not get obstructed in the wheels. Avoid hard crashes. Never give the vehicle or controller to any child under the age of 3 as it contains small parts. When not in use, remove batteries from compartments. Normal working distance is about 26 feet (8 meters).

TROUBLE SHOOTING

PROBLEMS	REASONS	SOLUTIONS
Running Problems	Battery inside the controller is weak	Replace with new Alkaline batteries.
	There is a weak or low reception to the controller.	
Operating Problems	Battery inside the vehicle is weak.	Recharge vehicle in the controller.
	Small object obstructs movement of the trim.	
Other	Vehicle driven on carpet and has fabric threads caught in the wheels.	Operating on carpet is not recommended. Run vehicle on a flat and hard surface.
	Vehicle does not respond to the controller.	
	The controller's frequency is disrupted by something around the environment.	Make sure the vehicle is linked to the controller. Operate in close proximity to the controller.

PLEASE NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

B1347 / B1350 / B1314

WARNING:
CHOKING HAZARD-
Small parts not for children under 3 years

MADE IN CHINA

ITEM NO. B1347 & B1350



MADE IN CHINA

Radio Control Vehicle

INSTRUCTION MANUAL

***IMPORTANT:** IF VEHICLE DOES NOT RESPOND PROPERLY, PLEASE CHARGE BATTERIES IN VEHICLE AND REPLACE BATTERIES IN CONTROLLER (4-AA NOT INCLUDED).

**** NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

WARNING:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE BATTERIES.

DO NOT MIX OLD AND NEW BATTERIES.

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

REQUIRES 4-AA BATTERIES IN CONTROLLER (NOT INCLUDED).

COLORS AND DECORATIONS MAY VARY. KEEP CONTENT DETAILS FOR FUTURE REFERENCE.

MANUFACTURED & DISTRIBUTED BY © 2020
MINDS B.V. LIMITED / MINDS INC. LLC
10000 BROADWAY INDUSTRIAL CENTRE, #03-24-26
400 PANGLOSS STREET, 13 JALAN, #11, HONG KONG
NORTH LANS, 17001 84221 USA
info@mindsinc.com