

ON

OFF

Power Switch

Turn on/off the speaker

USB Port / TF-Card Slot

Insert MP3 music media types

Micro-USB Port

M

Playing Mode Button*

Short press: Change the playing mode
Mode switches in order **BT>USB>FM>TF**

▶▶|/+

Long press: Increase volume
Short press: Select the next track
Short press (FM): Scan the next channel

◀◀|-

Long press: Decrease volume
Short press: Select the last track
Short press (FM): Scan the previous channel

▶|

Short press: Play and pause music
Long press: Reject calls
Short press: Answer and hang up calls
Short press (FM): Scan channels automatically

Bluetooth®

BLUETOOTH® CONNECTION

1.

Power the speaker on. The speaker will automatically enter pairing mode when powered on.

2.

Turn on your device's Bluetooth from the Bluetooth menu and select "MVMT_SP3444" speaker.

3.

When paired successfully the device will make a tone to confirm the connection has been made.

4.

Remember to turn the speaker off after each use.

Note:

The speaker will reconnect automatically if your device has been paired previously. Depending on your device's type and configuration, manual reconnection may be required each time.

Note:

If a password is needed, type in 0000.

Charging

1.

Using a Micro-USB cable (included), insert the jack into the port on back of unit and then plug the USB connector into USB port on the power source.

2.

Charge the device until the red LED indicator turns off.

3.

Always disconnect the cable when charging is finished.

Note:

It will take approximately 3 hour to achieve a full charge.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Trouble Shooting

No power

Recharge your speaker using the Micro-USB cable. If the problem persists, try using another Micro-USB cable.

No response from the unit

Ensure your Bluetooth device supports an A2DP, AVRCP, or HSP profile.

Check if both devices are paired and connected to each other.

Restart the device and try to reconnect.

No FM signal

Plug a Micro-USB cable into a device to maximize FM signal.

*Mode function works only when media type is inserted into the device.

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1- This device may not cause harmful interference.

2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or on experienced radio/TV technician for help or assistance.

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.

Specifications

Model No: SP3444 Omega

Working Distance: Approx. 33 ft

Playback Time: Approx. 2 Hours

Charge Time: 3 Hours

Speaker Output Power: 5 W x 1

Speaker Impedance: 2 Ω

Battery: 800 mAh Lithium (rechargeable)

Bluetooth®

M | M V M T ®

MVMT and MVMT logo are trademarks of Argento SC @2019. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Argento SC is under license. All other trademarks and trade names are those of their respective owners. Designed in New York. Made in China. New York NY 10018 support@argentosc.com | www.argentosc.com

RoHS

CE

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1- This device may not cause harmful interference.

2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or on experienced radio/TV technician for help or assistance.

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.

Specifications

Model No: SP3444 Omega

Working Distance: Approx. 33 ft

Playback Time: Approx. 2 Hours

Charge Time: 3 Hours

Speaker Output Power: 5 W x 1

Speaker Impedance: 2 Ω

Battery: 800 mAh Lithium (rechargeable)

Bluetooth®

M | M V M T ®

MVMT and MVMT logo are trademarks of Argento SC @2019. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Argento SC is under license. All other trademarks and trade names are those of their respective owners. Designed in New York. Made in China. New York NY 10018 support@argentosc.com | www.argentosc.com

RoHS

CE

Omega

LED WIRELESS SPEAKER

IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT