



**WARNING!****ADULT OPERATING ONLY!**

1. Make sure the vehicle is set on remote control operation. For remote control operation **press the button (10 on the diagram below)** on the dashboard of the vehicle.



2. Press the "ON" button on the remote control to make connection with the vehicle. The Indicator light should turn **red**.
3. Always use caution when operating. Make sure child is fastened in the vehicle with the seat belt when in remote control operation.
4. Move the **Left Joystick** up and down slowly to control the vehicle's speed. Releasing the joystick too quickly may cause sudden jerks to the vehicle.
5. Move the **Right Joystick** left and right to turn the vehicle.

FCC warning words in the instruction:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

(NOTE: Make sure steering wheel is set to **unlocked** when in remote control operation - *when the steering wheel is set to unlocked it will no longer control the front wheels, turning will only be possible with the remote control.*)

Steering Wheel Bottom View

