



Internal Photographs

EUT - Open View



EUT – PCB View

Antenna location



EUT – PCB View

