

BLUETOOTH DEVICE IS CONNECTED TO THE UNIT

- When the BLUETOOTH device is connected for the first time, the device needs to be paired with the unit, and once pairing is completed.
- Select BLUETOOTH as the input source, surface analysis shows BLUE, sound and issue the appropriate tone.
- Open the paired BLUETOOTH compatible device.
- In the device BLUETOOTH list, select the name BB2403, if you need a password, After the connection will be automatically established. Please enter 0 0 0 0 or 1 2 3 4.

Note: Please pair your BLUETOOTH unit with this unit within 10 meters

WARRANTY CARD	
CUSTOMER:	DATE OF PURCHASE:
ADDRESS:	
THE SELLER:	INVOICE NO.
SERVICE TEL:	CHOP:

Precautions and safety warnings

- Can only be installed on vertical walls For installation
- Avoid locations with high temperature and humidity, and do not install on equipment that can not support equipment
- Note that the cables of this device are connected to external devices before loading.
- To prevent electric shock, please plug in the end. Aslo do not open the rear panel.
- Please accidentally spilled water on the device, may not be placed on the device with liquid items, such as vases. Also Please do not expose this product to rain or damp places.
- To completely disconnect the device, unplug the power plug from the electrical outlet On the wall.
- This unit has no internal user-service components, for maintenance the need for professional staff to carry out maintenance.

SPECIFICATION :

- FUNCTION: AUC/USB/SD/BLUETOOTH/REMOTE/OPTICAL/COAXIAL
- OUTPUT POWER: 20W=5W\*4
- DRIVE UNIT: 2" \* 4
- POWER SUPPLY: ADAPTOR 5V/2A

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

SPEAKER


MODEL:BB2403




USER MANUAL

PLEASE READ THIS USER MANUAL BEFORE USING

CONTROL PANEL FUNCTON DESCRIPTION



REAR BOARD JACK FUNCTION DESCRIPTION



REMOTE CONTROLLER FUNCTION DESCRIPTION

