

390mm



AIR CONDUCTION TWS EARPHONES



FQ1100

POWER ON & POWER OFF

1. The earbuds will automatically turn on, on opening the charging case.
2. The earbuds will automatically turn off once placed inside the charging case with the lid closed.

PAIRING

1. First-time Pairing with Device

Step 1: Open the charging case, and the earbuds will automatically power on and enter into pairing mode.

Step 2: Activate Bluetooth on your Bluetooth-enabled device and search for other Bluetooth devices.

Step 3: Select "FQ1100" from the list of Bluetooth devices shown.

Notes:

The earbuds will automatically connect with the device paired last time when the case is open.

2. Pairing with a New Device or Connecting Two Bluetooth Devices Simultaneously

Step 1: Prepare for Pairing: Place both earbuds in the charging case, ensure they are charging, and keep the case open.

Step 2: Enter Pairing Mode: Press and hold the case button for 3 seconds until the earbuds' LED indicators flash white rapidly.


Step 3: Connect to a Device:

• For a new device: Search for the earbuds on the device and connect.


For two devices:

First, connect the earbuds to the first device.
Then, repeat steps 1 & 2 to enter pairing mode again (earbuds will disconnect from the first device).
Search and connect on the second device.
Finally, manually reconnect the earbuds on the first device.

TOUCH AREA DIAGRAM



PRODUCT DIAGRAM



INSTRUCTIONS FOR USE

• Single tap left side	◀ Volume Down
• Single tap right side	◀ Volume Up
• Double tap either side	▷ Play/Pause/Answer/Hang up
• Triple tap left	◀ Previous song
• Triple tap right	▷ Next song
— Touch and hold 2s right	Game Mode
— Touch and hold 2s left	Voice assistant
— Touch and hold 2s either side	Reject incoming calls

CHARGING INDICATOR LIGHT

1. Place the left and right earbuds in the charging case;
2. When charging the case with a cable: the red light of the charging case remains on, and when the charging case is fully charged, the red light turns off.

(Please be sure to use 5V/1A charging cable or attached charging cable when you purchasing products)

RESET

1. Long press the charging case button for 8 seconds.
2. The charging case indicator will flash white once at 3 seconds and once at 8 seconds.

MATTERS NEEDING ATTENTION

1. Please put the headset in the correct position for charging.
2. The battery (battery pack or combination battery) shall not be exposed to conditions such as sunlight, fire, or similar overheating.
3. Listening to music at a high volume for a long time may cause hearing damage. Please adjust the volume appropriately when using this device.
4. Do not use the device during thunderstorms, as thunderstorms may cause abnormal operation of the device and increase the risk of electric shock.
5. Do not dismantle or modify the headset for any reason. Otherwise, it may cause malfunction or burnout, which is not covered under warranty.

*If the consumer violates the above warning and uses it improperly, resulting in personal and property damage, the company will bear all consequences and will not bear any legal responsibility.

Product information

Maintenance records	Date	Cause and treatment of failure
Product name		
Product model		
Customer name		
Customer phone		
Purchase date		
Customer address		

110mm

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.