

Wireless Charger X5MAX Instruction

Product Features & Specifications

1. PC fireproof material, leather surface texture, and non-slip silicone mat bottom;
2. Dual-coil support mobile phone charging anyway;
3. Intelligent recognition lighting design, automatic identification of charging equipment.

Material: PC fireproof material	Input Voltage/Current: 5V/2A 9V/1.7A Output Voltage/Current: 5V/1A 9V/1.1A
Transmission power: 10W(MAX)	Input interface: Micro*2
Transmission distance: ≤8MM	Charging efficiency: ≥73%
Dimension:130*73*12.5mm Without bracket	Weight: 99.5g including bracket

Using Guide

Please install the base before using this product. The base is inserted in the direction of the arrow into the wireless charging transmitter slot. (**插示意图**)

This product contains two micro input interface, according to the phone placed flat or horizontal or vertical charging different ways, USB power cable just insert one of the micro input interface to recharge.

Connect the adapter to charge

1. Connect the wireless charger to the adapter with USB cable correctly.
2. When Power on, the two white indicator of wireless charger will shortly flashing and off, the product is in standby mode.
3. Put the charged device with wireless charging function on the wireless charger, when charging, then indicator will keep white light on.
4. After the charged device is fully charged or removed, the indicator of the wireless charger will off automatically.

5. If the indicator of the wireless charger is in quick flash mode, it indicates that the wireless charger is in abnormally alarmed condition or that foreign objects such as metal are placed on the wireless charging transmitter.

(For example: ①The transmitter coil and the receiver coil are not in good position; ②transmitter or receiver is abnormal, etc.)

Note: At present, Samsung support the function of the full charging feedback, feedback as above, the rest of the phone with full charging while wireless charging transmitter will not be prompted.

Mobile phone charging mode

1. Ensure that the wireless charger is connected to the power supply.
2. When the mobile phone is charged flat , the wireless charging transmitter need not be installed on the base. When the mobile phone is horizontally or vertically charged, please install the base according to the Using Guide.
3. When Power on, the two white indicator of wireless charger will shortly flashing and off, the product is in standby mode.
4. Put the mobile phone with wireless charging function on the wireless charger center, when charging , the indicator will keep white light on.
5. If the phone does not display charging, please move your mobile phone location.

Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Attentions

1. Please do not crush or collision;
2. Please do not disassemble, dispose into fire or water, to avoid short-circuit and leakage.

- 3、Please do not use X5max at severe high temperatures, humid or corrosive environments, to avoid circuit damage and leakage currents.
- 4、Please do not places X5max too close with magnetic strip or Chip magcard (ID, debit card), to avoid the magcard failure.
- 5、Please keep implantable medical devices (cardiac pacemaker, implanted cochlea etc.) away from X5max at lease 20cm, to avoid X5max interference or potential interference the medical devices.
- 6、Please take care of Children to ensure they are not use X5max as plaything, in case of any accident.

The pictures in this guider are only for information, take practicality as standard.

Including: Wireless charger, Power Line and User's Guider

Charging adapter is not including, if need please buy it separately.

After Sales

The warranty time of X5max is 12 months. If it malfunctions in warranty time, please send X5max with invoice back to ICON service center. ICON will maintained or offer other services according the testing result. Please make sure X5max work with specified mobile device. Artificial damage or not normal use cause of any damage, ICON assumes no responsibility. For any query, please call to ICON service center or visit ICON website for inquiry. ICON reserve all the right for the final explanation.