

grandinroad®

POOL BOY BELL #160893

INSTALLATION AND OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PART AWAY FROM CHILDREN

REQUIRED ONE '23A' SIZE & TWO "AAA" SIZE BATTERIES (NOT INCLUDED)



OPERATING INSTRUCTIONS:

- 1) Inserts one brand new '23A' alkaline battery in the battery compartment located on the back of Door Bell, and inserts two brand new "AAA" alkaline batteries in the battery compartment located on the back of receiver.
- 2) Locate a suitable location for the Door Bell.
- 3) Use a power drill to make a hole on wall. Hammer a wall anchors into wall; make sure it is tightly fit into the hole. Then use a screw drive to turn the screws into wall anchors.
- 4) Door Bell is ready to hang. Make sure it is securely hanged.
- 5) Press button on the back of receiver to select sound, there are four available sound options. Volume control is available next to sound button.
- 6) Receiver is wireless, just put it on desire location.

BATTERY INSTRUCTIONS AND CAUTIONS:

- Use only the batteries recommended.
- Remove batteries when not in use.
- Do NOT use rechargeable batteries.
- Be sure to insert the batteries with the correct polarity +/-.
- Never mix different types of batteries: old and new, carbon-zinc, alkaline, nickel-cadmium.
- Always dispose of exhausted batteries properly.
- ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.**

FCC WARNING!

This item is not a toy and should be used for decoration only. The item contains small parts, caution of choking hazard. This product is intended for use by persons 15 years of age and older. Not intended for use by children 14 years of age and younger.

WARNING! Do not turn on the item until you have completely finished assembly. Do not place item on uneven surface. Do not place weight on item anytime.

CAUTION: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

FCC Warning Statement

This equipment has been tested and found to comply with the limits, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) **This device may not cause harmful interference, and**
- (2) **This device must accept any interference received, including interference that may cause undesired operation.**

You may also find helpful the following booklet, prepared by the FCC: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402.

Changes and Modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commissions rules.

**Please contact one of our Product Specialists for assembly assistance or questions at
1-800-491-4958 or email ps@grandinroad.com. Specialists are available weekdays 8:00a.m. to
8:00p.m. EST, or Saturday 9:30a.m. to 6:00p.m. EST**

MADE IN CHINA