
媒体播放机说明书

i01

一、产品接口说明



编号	部件名称	数量
1	产品主机	1
2	遥控器	1
3	电源适配器	1
4	HDMI高清视频线*	1
5	网线	1
6	快速使用指南	1

(如部分图片有差异,以实际产品为准。使用该产品前,请详细阅读本说明书。同时请保留,供以后参考。)

三、开机启动

1、安装操作

以下步骤以HDMI连接来描述,如果你是用AV线连接,请选择电视机的AV接口。

- ① 先将高清线一头连接机顶盒,另一头连接电视机或其他显示屏的HDMI1接口。
- ② 电视连接: 使用电视机遥控器,找到【信号源】按键,将电视机信号源切换到HDMI1信号; 一般电视机有 几个HDMI接口,只有选择了正确的信号才能正确连接。如果你是用AV线连接,则请选择AV接口。
- ③ 将AC电源线(12V/1.5A)一头接盒子一头接插座,打开开机按钮直到LED信号灯亮起,等待广告首页画面出

2、联网操作

① 无线连接

进入"设置"-"WIFI",选择您的WIFI,输入密码,点击"确定"进行连接,稍后会显示连接状态。 注: 请确保路由器无线网已连接到外网。

② 有线连接

a.将网线一端插入盒子网口,另一端插入路由器。

b.进入设置打开有线网络,连接好后,会在盒子右上角显示连接状态。

四、安装/卸载APK

1、安装APK

- ① 将下载的APK复制到U盘或移动硬盘,并连接到盒子。
- ②在盒子里找到【全部应用-媒体中心】APP,点击,找到U盘,选择要安装的APK,点击遥控器确定键即可安装。


2、卸载APK

- ① 进入【全部应用】、【调到】要删除的APK图标位置。
- ② 遥控器点击"菜单键"。
- ③ 选择"卸载"即可。

MEDIA PLAYER PRODUCT MANUAL

i01

1. Product Interface Details



2. Product Package

NO.	NAME	QUANTITY
1	Media Player	1
2	Remote Controller	1
3	Power Adaptor	1
4	HDMI Cable	1
5	Etherlan Cable	1
6	Product Manual	1

(If some pictures are different, the actual products shall prevail. Please read this manual carefully before using the product. Please keep it for future reference.)

3. Get started

1) Installing and setting up the device

The steps described below is for connection through a HDMI cable, if an AV cable is used, please connect it to AV (yellow, red, white) ports respectively on TV.

- ① Connect one end of the supplied HDMI cable to the Media Player Box, the other end to a HDMI port on TV or other display device.
- ② Use TV remote controller (the signal source key) to select right signal path for the HDMI port connected. There are normally several HDMI ports on a TV, and the connection can be enabled only when the right signal path is selected. If an AV cable is used, please select AV port instead.
- ③ Connect the AC power adapter (12V/1.5A) to the box and the other end to the power socket, turn on the box by pressing the power key until the LED indicator lights up, wait the box home page show in the

2) Connect to internet

① Wireless connection

Go to setting, WI-FI, click on the desired wifi hot spot, and input password of the wireless router for connection (A wifi icon pops up on the status bar after connection).

Note: Please ensure that the wireless router has access to external internet.

- (2) Wired connection
- a) Plug one end of the net work cable in the LAN port on the device, and the other end to the router. b) Go to setting turn on ethernet, after connection, an icon of cabled connection appears on top-right conner of the status bar.

4. Install / Uninstall APK

- ②Chick "All APPs" --- "Filemanager", find USB, select the desired APK, and click on Install.

2) Uninstall APK

- ① Go to "All Apps", Click on the icon of the APK you want to delete.
- 2 Click "menu" key on remote controller.
- ③ Click "uninstall" to remove the APK.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

展开尺寸: 345x105mm 折成品尺寸: 115x105mm

材质: 157g书纸

工艺: 单黑正反面印刷, 三折页, 折成品