



Google TV


Mobile Theater User Manual ユーザー マニュアル 사용 설명서 Benutzerhandbuch Mode d'emploi Manuale dell'utente Manual del usuario Handleiding Instrukcja obsługi Užívateľská príručka

دليل المستخدم 使用手册 Руководство пользователя

Package contents

The number in brackets indicates the number of pieces.
• Mobile Theater (1) • Quick Guide (1) • USB Cable (1)


Device information



1. Power 2. Indicator light 3. Mic 4. Directional Pad
5. OK 6. Google Assistant 7. Home 8. Volume + / -
9. Customize 10. Prime video 11. YouTube 12. Back
13. Headset 14. USB Type-C 15. Micro SD

*USB Type-C Can be linked to other devices or charged.
This device supports USB Power Delivery and Quick Charge.

Preparation




Press and hold for 3 seconds to turn on the Mobile Theater when it is turned off.




Connect the glasses to the Headset input on the Mobile Theater. Wear glasses and follow the system instructions to configure the network before use.

Insert memory card (sold separately)



This device is compatible with Micro SD memory cards.
Make sure the notched corners are facing the correct direction when inserting the Micro SD card.

Understand the indicator




Connection



Access the internet via Wi-Fi connection, you can also connect it to other devices via Bluetooth.

Google Assistant



Connect the glasses to the Headset input on the Mobile Theater. Wear glasses and follow the system instructions to configure the network before use.

Specification

WARNING!

Precautions for Product Usage

- Before using this product, it is recommended to flip the device and check for any obvious damage, electrical leakage, or any other conditions that may pose a risk to human safety.

- Please do not store the battery for a long period of time after fully discharging it, as this can cause damage to the battery cells due to over-discharge.

- To maintain optimal product performance, avoid prolonged charging.

- The product is not water resistant. Do not expose it to water or rain.

- Do not pour or spray liquid on the product. If you want to clean the product, dampen a microfiber cloth with neutral detergent and wipe the surface of the product with the microfiber cloth.

- Before cleaning or maintenance, please stop using the product and unplug all cables.

- Do not expose the product to direct sunlight and keep it away from heat sources such as radiators or flames.

- This product contains precision electronic components. Avoid strong impacts caused by dropping, collisions and other causes. Do not place heavy objects on top of the product.

- Do not damage or modify the product in any form to ensure proper use.

- Do not use the product if it is damaged.

- The product cannot be disassembled without authorization. If the product does not work properly, contact after-sales personnel for troubleshooting. Unauthorized disassembly may cause an explosion or fire.

- This product contains a lithium battery. When boarding a plane, store the product in carry-on luggage. Do not store the product in checked baggage.

- If you think the product is interfering with any medical device, stop using the product and consult your doctor.

- Dispose of the waste lithium battery in accordance with local regulations on household waste.

- Observe signs and notices of forbidding or restricting the use of electronic devices.

- Place the product and provided accessories in a proper location to prevent pets from biting and damaging them.

- If skin issues occur when you use the product, stop using it.

Disclaimer

Once you use the product, you are deemed to have read the disclaimer and safety instructions carefully, and have understood, agreed to, and accepted the disclaimer and safety instructions. You are responsible for the consequences when you use the product. You agree to use the product only in proper environments and for purposes that are in accordance with all applicable laws and regulations. If spontaneous combustion, explosion, other loss, personal injuries, and other consequences occur due to your improper operations or violations of safety instructions, we assume no responsibility.

Operating Environment

To ensure safety, it is important to carefully check the operating environment before using the product.

- Recommended temperature: 0°C-35°C. Avoid extreme temperatures to prevent performance issues or damage.

Precautions for Product Storage

- If you will not use the product within a long period of time, we recommend that you place it indoors and in a shaded and well-ventilated area.

- To prevent irreparable damage to the product, avoid placing it in a damp place, and do not expose it to rain or snow.

- The recommended storage temperature is 0°C to 40°C.

- Avoid placing the product in high-temperature cars.

Safety information

CAUTION!

NOTICE:

For fire and electric shock, do not expose this device to rain or moisture. In order to avoid any possible risk of electric shock, never attempt to open the device. If the device is damaged, do not attempt to repair it by yourself. Please contact qualified technicians. No part of this unit should be repaired by users.

Do more on your TV with your voice

Your TV is more helpful than ever. Ask Google Assistant to find movies, stream apps, play music, and control the TV - all with your voice. Even get answers, control smart home devices, and more. Press the Google Assistant button on the Mobile Theater to get started.

Hey Google

AVERTISSEMENT !

Once vous utilisez le produit, vous êtes considéré comme ayant lu et accepté la déclaration et les instructions de sécurité. Vous êtes responsable pour les conséquences lorsque vous utilisez le produit. Vous acceptez d'utiliser le produit uniquement dans des environnements appropriés et à des fins conformes à toutes les lois et régulations applicables. Si une explosion, une explosion d'autres pertes, des blessures corporelles et d'autres conséquences se produisent en raison de vos mauvaises opérations ou de violations des consignes de sécurité, nous n'assumons aucune responsabilité.

REMARQUE : Pour éviter les incendies et les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Afin d'éviter tout risque éventuel d'électrocution, n'essayez jamais d'ouvrir l'appareil. En cas de panne de l'appareil, n'essayez pas de le réparer vous-même. Toute réparation doit être effectuée par des techniciens qualifiés. Aucune partie de cet appareil ne doit être réparée par les utilisateurs.

Charge de Responsabilité

Une fois que vous avez utilisé le produit, vous êtes réputé avoir lu attentivement la décharge de responsabilité et les consignes de sécurité, et vous acceptez d'accéder à la décharge de responsabilité et les consignes de sécurité. Vous êtes responsable des conséquences lorsque vous utilisez le produit. Vous acceptez d'utiliser le produit uniquement dans des environnements appropriés et à des fins conformes à toutes les lois et régulations applicables. Si une explosion, une explosion d'autres pertes, des blessures corporelles et d'autres conséquences se produisent en raison de vos mauvaises opérations ou de violations des consignes de sécurité, nous n'assumons aucune responsabilité.

Environnement de Fonctionnement

- Pour garantir la sécurité, il est important de vérifier soigneusement l'environnement de fonctionnement avant d'utiliser le produit.

- Température recommandée : 0°C-35°C. Évitez les températures extrêmes pour éviter les problèmes de performance ou les dommages.

Warranty

Warranty service is provided within one year from the date of purchase, unless local regulations state otherwise. The product is not within the scope of warranty in any of the following cases:

- The warranty period expires.
- Your product is a resold product.
- Damage caused by repairers who are not authorized by Shenzhen SEI Robotics Co., Ltd to disassemble the product.
- Damage caused by failure to use, maintain, or store the product according to the requirements of the user manual.
- Damage caused by force majeure.
- Damage caused by other non-product quality issues.

Trademark

Google TV is the name of this device's software experience and a trademark of Google LLC. Google and YouTube are trademarks of Google LLC. Google TV is not available in certain languages and countries. Availability of services varies by country and language. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license.

FCC regulatory performance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

AVERTISSEMENT !

Précautions pour le Stockage du Produit

- Si vous n'utilisez pas le produit pendant une longue période, nous vous recommandons de le placer à l'intérieur et dans un endroit ombragé et bien ventilé.

- Pour éviter des dommages irréparables au produit, évitez de le placer dans un endroit humide et ne l'exposez pas à la pluie ou à la neige.

- La température de stockage recommandée est de 0°C à 40°C.

- Évitez de placer le produit dans des voitures à haute température.

Garantie

Le service de garantie est fourni dans un délai d'un an à compter de la date d'achat, sauf disposition contraire de la réglementation locale.

Le produit n'est pas couvert par la garantie dans l'une des circonstances suivantes.

- La période de garantie expire.

- Votre produit est un produit revendu.

- Dommages causés par des réparateurs qui ne sont pas autorisés par Shenzhen SEI Robotics Co., Ltd. à démonter le produit.

- Dommages causés par le défaut d'utilisation, d'entretien ou de stockage du produit conformément aux exigences du manuel d'utilisation.

- Dommages causés par le cas de force majeure.

- Dommages causés par d'autres problèmes de qualité non liés au produit.

Marquage CE

C'est un produit de classe B. Dans un environnement domestique, ce produit peut provoquer des interférences radio, auquel cas l'utilisateur devra peut-être prendre des mesures adéquates.

Déclaration UE de Conformité

L'appareil est conforme aux exigences essentielles et aux dispositions des directives 2014/53/UE.

Conformité réglementaire IC

Cet appareil est conforme à la norme CAN ICES-003 (B) NMB-003 (B).

Cet appareil contient des émetteurs / récepteurs exempt(s) de licence et sont conformes aux RSS exemptes de licence d'innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toutes les interférences requises, y compris les interférences susceptibles de provoquer un fonctionnement indésirable.

Déclaration de la FCC

Cet appareil a été testé et déclaré conforme aux limites d'un appareil numerique de Classe B, conformément à la Partie 15 des Règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet appareil génère, utilise et émet de l'énergie radioélectrique. S'il n'est pas installé et utilisé conformément aux instructions, il peut provoquer des interférences nuisibles aux communications radio. Cependant, il n'y a aucune garantie que des interférences ne se produisent pas dans une installation particulière. Si cet appareil provoque des interférences nuisibles aux communications radio, lequel, il n'y a aucune garantie que des interférences ne se produisent pas dans une installation particulière.

Si des problèmes de peau surviennent lorsque vous utilisez le produit, arrêtez de l'utiliser.

Environnement de Fonctionnement

- Pour garantir la sécurité, il est important de vérifier soigneusement l'environnement de fonctionnement avant d'utiliser le produit.

- Température recommandée : 0°C-35°C. Évitez les températures extrêmes pour éviter les problèmes de performance ou les dommages.

Restrictions Nationales

Restriction réglementaire d'utilisation : Lorsque le produit fonctionne dans la bande de fréquences 5150 - 5350 MHz, son utilisation n'est autorisée qu'à l'intérieur d'un bâtiment.

CE Mark



This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

The device is in compliance with the essential requirements and provisions of directives 2014/53/EU.

National restrictions

Regulatory restriction of use: When the product operates in the 5150 - 5350 MHz frequency band, its use is only authorized inside a building.

Operation temperature: 0-35°C

Operation frequency (Max power)

Bluetooth: 2402-2480 (9dBm)

WiFi: 2412MHz-2472MHz(16dBm)

5745MHz-5825MHz(11dBm)