

GQ3109-Armor Pad Lite说明书

成品尺寸：70*113mm

材质：128g铜版纸双面印过哑胶

ulefone




Follow us on Facebook

ARMOR PAD LITE
USER MANUAL

www.ulefone.com

LANGUAGE:EN/DE/FR/ES/IT/RU/UA/JP

1. Device Layout



- | | |
|-------------------------------------|-------------------------------|
| 1-Power Key/Side Fingerprint Sensor | 8-3.5mm Headphone Jack |
| 2-Customized Button | 9-Type-C Charging Port |
| 3-Front Camera | 10-Flash |
| 4-Receiver | 11-Rear Camera |
| 5-Light Sensor/Proximity Sensor | 12-NFC |
| 6-LED Indicator Light | 13-uSmart Expansion Connector |
| 7-Speaker | 14-Volume |

2.GETTING STARTED

2.1 Charging the battery

Connect the supplied USB cable to the Type-C connector of the tablet. Connect the cable to the adapter and the adapter to the mains. The tablet begins to charge and the battery indicator is shown on the screen.

2.2 Long press the ON / OFF button to start.



WARNING:

Charge the battery fully during the first charge and prior to first use.

3.Contained in the box



Tablet



Charger




Type-C



Quick Start Guide

[2]

1.BESCHREIBUNG DES GERÄTES



- | | |
|---|-------------------------------|
| 1-An Knopf/Seitlicher Fingerabdrucksensor | 8-3,5-mm-Kopfhöreranschluss |
| 2-Individueller Knopf | 9-Typ-C Ladebuchse |
| 3-Frontkamera | 10-Blitz |
| 4-Empfänger | 11-Rückkamera |
| 5-Lichtsensor/Näherungssensor | 12-NFC |
| 6-LED Anzeige | 13-uSmart Expansion Connector |
| 7-Lautsprecher | 14-Lautstärke |

[3]

2. ERSTE SCHRITTE

2.1 Aufladen des Akkus

Schließen Sie das mitgelieferte USB-Kabel an den Typ-C-Anschluss des Tablets an. Verbinden Sie das Kabel mit dem Adapter und den Adapter mit dem Stromnetz.

Das Tablet beginnt zu laden und die Akkuanzeige wird auf dem Bildschirm angezeigt.

2.2 Drücken Sie zum Starten lang die Taste EIN / AUS.



WARNUNG:

Laden Sie den Akku beim ersten Aufladen und vor der ersten Verwendung vollständig auf.

3. Enthalten in der Box



Ladegerät




Type-C



Schnellstartanleitung

[4]

1. DESCRIPTION DE L'UNITÉ



- | | |
|--|-------------------------------|
| 1-Touche Démarrage/Capteur Empreinte Digitale Latérale | 8-Prise casque 3.5mm |
| 2-Bouton Personnalisé | 9-Port Charge de Type-C |
| 3-Caméra Frontale | 10-Flash |
| 4-Receveur | 11-Caméra Arrière |
| 5-Capteur Lumière/Capteur Proximité | 12-NFC |
| 6-Indicateur LED | 13-uSmart Expansion Connector |
| 7-Orateur | 14-Volume |

[5]

2.COMMENCER

2.1Charger la batterie

Connectez le câble USB fourni au connecteur Type-C de la tablette.
Connectez le câble à l'adaptateur et l'adaptateur au secteur.
La tablette commence à se charger et l'indicateur de batterie s'affiche à l'écran.


2.2 Appuyez longuement sur le bouton Allumez / Éteignez pour démarrer



ATTENTION:

Chargez complètement la batterie lors de la première charge et avant la première utilisation.


3.L'emballage du produit



Chargeur




Type-C



Guide de
démarrage rapide

[6]

1.DESCRIPCIÓN DE LAS PIEZAS



- | | |
|---|--------------------------------------|
| 1-Tecla de encendido/Sensor de huellas dactilares lateral | 8-Enchufe para auriculares de 3,5 mm |
| 2-Botón personalizado | 9-Puerto de carga tipo C |
| 3-Cámara frontal | 10-Flash |
| 4-Receptor | 11-Cámara trasera |
| 5-Sensor de luz/Sensor de proximidad | 12-NFC |
| 6-Led de notificaciones | 13-uSmart Expansion Connector |
| 7-Altavoz | 14- Volumen |

[7]

2. CÓMO EMPEZAR

2.1 Cargar la batería

Conecte el cable USB suministrado al conector tipo C de la tableta.
Conecte el cable al adaptador y el adaptador a la red.
La tableta comienza a cargarse y el indicador de batería se muestra en la pantalla.


2.2 Mantenga presionado el botón de reposo/activación para comenzar.



ADVERTENCIA:

Cargue la batería completamente durante la primera carga y antes del primer uso.

3. Contenido en la caja




Tableta



Cargador




Tipo-C



Guía de inicio rápido

[8]

1. DESCRIZIONE DELLE PARTI



- | | |
|--|-------------------------------|
| 1-Tasto Avviare/Sensore Impronte Digitali Laterale | 8-Presa per cuffie da 3,5 mm |
| 2-Pulsante personalizzato | 9-Porta Carica Tipo-C |
| 3-Fotocamera Frontale | 10-Flash |
| 4-Ricevitore | 11-Fotocamera Posteriore |
| 5-Sensore Luce/Sensore Prossimità | 12-NFC |
| 6-Indicatore LED | 13-uSmart Expansion Connector |
| 7-Altoparlante | 14-Volume |

[9]

IT

2. COME INIZIARE

2.1 Caricare la batteria

Collegare il cavo USB in dotazione al connettore Type-C sul tablet.
Collegare il cavo all'adattatore e l'adattatore alla rete.
Il tablet inizia a caricarsi e l'indicatore della batteria viene visualizzato sullo schermo.


2.2 Tenere premuto il pulsante Sleep / Wake per iniziare.



AVVERTIMENTO:

Caricare completamente la batteria durante la prima carica e prima del primo utilizzo.

3. Cosa c'è nella scatola



Tavoletta



Caricabatterie



Type-C




Guida Rapida

[10]

RU

1. ОСНОВНЫЕ ЭЛЕМЕНТЫ УСТРОЙСТВА



- | | |
|---|-------------------------------|
| 1-Кнопка питания/Сканер отпечатков пальца | 8-3,5-мм разъем для наушников |
| 2-Настраиваемая кнопка | 9-Зарядный порт Type-C |
| 3-Селфи-камера | 10-Вспышка |
| 4-Приемник | 11-Основная камера |
| 5-Световой сенсор/Датчик приближения | 12-NFC |
| 6-Светодиодный индикатор событий | 13-uSmart Expansion Connector |
| 7-Speaker | 14-Громкость |

[11]

RU

2. ПЕРВОЕ ВКЛЮЧЕНИЕ

2.1 Зарядите батарею

Подключите идущий в комплекте USB-кабель к Type-C разъему планшета. Подключите кабель к зарядному устройству, а зарядное устройство в розетку. Планшет начнет процесс зарядки, вы увидите индикацию на дисплее.

2.2 На несколько секунд зажмите кнопку питания для включения.



ВАЖНО:

Полностью зарядите батарею перед первым использованием планшета.

3. Комплектация



Планшет



Зарядное устр-во



Типо-С




Краткое руководство пользователя

[12]

UA

1. ОСНОВНІ ЕЛЕМЕНТИ ПРИСТРОЮ



- | | |
|--|---------------------------------------|
| 1-Кнопка ввімкнення/Боковий датчик відиномік | 8-Джек для слухових телефонів 3, 5 мм |
| 2-Налаштована кнопка | 9-Порт зарядки Type-C |
| 3-Передня камера | 10-Спалах |
| 4-Приймач | 11-Задня камера |
| 5-Сенсор світла/Датчик наближення | 12-NFC |
| 6-Світлодіодний індикатор | 13-uSmart Expansion Connector |
| 7-Мікрофон | 14-Гучність |

[13]

UA

2. ПЕРШЕ ВКЛЮЧЕННЯ

2.1 Зарядіть батарею

Підключіть йде в комплекті USB-кабель до Type-C роз'єму планшета. Підключіть кабель до зарядного пристрою, а зарядний пристрій в розетку. Планшет почне процес зарядки, ви побачите індикацію на дисплеї.

2.2 На кілька секунд затисніть кнопку живлення для включення.



ВАЖЛИВО:

Повністю зарядіть батарею перед першим використанням планшета.

3. Комплектація



Планшет



Зарядний пристрій



Type-C




Короткий посібник користувача

[14]

JP

1. 各部の紹介



1-電源鍵/側面指紋

2-カスタムボタン

3-フロントカメラ

4-イヤホン

5-光線センサー/距離センサー

6-フラッシュ

7-スピーカー

8-3.5mmヘッドフォンジャック

9-タイプC充電口

10-フラッシュ

11-リアカメラ

12-NFC

13-uSmart Expansion Connector

14-ボリューム

[15]

2.初めにお読みください。

2.1 充電について

USBケーブルをタブレットのType-Cポートに接続します。
ケーブルを充電アダプターに接続し、アダプターを電源コンセントに接続します。
タブレットの充電が始まり、通知LEDライトが点灯します。


2.2 ON/OFFボタンを長押しと、起動/OFFします。




警告:

最初の充電中および最初の使用前に、バッテリーを完全に充電してください。

3.梱包内容:



タブレット



充電器



Type-Cケーブル



クイックスタートガイド

[16]

CE Warning

1. Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.

2. CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

3. The product shall only be connected to a USB interface of version USB2.0.

4. Adapter shall be installed near the equipment and shall be easily accessible.

5. Operation temperature:-10~40C

6. The plug considered as disconnect device of adapter.

7. SAR: The device complies with RF specifications when the device used at 5mm from your body (SAR limit 2.0W/Kg), The device is in compliance with the requirements.



[17]

This information has to be presented in such a way that the user can readily understand it. Typically, this will necessitate translation into every local language (required by national consumer laws) of the markets where the equipment is intended to be sold. Illustrations, pictograms and using international abbreviations for country names may help reduce the need for translation.

Restrictions in the 5 GHz band:

According to Article 10 (10) of Directive 2014/53/EU, the packaging shows that this radio equipment will be subject to some restrictions when placed on the market in Belgium (BE), Bulgaria (BG), the Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE), the United Kingdom (UK), Turkey (TR), Norway (NO), Switzerland (CH), Iceland (IS), and Liechtenstein (LI).

The WLAN function for this device is restricted to indoor use only when operating in the 5150 to 5250 MHz frequency range.



FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of this Device GQ3019(FCC ID: 2AOWK-3109SH5) has been tested against this SAR limit. SAR information on this can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested for typical operations 0mm from the body. The device can be used in portable exposure conditions without restriction.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

[20]

ulefone®
All Rights Reserved

The information contained herein is subject to change without notice. The only warranties for Connect and services are set forth in the express warranty statements accompanying such products and services.

Nothing herein should be construed as constituting an additional warranty. Connect shall not be liable for technical or editorial errors omissions contained herein.

Shenzhen Gotron Electronic CO., LTD
Address: Floor 7, Building A, Block 1, Anhongji Tianyao Plaza,
Longhua District, Shenzhen City, Guangdong Province China

Service Center
Email: service@ulefone.com



[21]

Function	Operation Frequency	Max RF outputpower:
BT(BR+EDR)	2402MHz~2480MHz	<10dBm
BLE	2402MHz~2480MHz	<10dBm
WIFI 802.11b/g/ n(HT20,HT40)	802.11b/g/n(20MHz): 2412~2472MHz; 802.11n(40MHz):2422~2462MHz	<20dBm
Wi-Fi 5.2G(802.11a/n20/n40 /ac20/ac40/ac80)	802.11a/ n20/ac20:5180MHz~5240MHz 802.11 n40/ac40:5190MHz~5230MHz 802.11ac80:5210MHz	<20dBm
Wi-Fi 5.8G(802.11a/n20/n40 /ac20/ac40/ac80)	802.11a/ n20/ac20:5745MHz~5825MHz 802.11 n40/ac40:5755MHz~5795MHz 802.11ac80:5775MHz	<13.98dBm
FM	Rx(Downlink): 87.5MHz~108MHz	--
GPS	Rx(Downlink): 1.57542GHz	--
NFC	13.56MHz	<60dBuA/m@10m