

产品说明书
—Product description—

YYK-520
无线商务耳机

产品示意图

配对示意图

多功能按键

多功能按键

开机机

给充电仓充电

产品规格

版本	V5.1
支持蓝牙	A2DP.AVRCP.HFP.HSP.EDR
通信距离	≥10m
频带	2.402GHz-2.480GHz
喇叭阻抗	13Ω±10%
待机时间	180h
通话时间	8-10小时
音乐播放时间	8-10小时
耳机电池容量	60mAh
充电仓电池容量	500mAh
耳机充电时间	约1.5小时
充电仓充电时间	约1.5小时
产品重量	71g

为什么耳机会自动关机?

请确保耳机有足够的电量,另外耳机将自动断开蓝牙连接10min,将耳机重新放入充电仓,拿起耳机将自动开机。

为什么不能给充电仓充电?

1.确保充电线或者充电器是良好状态且正确连接。2.可能接触不良,用手指接触耳机将耳机的充电触点完全连接到充电盒。3.耳机的充电触点可能被多尘或汗液污染,放入充电仓充电。4.耳机请把汗水放回充电仓,耳机指示灯亮起。5.如果听到“Battery Low”的提示音,请为耳机充电。充电LED显示编号达到“10”时,请为耳机充电。请注意不要使耳机和充电盒中的电量耗尽,可能会缩短锂电池的使用寿命。

安全预防

高质量的耳机,为了延长使用寿命,请参考以下说明:1.请让产品远离高温、高湿、腐蚀、灰尘。2.请防止产品被撞击、跌落、弯曲、浸泡。3.请不要拆卸重新组装产品,以免发生故障或火灾。4.请避免接触腐蚀性液体,以免损坏产品。5.不要放在-10摄氏度以下或者50摄氏度以上的极端温度下。6.远离小孩或者宠物。7.1个月内不使用的话,为了安全运行,请定期充电。8.因为蓝牙信号不能在水中传输,游泳潜水将导致信号断开或者中断。

为什么我搜索不到蓝牙?为什么不能连接蓝牙?

1.蓝牙的距离是10m,请确保没有障碍物,手机需要靠近耳机。2.如果有其他手机或者设备连接过该耳机,请先解除配对。3.请重新启动蓝牙设备,然后尝试重设耳机。

产品包装内有

- 1.蓝牙耳机1个
- 2.充电座1个
- 3.Type-c充电线1条
- 4.另外的耳帽2个
- 5.说明书1本

User Manual
—Product description—

YYK-520
Wireless business headset

Product Photo

Wireless Pairing

MFB Button

MFB Button

ON/OFF switch

How to recharge the charging bin

1. Please use a mobile phone adapter to recharge the charging bin. You may charge via a Type-c cable connected to a computer, or other charger with a Type-c interface.
2. The digital display of the charging bin will indicate the recharging process, and 100% battery level means fully recharged.

Product specification

Version	V5.1
Wireless support	A2DP.AVRCP.HFP.HSP.EDR
Communication range	≥10m
Frequency band	2.402GHz-2.480GHz
Electrical impedance	13Ω±10%
Standby time	180h
Music playing time	8-10h
Earbuds battery capacity	60mAh
Host battery capacity	500mAh
Charging bin recharging time	About 1.5h
Charging time of headset	About 1.5h
Weight	71g

Mobile phone transmission range

The transmission distance of the mobile phone is shown in the following chart

Why do the earbuds turn off automatically?

Please ensure sufficient battery. In addition, the earbuds will automatically disconnect Wireless for 10min. Please take the earbuds back to the charging bin and they will restart after reconnection.

Why cannot I recharge the charging bin?

1. Please ensure the charging cable or mobile phone charger is in good state and with proper connection.
2. To ensure proper connection, press the earbuds to the charging points to the charging bin.
3. The earbud charging points might be stained with dust or sweat. When placing them into the charging bin for recharging, please clean with alcohol or cloth.
4. Please wipe the sweat on the earbuds before putting them into the charging bin, and the indicator lights will turn on.
5. Once the prompt tone “Battery Low” appears, please recharge the earbuds. When the number displayed by the LED lights on the charging bin reaches “10”, please recharge the charging bin. Please pay attention to not using up the battery of the earbuds and charging bin, as it is shorter the service life of the built-in lithium battery.

Safety Precautions

To guarantee the service life of the quality earbuds, please refer to the instructions as follows:

1. Please keep away from high temperature, high humidity and corrosive environment.
2. Please avoid bumping, fall, bending, soaking, and etc.
3. Please do not disassemble the earbuds or charging bin.
4. Please do not overcharge it for long time, which will shorten the service life.
5. In the case of feeling any discomfort or pain, please stop using the product.
6. Please use certified DC 5V-1A adapter from manufacturer under the supervision of regulatory authorities. Repeat charging and discharging will impair the battery performance over time, which needs to recharge all the time.

Packing Contents

1. Earbuds * 1
2. Charger * 1
3. Type-C charging cable * 1
4. Ear caps * 2
5. User Manual * 1

<p>FCC Warning</p> <p>15.19 Labeling requirements.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>15.21 Information to user.</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>15.105 Information to the user.</p> <p>Note: This equipment has been tested and found to comply with</p>	<p>the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference</p>	<p>will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">-Reorient or relocate the receiving antenna.-Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different	<p>from that to which the receiver is connected.</p> <ul style="list-style-type: none">-Consult the dealer or an experienced radio/TV technician for help. <p>FCC RF Radiation Exposure Statement:</p> <ol style="list-style-type: none">1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm <p>between the radiator and your body.</p>
--	--	---	--