




Get started

With a cable
Connect the cable between your Type and computer. Ready!

Wireless use

1. Move the switch under your TYPE to ON.
2. Press the CONNECT button under your TYPE. The LED will now start flashing blue. Open your computers Bluetooth menu and connect to the unit named MT TYPE.
3. To charge the unit, if needed, connect the cable to your computer or power source when the LED is flashing RED.

Erste Schritte

Mit Kabel
Verbinden Sie Ihren Type und Ihren Computer mit dem Kabel. Fertig!

Kabellose Nutzung

1. Stellen Sie den Schalter unter Ihrem TYPE auf EIN.
2. Drücken Sie die CONNECT-Taste unter Ihrem TYPE. Nun beginnt die LED-Leuchte blau zu blinken. Öffnen Sie das Bluetooth-Menü Ihres Computers und verbinden Sie ihn mit der Einheit mit der Bezeichnung MT TYPE.
3. Um die Einheit bei Bedarf aufzuladen, schließen Sie das Kabel an Ihren Computer oder die Stromversorgung an, wenn die LED-Anzeige ROT leuchtet.

Démarrage


Avec un câble
Branchez le câble entre votre Type et votre ordinateur. C'est prêt!

Utilisation sans fil

1. Mettez l'interrupteur sous votre TYPE sur ON.
2. Appuyez sur le bouton CONNECT sous votre TYPE. La LED se met alors à clignoter en bleu. Ouvrez le Bluetooth de votre ordinateur et connectez-vous à l'unité nommée MT TYPE.
3. Pour charger l'appareil, si nécessaire, connectez le câble à votre ordinateur ou à une source d'alimentation lorsque le voyant clignote en rouge.



You can also scan the QR-code to follow the steps and learn even more about Type. Or visit mousetrapper.com/get-started-with-type



Change button functions

The button functions can easily be reprogrammed with MT Keys – which you can launch in your browser using the designated button (F1). Read more at mousetrapper.com/software

Tastenfunktionen ändern

Die Tastenfunktionen können mit MT Keys problemlos neu programmiert werden, was Sie über die vorgesehene Schaltfläche (F1) in Ihrem Browser ausführen können. Erfahren Sie mehr auf mousetrapper.com/software

Modifier les fonctions des touches

Les fonctions de bouton peuvent être facilement reprogrammées avec les MT Keys, que vous pouvez lancer dans votre navigateur à l'aide du bouton désigné (F1). Pour davantage d'informations, consultez mousetrapper.com/software

Fight the Pain



Mousetrapper®

Fight the Pain

www.mousetrapper.com



Mousetrapper

Type

Mousetrapper Type


Designed in Sweden

654,8

37,5

Mousetrapper®

Mousetrapper® Type
AT No. TB463
Made in China



7 453007 142034



Designed in Sweden
www.mousetrapper.com

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.