

PRODUCTION WORKSHEET

PRODUCT	BIBI MANUAL DESIGN	MANUFACTURER	
---------	---------------------------	--------------	--

- SIZE:(W) 320 *(H) 160 mm
- MATERIAL: Art Paper 150g
- The above image may differ from the actual product

- FCC Statement

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept

any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

- Industry Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC and IC RF Radiation Exposure Statement:

This equipment complies with FCC and IC RF Radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

RF du FCC et IC d'exposition aux radiations:

Cet équipement est conforme à l'exposition de FCC et IC rayonnements RF limites établies pour un environnement non contrôlé. L'antenne pour ce transmetteur ne doit pas être même endroit avec d'autres émetteur sauf conformément à FCC et IC procédures de produits Multi-émetteur.

BIBI OFFICIAL LIGHT STICK USER MANUAL

HOW TO INSERT AND REPLACE BATTERIES

1. Turn and open the cap underneath the handle to remove the battery socket.
2. Insert three AAA alkaline batteries in the battery socket as shown.
(Ensure the + and - terminals are facing the right direction. The - terminal should touch the spring, and the + terminal should touch the flat end of the socket.)
3. Insert the battery socket with batteries inside into the product in the direction of the arrow shown and close the cap at the bottom.
(Ensure the battery socket is inserted in the right direction. Inserting it in the wrong direction prevents the light stick from functioning and can cause damage.)

PRODUCT FEATURES AND USAGE INSTRUCTIONS


- BIBI OFFICIAL LIGHT STICK is a product with wireless control function.
- Power Setting : Press the button on the light stick to turn the product on.
- LED Mode Setting : EVE ON → EVE-1 ON ^ EVE DIMMING → EVE-1 DIMMING → BIBI MODE → NAKED BIBI MODE → OFF
- Press and hold the button for 3 seconds to turn on 「Bluetooth mode」.
(Please use this mode when entering seat information.)
- Pressing and holding the button for 3 seconds in 「Bluetooth mode」will turn on「Concert mode」.
(Please use this mode during a concert.)

PRODUCT SPECIFICATION

- Product Name : BIBI OFFICIAL LIGHT STICK
- Model : BIBI OFFICIAL LIGHT STICK
- Size : 105 x 80 x 246 (mm)
- Weight : Approximately 210g
- Materials : PC, ABS, SILICONE
- Components : Light Stick, Strap, User Manual, Photocard
- Battery : Not Included (Use 3 alkaline AAA batteries)
- Rated Voltage : 4.5V
- Radio Frequency : 2.4 GHz
- Operating Time : About 5 Hours
- Manufacturer : FANLIGHT Co., Ltd.
- Date of Manufacture : 2025. 00
- Country of Origin : Made in China
- Brand: FANLIGHT

PRECAUTIONS

- Store at room temperature to avoid high temperature or humidity.
- Do not shine the LED light directly into the eyes.
- Product malfunction can be caused by arbitrary disassembly and assembly, shock, or usage near water or fire.
- When changing batteries, use new authentic alkaline AAA batteries. Using other types of batteries (such as manganese batteries) may cause product malfunction or damage.
- Change all 3 batteries when replacing batteries.
- When storing the product, remove the batteries to prevent damage from the battery fluid.
- Keep batteries out of reach of children/infants and dispose of used batteries at the designated disposal site.
- Be sure to check the battery +/- polarity and insert the batteries in the correct polarity direction. (Incorrect insertion may cause product malfunction, fire, and/or heat burns.)
- If the batteries suddenly become hot, remove the batteries immediately and visit the 「Wireless Control Fanlight Support Center」at the concert venue.
- During a concert, if the light stick suddenly loses wireless control or turns red, please replace the batteries (all 3) with new ones as the batteries are discharged.
- Replacing all batteries with new ones before each concert is recommended.
- In rare occasions, radio frequencies and other wireless signals used at concerts may interfere with the product's wireless functions. This is not a product failure.



CUSTOMER SERVICE POLICY

- Please open the product when purchased, and if it is defective, visit the 「Wireless Control Fanlight Support Center」 at the venue with its receipt. (Please understand in advance that return and exchange services are not possible after the concert.)
- Free repair is unavailable if any of the following cases apply
 - Product damage or malfunction caused by the user's negligence
 - Product damage or malfunction caused by natural disasters such as flood, fire and/or earthquake
 - Request for a product replacement for scratches from usage
 - Minor scratches on the product that may occur during the manufacturing or shipping process
 - Use of customer service centers other than the official customer service center, or performing arbitrary disassembly, repair or modification to the product
- Product specifications are subject to change without prior notice to improve product performance which is not a valid reason for exchange or refund.
- During shipping, there may be crumpling, tearing, and damage to the package box.

APPLICATION FOR CUSTOMER SERVICE

FANLIGHT Co., Ltd. | Phone : 070-4848-5125 | E-mail : cs@fanlight.com
Warranty Period : 3 months from the date of purchase (Receipt verification is required)