

Front



Monster Boombox Go Speaker

ALTAZOZ INALAMBRICO PORTATIL CONCORRER DE TRANSPORTE + ESPECTACULO DE LUZES LED

Model: 2MNSK2173

CONTROLS:

Power On: Hold the power button to hear the prompt tone. The blue light flashes to indicate successful startup. Hold again to hear the prompt tone, and the light goes off, indicating successful shutdown.

Light Button: Press to change the light color. Hold to turn on/off the LED light.

Play/Pause: Press "▶" to Play or Pause

Bluetooth mode: Hold "▶" to disconnect the Bluetooth connection.

Phone mode: Double-click "▶" to call back the last dialed phone number; Press "▶" to hang up the phone.

TWS pairing mode: When two speakers are Powered On and not connected to a phone or other bluetooth devices, Hold "▶" button to enter or disconnect TWS.

Next/Prev Keys: Click the plus and minus keys to adjust the volume, and Hold to switch between the next and previous songs.

Mode Buttoning: Click the multi-function key (M Key) to switch between TF card/U disk, Bluetooth mode, and AUX mode.

BLUETOOTH PAIRING:

1. Hold the power button to turn on the Bluetooth speaker. After startup, a pure music prompt tone and a flashing LED blue light indicates that the speaker is in Bluetooth mode and ready to be searched.
2. Turn on the Bluetooth of your mobile phone or other Bluetooth devices, search for the Bluetooth name "Monster Boombox Go," and click to pair.
3. Upon successful pairing, there will be a "connected" prompt tone, the LED light will stay on, and flash slowly during music playback.
4. Hold the playback pause button to disconnect the mobile phone or other Bluetooth devices from the speaker.

TWS PAIRING

Turn on both speakers simultaneously, before connecting to a phone or other bluetooth devices, Press and hold any playback pause button, and after a few seconds, the speakers will pair successfully. (Please note that if the speaker was connected with a bluetooth device, then they can't enter TWS mode, they need to be disconnected from the bluetooth device first)

MUSIC PLAYBACK:

Click the play/pause button to play or pause music. Use the plus and minus buttons to adjust the volume, and Hold to switch to the next song.

CALL ANSWERING/DIALING OPERATION:

After successful pairing, double-click the playback pause button to call back the last dialed phone number, and Press to hang up. When a call is received, Hold the play/pause button to reject, Press to answer, and press again to hang up.

TF CARD/U DISK/AUX:

Insert the TF card or U disk into the card slot for automatic playback. The LED will flash slowly. The speaker will read audio files and can be controlled using the buttons.

Insert the audio cable into the AUX hole, and the speaker will automatically play audio from the connected device.

BLUETOOTH SPEAKER CHARGING:

Use the provided charging cable with a charging voltage of DC5V.

The red light will be on during charging and turn off when fully charged.

USE OF COLORFUL LIGHTING EFFECTS:

Hold the Light button to turn on/off the LED light. Choose between 13 different effects.

BUTTON BETWEEN BLUETOOTH AND TF CARD FUNCTION:

After connecting to Bluetooth and inserting a TF card, click the Mode Button key (M key) to switch between different playback modes.

IMPORTANT SAFETY INFORMATION:

Before using the Bluetooth speaker, review these safety tips:

Read and understand all safety guidelines.

Use charging equipment with an output voltage of DC5V/1A to avoid damage.

Turn off the built-in lithium battery when not in use.

Keep the product away from high heat sources; do not expose it to high temperatures.

Avoid dropping or applying heavy pressure to the product.

*Playtime based on Music at 50% Volume

Back

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty

What is covered under the 2 Year Warranty?

Monster® warrants that this product will be free from defects in workmanship and materials under normal use ("Limited Warranty"). In a case where the product is determined to be "defective", we will repair the product free of charge. If we cannot repair the product, we will replace it for you free of charge.

How long am I covered?

You are covered for the 2 Years from Purchase

What is not covered under the Limited Warranty?

1. Normal wear and tear of product use.
2. Misuse, lack of care, mishandling, accidental damage, abuse or other abnormal use.
3. Use of the product other than for its intended purpose.
4. Damage caused by improper or unauthorized repair or maintenance.
5. Product that has been modified or altered.
6. Any product that is not manufactured by Monster® (including, without limitation, any non-Monster® product that is used in connection with the product).

Play/Pause, Answer/End Call, TWS Mode
Power On/Off
Mode
Next Track/ Volume Up
Previous Track/ Volume Down
Light Show / Switch

USB Port
TF Card
Aux Port
USB-C Charging Port

USB-C Charging Port
TF Card
Aux Port
USB Port



website: monsterstore.com

support: support@monsterforever.com

2 Year Limited Warranty

Package Contents: (1) Speaker, (1) USB-C™ Charging Cable, (1) User Manual

Manufactured and distributed by Lifeworks Technology Group LLC, under license, New York, NY 10018, C0203. The M/Monster logo and the M slice logo are trademarks or registered trademarks of Monster Inc. and its subsidiaries in the U.S. and other countries and are used under license. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. USB-C is a registered trademark of USB Implementers Forum. Other trademarks and trade names are those of their respective owners. MADE IN CHINA

 **WARNING:** This product can expose you to chemicals including Lead and Lead Compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov. **ADVERTENCIA:** Este producto puede exponerlo a químicos incluyendo Lead and Lead Compounds, que es (son) conocido (s) por el Estado de California como causante (s) de cáncer y defectos de nacimiento u otros daños reproductivos. Para mayor información, visite www.P65Warnings.ca.gov.