

ITEM #: 000 000


MODEL#: LT2204304GW-BK

LT2204304GW-WH

HAMPTON BAY®

USE AND CARE GUIDE

LED table lamp



Questions, problems, missing parts?

Before returning to the store, call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this light fixture. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Safety / Security Information

For your safety, please read carefully and fully understand the information provided in this manual before using the lamp. Failure to do so may result in electric shock, fire or other dangerous or even fatal injuries.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1.This device may not cause interference. 2.This device must accept any interference, including interference that may cause undesired operation of the device. This equipment should be installed and operated with a minimum distance of 10 cm between the radiator and your body.

Specification parameter

Adapter input: 100-240V ~ 50/60Hz, 0.5A.

Output: 5Vdc, 3A 15W

Lamp input: 5VDC, 1.2A 6W.


Wireless charge and output: 5Vdc, 1.0A 5W

A minimum distance of 0.2m must be kept between the lamp cap and any lighting object.



Operating instructions of lamps

1. Connect the connector behind the adapter lamp.



2. Touch the switch button, touch the lamp on, and touch the lamp off again.



3. Five-gear color temperature adjustment button, the default value is 3000k, touch 3500k once, touch 4000k again, touch 5000k again, and touch 6500k again.




4. Touch the power-off touch key once, turn off the lights for 0.5H, and the green indicator lights up. Touch it again for 1H to turn off the lights, while the blue indicator lights up, and then touch the power-off button again.




5. Brightness level touch bar, 50% on by default, 10% at the lowest touch, and gradually brighten to 100% by sliding from left to right. Any color temperature segment can be dimmed by touch bar.



6. Wireless charging area, the phone can be charged when placed in the center.



7. The angle adjustment range of the lamp is as shown in the figure (excessive adjustment of the movable joint will cause product damage).



Instructions for use and care of lamps and lanterns

1. Lamps and lanterns are only used indoors.
2. Keep it out of the reach of young children and pets.
3. Before cleaning the lamps and lanterns, it is necessary to disconnect the power supply, carefully wipe or remove dust with a dry and soft cloth, or wipe the outer surface of the lamps and lanterns with a slightly damp cleaning cloth (do not use any detergent containing chemicals, solvents or irritants).
4. When the lamp is working, the lamp head will heat up, which is a normal phenomenon.
5. If you don't use the lamp for a long time, disconnect the power adapter from the socket.
6. Replace the light source for non-users.
7. Lamps can only be repaired by qualified technicians according to standards/specifications.
8. Please use the adapter provided by our company; Using adapters from other manufacturers may damage the lamps or cause personal injury.
9. If the lamp, wire or plug is damaged, please do not operate the lamp and send it to the service center for repair.
10. If the lamp falls into the water, please send it to the service center for repair.
11. Do not use lamps in flammable and explosive places.

Common troubleshooting

Fault phenomenon 1. Lamps can't light up.

Treatment method: First check whether the connection points between the adapter and the lamp and the power socket are in good contact. If it is in poor contact, reconnect it.

Fault 2. Lamps can't charge mobile phones.

Treatment: Check whether the mobile phone and the wireless charging logo are in the same position, if not, re-adjust the mobile phone position.

Fault phenomenon 3. Switch failure or disorder of lamps and lanterns keys.

Treatment: If the control panel is damaged, contact our local service personnel for repair.

After-sale protection

1. Warranty commitment: the detailed rules in the Three Guarantees Regulations promulgated by relevant state departments shall apply. If the product itself has quality problems, the whole machine will be guaranteed for 3 years free of charge with the warranty card from the date of purchase by the user.
2. The following situations are not covered by the free warranty "
 1. Failure to use, maintain and keep the product according to the requirements of the product instructions, resulting in failure or damage.
 2. can't produce a valid warranty card and proof of purchase.
 3. Damage caused by connecting the power supply with inappropriate voltage or refitting accessories.
 4. Products that have exceeded the specified warranty period.
 5. The warranty card will not be guaranteed after alteration.
3. Please properly package and transport the products sent for repair. If there is any damage or loss in the process of transportation, our company will not pay any responsibility.

FCC Warning

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

HAMPTON BAY[®]

Questions, problems, missing parts?

Before returning to the strore, call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manial for future use