



Wireless keyboard

ITEM: RWK-01
USER'S MANUAL

Thank you for purchasing the QUB Works 2.4GHz Wireless Keyboard & Mouse, item RWK-01. Included with your set is a USB Nano Receiver that can be stored inside the mouse itself, making it perfect for use with laptop computers and easy to carry when traveling. Please read this manual carefully FIRST in order to get the most out of your keyboard and mouse.

INSERTING BATTERIES

In order to operate your keyboard and mouse successfully, you will need to insert 2AAA batteries (not included) into the keyboard and 1AA battery into the mouse. To do so follow the steps below:

1. Pull the battery compartment covers off of both the keyboard and mouse, revealing the battery compartment. The battery compartment covers are located on the bottom of the mouse and the bottom of the keyboard.
2. Insert 2AAA batteries into the keyboard's compartment and 1AA battery into the mouse, making sure to insert them with the correct polarity (+-) as shown on the battery compartment.
3. Once your batteries are properly inserted, you can put the battery compartment covers back on the keyboard and mouse.

For best results always use new alkaline batteries when powering your keyboard and mouse. Do not mix old and new batteries or different types of batteries.

2.4GHz
WIRELESS

KEYBOARD AND MOUSE SETUP

In order to connect your keyboard and mouse to your computer, follow the steps below:

1. Take the USB Nano Receiver from the bottom of your mouse.
2. Plug the USB Nano Receiver into an available USB port on your computer.
3. Make sure that both computer, keyboard and mouse are powered on.



USB

NOTES

-The mouse will stop working once you pull the receiver out of the USB port or the computer is turned off.

-You can store your mouse's USB Nano Receiver underneath your mouse, making it even extra portable and easy to store when not in use.



Optical Sensing



FEATURES AND SPECIFICATIONS

- Radio Frequency: 2.4G Hz
- Mouse Resolution up to 1000 DPI
- Keyboard Output DC3.0V 10mA
- Mouse Output: DC 1.5V 15mA
- Keyboard: 2AAA Batteries
- Mouse: 1AA Batteries
- Operating Distance: 10 meters
- Compatible with windows 2000/XP/98/ME/NT4.0/vista/7/8/10

IMPORTANT SAFETY PRECAUTIONS

When using your mouse, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR KEYBOARD AND MOUSE.
2. Never expose your keyboard and mouse to high temperatures, extreme cold, high humidity or any moisture or water.
3. In order to avoid the risk of electric shock, never attempt to open your keyboard and or repair them without the assistance of certified professionals.
4. Your keyboard and mouse are not to be used by children or the infirm without suitable adult supervision.
5. Do not use your keyboard and mouse at temperatures under 32°F (0°C) or over 104°F (40°C).
6. Do not drop your keyboard and mouse, throw them, or subject them to strong impacts or physical trauma.
7. If you detect any abnormalities when using your keyboard and mouse, contact the manufacturer for support.
8. Keep this manual and all relevant information for future reference.
9. Clean your keyboard and mouse using a soft cloth or paper towel. Do not use harsh chemicals when cleaning, and never submerge your keyboard and mouse in water.
10. Please recycle or dispose of your keyboard and mouse properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your keyboard and mouse for further information.



CAUTION

Risk of Fire and Burns.
 Do Not Open, Crush, Heat Above 104°F (40°C) or Incinerate.
 Always Follow All Manufacturer's Instructions When Using.

TROUBLESHOOTING

If your Keyboard and Mouse are not working properly, please try the following:

- Make sure that your keyboard, mouse and your computer are powered on.
- Make sure the distance between the devices is less than 10m.
- Make sure that your computer has suitable drivers for recognizing a USB keyboard and mouse.
- Make sure the batteries in your keyboard and mouse have been inserted correctly.

SAKAR ONE YEAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-877-397-8200 or visit our website at www.sakar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepairable.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.