

## Internal Photos


### OPEN VIEW OF EUT




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2



INTERNAL VIEW OF EUT-3



INTERNAL VIEW OF EUT-4



INTERNAL VIEW OF EUT-5




**Series Model**  
**KBJ-103N-T8290-BTH**  
**OPEN VIEW OF EUT**




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2



INTERNAL VIEW OF EUT-3



## INTERNAL VIEW OF EUT-4



## INTERNAL VIEW OF EUT-5

