



SEND CUSTOMER SERVICE INQUIRIES TO
OPENROADBRANDS.COM/CONTACT

FCC STATEMENT: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions
(1) this device may not cause harmful interference, and (2) this device must accept any
interference received, including interference that may cause undesired operation. This
device has been evaluated to meet general RF exposure requirement. The
device can be used in portable exposure condition without
restriction.

BLUETOOTH SPEAKER

Quick Start Guide

CHARGE

CONNECT BLUETOOTH SPEAKER TO A USB PORT. CHARGE WITH CABLE (INCLUDED).

PAIR

USE TOP SWITCH TO TURN ON BLUETOOTH SPEAKER. IT WILL ENTER
DISCOVERABLE MODE. SEARCH FOR OPENROAD CAN
IN DEVICE'S BLUETOOTH SETTINGS. SELECT DEVICE TO PAIR.

PLAY

CENTER BUTTON: TAP FOR PLAY/PAUSE, ANSWER/END PHONE.
TAP TWICE FOR NEXT TRACK.
TAP OR HOLD (+)(-) BUTTONS FOR VOLUME CONTROL.

NAME: Can Speaker

MODEL: OR-BT-4-6

FCC ID: 2APCV-ORBT46